Direction "from": Message A

Key	Value	Meaning
setpointType	absolute	Setpoint type used by the device
	relative	Setpoint type used by the device

Direction "to": Message B

Key	Value	Meaning
baseSetpoint	15 ... 30, step 1	Visualization of the temperature setpoint
coolingSymbol	off	Enable/disable cooling symbol
	on	Enable/disable cooling symbol
fanSpeed	auto	Override actual fan speed
	notAvailable	Override actual fan speed
	speed0	Override actual fan speed
	speed1	Override actual fan speed
	speed2	Override actual fan speed
	speed3	Override actual fan speed
heatingSymbol	off	Enable/disable heating symbol
	on	Enable/disable heating symbol
occupancyState	occupied	Overrride occupancy State
	unoccupied	Overrride occupancy State
setpointType	absolute	Setpoint type used by the device
	relative	Setpoint type used by the device
temperatureCorrection	0 ... 255, step 1	Override Setpoint offset
validTempCorrection	1	-1…1
	10	-10…10
	2	-2…2
	3	-3…3
	4	-4…4
	5	-5…5
	6	-6…6
	7	-7…7
	8	-8…8
	9	-9…9
windowOpen	off	Enable/disable window open symbol
	on	Enable/disable window open symbol

Direction "from": Message C

Key	Value	Meaning
baseSetpoint	15 ... 30, step 1	Internal baseSetpoint required absolute setpoint
fanSpeed	auto	Fan speed
	notAvailable	Fan speed
	speed0	Fan speed
	speed1	Fan speed
	speed2	Fan speed
	speed3	Fan speed
humidity	0 ... 100, step 0.4	Humidity value
occupancyState	occupied	Occupancy state
	unoccupied	Occupancy state
setpointOffset	0 ... 255, step 1	Setpoint shift
setpointType	absolute	Setpoint type used by the device
	relative	Setpoint type used by the device
telegramType	heartbeat	Telegram trigger
	userInteraction	Telegram trigger
	valueChange	Telegram trigger
temperature	0 ... 40, step 0.157	Temperature value
validTempCorrection	1	-1…1
	10	-10…10
	2	-2…2
	3	-3…3
	4	-4…4
	5	-5…5
	6	-6…6
	7	-7…7
	8	-8…8
	9	-9…9