Direction "from": Request actual data

Key	Value	Meaning
roomId	1 ... 15, step 1	Room Number

Direction "to": Override device parameters

Key	Value	Meaning
batterySymbol	hide	Hide battery symbol
	show	Show battery symbol
coolingSymbol	hide	Hide cooling symbol
	show	Show cooling symbol
errorCode	noError	No error to report
	sensorError	One or more sensors ceased to function
	unknownError	Undefined error happend
	valveError	One or more heating valves failed
heatingSymbol	hide	Hide heating symbol
	show	Show heating symbol
humidity	0 ... 100 [%], step 1	Transmitted humdity
	notAvailable	Humidity currently not available
occupancySymbol	hide	Hide occupancy symbol
	show	Show occupancy symbol
roomId	1 ... 15, step 1	Room Number
setpoint	8 ... 28 [°C], step 0.5	Gateway base setpoint
temperature	0 ... 40 [°C], step 0.5	Transmitted temperature
	notAvailable	Temperature currently not available
windowOpenSymbol	hide	Hide window open symbol
	show	Show window open symbol

Direction "from": Transmit setpoint of one room

Key	Value	Meaning
roomId	1 ... 15, step 1	Room Number
setpoint	8 ... 28 [°C], step 0.5	Sum of base setpoint and local user changes

Direction "from": Transmit heartbeat and measurements

Key	Value	Meaning
humidity	0 ... 100 [%], step 1	Actual room humidity
	notAvailable	Humidity currently not available
request	noAnswer	No answer requested
	receiverOpen	Receiver open for an answer
telegramTrigger	heartbeat	Heartbeat
	valueChange	Change of measurement
temperature	0 ... 40 [°C], step 0.5	Actual room temperature
	notAvailable	Temperature currently not available