Direction "from": Sensor Telegramm: Recieved Values

Key	Value	Meaning
illumination	0 ... 100000 [lx], step 1	Illumination (linear)
presence	noPresenceDetected	PIR inactive
	notDetectable	PIR currently unable to detect.
	presenceDetected	PIR active due to presence in FOV
soundPressure	0 ... 204.6 [dbSPL], step 0.1	Sound Pressure in vicinity
temperature	0 ... 50 [°C], step 0.1	temperature sensor measurement

Direction "from": Sensor Telegramm: Error Report Recieved

Key	Value	Meaning
sensorError	illuminationError	Illumination out of range error or malfunction
	presenceError	PIR sensor reports malfunction
	soundPressureError	Sound pressure out of range or malfunction
	temperaturError	Temperatur out of range error or malfunction