Direction "from"

Key	Value	Meaning
humidity	0 ... 100 [%], step 0.5	Relative humidity (linear)
	invalid	Invalid humidity value
	notSupported	Sensor does not support humidty
leakDetection	leakDetected	Active leakage detected
	noLeakDetected	No leakage detected
	sensorError	Leakage sensor reported error
pastLeakDetection	leakDetected	Active leakage was detected
	noLeakDetected	No leakage was detected
temperature	0 ... 50 [°C], step 0.1	Measurement of Temperature (linear)
	error	Invalid temperature value