Direction "from"

Key	Value	Meaning
current1	0 ... 4095 [A], step 0.1	Current value channel 1
current2	0 ... 4095 [A], step 0.1	Current value channel 2
powerFailureDetected	false	Power failure not detected
	true	Power failure detected