Direction "from": Dispenser state

Key	Value	Meaning
channel	0 ... 255, step 1	Number of the channel of the dispenser. Each device starts with channel #0
errorCode	deviceEmpty	Error code of the device
	groundLoop	Error code of the device
	measurementsTooLow	Error code of the device
	noError	Error code of the device
	reserved	Error code of the device
	sensorCommunicationFailed	Error code of the device
	tooMuchIR	Error code of the device
materialLevel	0 ... 100 [%], step 1	Level of the material in the channel