*TITLE

Purpose: Define job title.

Card 1	1	2	3	4	5	6	7	8
Variable	TITLE							
Type	C							
Default	LS-DYNA USER INPUT							

VARIABLE	DESCRIPTION
TITLE	Heading to appear on output and in output files.