HX-400 Hydraulic Press - Maintenance Manual

Section 2: Safety. Before any service, lock out and tag out the main disconnect.
Release stored hydraulic pressure by opening bleed valve BV-3 until gauge G1 reads 0 bar.
WARNING: Stored pressure can cause serious injury. Wear eye protection.

Section 5: Troubleshooting

Fault code E-217: Low hydraulic pressure.
1. Check reservoir oil level; refill with ISO VG 46 oil to the MAX mark.
2. Inspect suction filter F2 for clogging; replace if differential pressure exceeds 1.5 bar.
3. Verify relief valve RV-1 is set to 210 bar.
Torque for pump mounting bolts: refer to the OEM appendix (not included).

Section 7: Preventive maintenance schedule

Daily: check oil level and inspect hoses for leaks.
Every 500 hours: replace suction filter F2.
Every 2000 hours: replace hydraulic oil and clean the reservoir.