

The image displays the MATLAB software interface. The top menu bar includes options like HOME, PLOTS, APPS, FIGURE, FORMAT, and TOOLS. The central workspace is divided into three main sections: the Command Window on the left, the Editor on the right, and the Workspace on the bottom left. The Command Window shows the execution of a script named 'SlotC\_Exp8c.m'. The script calculates the beam direction error for various steering angles. The Editor displays the script code, which includes comments and calculations for desired, actual, and error values. The Workspace section shows the variables 'actual', 'desired', and 'error' with their respective values and sizes. The plot area on the right shows a line graph titled 'Beam Direction Error for Different Steering Angles'. The x-axis is labeled 'Desired Steering Angle (Degrees)' and ranges from -60 to 60. The y-axis is labeled 'Beam Direction Error (Degrees)' and ranges from 1 to 2. The plot shows a blue line with circular markers at the data points, which are connected by straight line segments. The error is 2.0 for angles from -60 to -30, drops to 1.0 at -30, remains at 1.0 until 30, and then rises back to 2.0 at 60.

| Desired Steering Angle (Degrees) | Beam Direction Error (Degrees) |
|----------------------------------|--------------------------------|
| -60                              | 2.0                            |
| -30                              | 1.0                            |
| 0                                | 1.0                            |
| 30                               | 1.0                            |
| 60                               | 2.0                            |

Breaking news  
Karoline Leavitt t...  
Search  
ENG  
IN  
10:39  
13-08-2026



The figure displays a MATLAB environment with a bar chart titled "Array Gain for Different Steering Angles". The x-axis represents the "Steering Angle (Degrees)" with values [-60, -30, 0, 30, 60]. The y-axis represents the "Array Gain (dB)" with values [0, 5, 10, 15]. The bar chart shows gains of approximately 9, 12, 15, 12, and 9 dB for the respective angles. The MATLAB code in the Command Window is as follows:

```
1 clc;
2 clear;
3 close all;
4 angle = [-60 -30 0 30 60];
5 gain = [9 12 15 12 9];
6 figure
7 bar(angle, gain)
8 grid on
9 % Steering Angles (degrees)
10 % Array Gain (dB)
11 xlabel('Steering Angle (Degrees)')
12 ylabel('Array Gain (dB)')
13 title('Array Gain for Different Steering Angles')
```

| Steering Angle (Degrees) | Array Gain (dB) |
|--------------------------|-----------------|
| -60                      | 9               |
| -30                      | 12              |
| 0                        | 15              |
| 30                       | 12              |
| 60                       | 9               |