Ricoh GR Customizer

USER GUIDE / 01 Frequently Asked Questions

Which cameras and computers are supported?

Currently tested models: **Ricoh GR IV** and **Ricoh GR IV HDF**, using official firmware 1.11. Mac: Intel with macOS 10.13 or later; Apple silicon with macOS 11 or later. The original project also supports 64-bit Windows 10 / 11; this community download is for Mac.

Where do I get the firmware?

Firmware is not included. Select your camera model and click **Download** to get it from Ricoh, or drag a downloaded **fwdc248b.bin** file into the app. If an official update fails, the bridge-firmware option may help; follow its instructions.

How do I install the changes on my camera?

Click **Write to card**. Turn the camera off, insert the card, then hold **MENU** while turning it on. Run the firmware update. Image Control and aspect-ratio changes are combined in the same firmware file.

When do I need the factory menu?

Only custom power-off images require the factory menu to enable Script. Features installed through a firmware update do not need it.

Which preset files can I import?

.xmp Look profiles and **.cube** LUTs based on **sRGB / Rec.709**.

Which camera settings best match my imported preset?

Set Saturation, Hue, High/Low Key Adjustment, Contrast, Highlight Contrast, and Shadow Contrast to **0**. Use **sRGB**. Turn Highlight Correction and Shadow Correction **off**.

How do I restore the original firmware?

On Image Control, open the **...** menu and choose **Write factory firmware**. Hold MENU while turning on the camera to update. If you used soft focus, B&W looks, or added preset slots, switch the camera back to its original available settings before restoring.

Why does macOS block the first launch?

The app is not signed with an Apple Developer ID. Go to **System Settings > Privacy & Security** and choose **Open Anyway**. Allow access to removable volumes when first writing to a card.

Are there any risks?

Modified firmware may leave the camera unable to start. The documented workflow accepts official 1.11 firmware as input and checks each generated file, but these checks do not guarantee safe operation. Decide whether to proceed at your own risk.

Firmware & Script

USER GUIDE / 02 Two different ways to customize your camera

	Firmware	Script
Used for	Image Control, aspect ratios, soft focus, date imprint, B&W looks, and added preset slots.	Power-off images: up to 9 images, with one selected on each power-on.
Written to the card	One firmware file: fwdc248b.bin.	Image files and a startup script.
First-time setup	No factory-menu setup required.	Once per camera: choose Open factory menu, write the entry files, then hold MENU while turning on the camera. Set Script to Enable.
How it takes effect	Turn the camera off, insert the card, then hold MENU while turning it on. Run the firmware update.	Leave the card in the camera. The script runs at startup.
After removing the card	Changes remain installed in the camera firmware.	A single image is written into the camera. A rotating set requires the card to remain inserted.
Memory card	Any capacity; FAT32 or exFAT.	Up to 32 GB; FAT32; MBR partition table.
Restore the original	... menu > Write factory firmware.	Select the factory image on the Power-Off Image page.

One card: one active startup workflow at a time

When firmware is written to a card, conflicting power-off scripts are moved to **GRMOD/parked-[timestamp]**, rather than deleted. After updating, reconnect the card to your computer and click **Restore power-off images** to put them back.

Both factory-menu entry and firmware updating use **MENU + power-on**. Writing factory-menu entry files moves the firmware aside. Writing firmware or power-off images moves the entry files aside.

Format cards in the camera before use. Back up their contents first: formatting erases all files.

More Color Recipes - Visit LUTs Maker
https://luts-maker.uk