


ST-LINK/V2 (20-pin) pinout labels

Print at 100% / Actual size. Check the 50 mm bar, then cut along the dashed lines.



ST-LINK/V2 20-pin JTAG/SWD

1 VAPP	3 TRST	5 TDI	7 SWDIO	9 SWCLK	11 NC	13 SWO	15 NRST	17 NC	19 3V3 out
2 VAPP	4 GND	6 GND	8 GND	10 GND	12 GND	14 GND	16 GND	18 GND	20 GND

Pin 1 = red stripe. SWD: 1 VAPP to target 3.3V (required), 7, 9, GND. Never connect 19.

Main label - stick next to the 20-pin header, pin 1 (triangle) on the red-stripe side.

ST-LINK/V2 → Nano-Tek (SWD)

1 VAPP	→ J4-4 +3V3
4 GND	→ J4-5 GND
7 SWDIO	→ J4-6 SWDIO
9 SWCLK	→ J4-7 SWCLK
15 NRST	→ J2-1 NRST (opt.)

FlashFloppy on chip: BOOT0 high (J2 9-10) for SWD

Wiring card - keep with the ST-LINK or on the jumper-wire bundle.

ST-LINK/V2 20-pin JTAG/SWD

1 VAPP	3 TRST	5 TDI	7 SWDIO	9 SWCLK	11 NC	13 SWO	15 NRST	17 NC	19 3V3 out
2 VAPP	4 GND	6 GND	8 GND	10 GND	12 GND	14 GND	16 GND	18 GND	20 GND

Pin 1 = red stripe. SWD: 1 VAPP to target 3.3V (required), 7, 9, GND. Never connect 19.

Compact copy (7 mm cells)

Finding pin 1 on the box header with a meter (probe unplugged):

- The even row is the one where 9 pins (4, 6 ... 20) are all GND; its one non-GND end pin is pin 2.
- Pin 1 is next to pin 2 in the other row (pins 1 and 2 are both VAPP and read shorted).

VAPP only senses the target voltage; the ST-LINK/V2 does not power the target.

Pin 19 is the probe's own 3.3 V output - leave it unconnected.

Source: ST UM1075, Table 4 (JTAG/SWD cable connections).