Sky Weather

How to use your desk

This desk shows the weather for the town you choose, plus the clock, the night sky, rocket launches, and the space station. There is no app and no account. Keep it plugged in, and give it your home Wi-Fi.

First time

1. Plug in the power cable. The screen comes on.

2. Tap WIFI along the bottom. Tap SCAN and pick your network, or type the name. Type the password on the keyboard. ABC switches to capital letters. !# switches to numbers and symbols. Tap SAVE.

If it joins, you return to the home screen. If it says no join, check the name and the password and tap SAVE again. If your home has two network names and one ends in 5G, use the other name.

3. Tap PLACE. Type your town and tap SEARCH. Tap the matching place. The clock and the weather follow that town. Give it a minute. The numbers fill in as they arrive.

The buttons along the bottom

PLACE changes the town.

RADAR opens the pictures from above.

RAIN opens the next 12 hours.

SKY opens the clock, launches, the night sky, and the space station.

WIFI opens the network.

SET opens the look, the lamp, the temperature, and updates.

Home screen

The line at the top is about warnings. On a clear, quiet day it says ALL CLEAR. If the sky is cloudy or wet and nothing is posted, it says NO WARNINGS. If a warning is posted, that line names it and when it ends. Tap the line to read the list. Warnings are for places in the United States.

The large word is the sky right now. The clock in the corner shows the hour and the minute for your town.

Tap the temperature card for the next 7 days. It shows the reading now, and today's high and low.

The moon card shows the phase and how much of the moon is lit.

The tide card shows the next high and the next low if you are near a coast in the United States. Inland, it says no coast tide. That is normal. If a coast is nearby and the times have not come in yet, it says tide waiting.

The rain card shows the chance of rain over the next 6 hours, with a short row of bars. Tap it for the next 24 hours.

The sun card draws the path from sunrise to sunset, with the times underneath. After sunset the sun on that path hides until morning. The numbers at the top of the card are how strong the sun is, and the UV.

The bar under the sky word is the air pressure. It can say rising or steady. Tap that bar for wind and air pressure.

Radar

SAT is a picture of the ground from above. CLOUDS is that same picture with the bright clouds laid on it. STORM is that picture with the colored storm picture laid on it. Town names appear on the picture, along with rivers and lakes when they are nearby.

Rain

The RAIN button along the bottom is the next 12 hours, drawn as bars. The rain card on the home screen is a shorter look. A tap on that card opens the next 24 hours.

Sky

Four tiles.

CLOCK is a quiet clock: the time, sunrise, sunset, the sky, the temperature, and the wind. It does not show seconds.

LAUNCH is upcoming rocket launches: the rocket, the place, and the time.

NIGHT is the night sky. Planets that are up come first, then the moon, then stars and clusters. Tap PAGE 2 when it is shown, to see the rest. PAGE 1 brings you back.

ISS is the space station. You see the world, day and night, the path, and when you can look for it. A pink dot is your town. If it is passing where you can see it, the screen says LOOK and a direction.

Back and home

BACK returns to the page you came from. HOME returns to the main screen.

Set

LOOK is DARK or LIGHT.

LAMP is DIM, MID, or BRIGHT. Bright is full. Dim and mid are softer.

F shows Fahrenheit. C shows Celsius. The choice stays until you change it.

WIFI on this page opens the network page. ABOUT is for updates.

FACTORY RESET clears this desk only: the town, the network, and the choices on this screen. The desk restarts. It does not change anything else in your house.

On the Wi-Fi page, RESET WIFI forgets the network name and password. FACTORY on that page does the same full clear as FACTORY RESET.

Updates

Tap SET, then ABOUT. The page shows the version that is on your desk.

Tap CHECK FOR UPDATES and leave the desk on Wi-Fi. If nothing newer is waiting, it says newest firmware already installed.

If a newer one is ready, it shows that version and asks you to tap INSTALL. Leave the desk plugged in. Do not unplug it while it says it is downloading. It restarts on its own when it is done.

A few things that are normal

Pictures in the shop use a sample town. Your screen shows the town you picked.

The first time you open the space station, the world picture is already there. The path and the list of passes fill in once the desk is on Wi-Fi.

If the Wi-Fi drops, the desk keeps showing the last numbers it has. Join the network again when you can.