	SNES		
IOMHZdk	10MHz-clk	W 18	
reset	reset		
<u>a</u>	a		
Ь	b		
X	X		
у	y	huttons[7.0]	buttons 8
up	up		
down	down		
left	left		
right	right .		
start	stort		
select	select		T. Friends
left-bumper	left_bumper		
right-bumper	right-bumper		1