

Proposed Pull Requests — grblHAL Simulator

Fork [stevenrwood/Simulator](#) → upstream [grblHAL/Simulator](#) · base branch `master` (`171a661` “Updated submodules”) · 5 proposal branches + 2 submodule forks · **none submitted upstream yet** (staging document)

Shared base. All five branches start from the same 6-commit *sim-core* base ([below](#)): simulated limit/probe switches, fast homing, and the CI release workflow. `pr/sim-view` (= the fork’s integration branch, `9f7fdab`) is a **superset** that contains every other branch plus the 3D view; the focused branches are its constituent, separately-reviewable parts. Line counts below **exclude vendored code** (the `littlefs` library and the `src/grbl` / `src/sdcard` submodules — the latter are tracked as the two submodule-fork PRs at the end).

B	Sim-core base — simulated switches, fast homing, CI release	(in all branches)	+192/-9 · 4 files
1	YModem binary stream over the socket	<code>pr/ymodem-socket</code>	+254/-55 · 11 files
2	Probe modelling (any-axis, stock/toolsetter/spoilboard, \$6)	<code>pr/sim-probe</code>	+255/-9 · 4 files
3	littlefs filesystem + <code>-format</code>	<code>pr/littlefs</code>	+489/-17 · 12 files (+ littlefs lib)
4	Settings persistence fix + <code>\$REBOOT</code>	<code>pr/persistence-reboot</code>	+535/-26 · 13 files
5	3D machine view + material-removal carve (superset)	<code>pr/sim-view</code>	+2597/-74 · 26 files
S1	core: mount littlefs at <code>/littlefs</code> + named-subsearch	<code>core: simulator-littlefs-named-sub</code>	submodule
S2	Plugin_SD_card: YModem init-before-publish fix	<code>Plugin_SD_card: simulator-ymodem-init-fix</code>	submodule

BASE**Sim-core: simulated switches, fast homing, CI release**

Scope	The first 6 commits (171a661..741ab27) shared by all proposal branches below.
Files	src/driver.c, src/driver.h, src/simulator.c, .github/workflows/release-sim.yml

The stock simulator does not model limit or probe switches, so homing (\$H) alarms out and probing cannot be exercised at all. This base makes the simulated machine behave enough like real hardware to run those workflows:

- **Simulated limit & probe switches** derived from the tracked machine position, so \$H and probe moves see real switch transitions.
- **Fast \$H** — the carriage parks near the home switch instead of seeking the full travel in real time, and [MSG:Homing] is emitted at the start.
- **Honor \$5** (limit invert) in the simulated limit switches.
- **Suppress the hard-limit IRQ during homing** — otherwise a machine with \$21=1 (hard limits enabled) trips Alarm 8 the instant homing seeks the switch.
- **CI release workflow** (release-sim.yml): builds the patched Windows grblHAL_sim.exe and publishes it as the rolling sim-latest release asset — the build ioSender's "download simulator" path consumes.

PR 1 Fix YModem (binary stream) over the socket so file upload works

Branch `pr/y modem-socket`

Depends on Sim-core base.

Compare <https://github.com/grblHAL/Simulator/compare/master...stevenrwood:Simulator:pr/y modem-socket>

File upload into the simulator (ioSender's *Install ATC macros*, which sends the macro files over YModem) did not work across the simulator's TCP socket.

- **YModem over the socket:** handle the YModem binary stream correctly on the socket transport (the byte path differs from the serial console).
- **Flush per TX burst, not per byte:** the simulator flushed socket output one byte at a time, which stalled the binary transfer; flushing per write-burst lets blocks move.

Pairs with the [Plugin_SD_card submodule fork](#) (the init-before-publish race that made block 0 NAK out of sequence).

Touches the serial/MCU/platform plumbing: `serial.c`, `simulator.c`, `mcu.c`, `platform_windows.c/platform_linux.c`, `main.c`.

PR 2 Probe modelling: any-axis, real surfaces, \$6 invert

Branch	pr/sim-probe
Depends on	Sim-core base.
Compare	https://github.com/grblHAL/Simulator/compare/master...stevenwood:Simulator:pr/sim-probe

Extends the simulated probe so ATC tool-length and 3D probing workflows can be rehearsed in the simulator:

- **Trip on any axis** (not just Z), enabling 3D corner / edge probing.
- **Model real surfaces** — stock, toolsetter and spoilboard — so probe moves contact something meaningful at the expected heights.
- **Honor \$6** (probe invert): an inverted-probe configuration is otherwise read as permanently triggered.

Files: `src/driver.c`, `src/driver.h`, `src/simulator.c`.

PR 3 Add littlefs filesystem support + `-format`

Branch	pr/littlefs
Depends on	Sim-core base; the core and Plugin_SD_card submodule forks.
Compare	https://github.com/grblHAL/Simulator/compare/master...stevenwood:Simulator:pr/littlefs

Gives the simulator a persistent filesystem so ATC macro upload and `0<name> CALL` macro resolution behave like real hardware:

- **littlefs** backed by a host file, wired in via the SD card plugin.
- **Per-block persistence** in the littlefs HAL (rather than rewriting the whole image on every write).
- **Optional case-insensitive name matching** (`LFS_CASE_INSENSITIVE`) so upper-cased O-word labels resolve to lower-case macro files, matching FatFs semantics.
- **Mount at `/littlefs`** and resolve named-sub macros there (the matching core search-path change is the [core submodule fork](#)).
- **`-format`** command-line switch to wipe and reformat littlefs on boot.

The line count excludes the vendored `littlefs` library bundled into the build. Files: `src/littlefs_hal.c/.h`, `src/driver.c`, `src/main.c`, `CMakeLists.txt/.tpl`, `.gitmodules` (submodule pointers).

PR 4 Settings persistence fix + \$REBOOT

Branch `pr/persistence-reboot`
Depends on `Sim-core base + the littlefs work (PR 3)`.
Compare <https://github.com/grblHAL/Simulator/compare/master...stevenwood:Simulator:pr/persistence-reboot>

Two lifecycle fixes so the simulator survives restarts and self-reboots like real firmware:

- **Settings persistence:** correct the EEPROM checksum so \$ settings survive a restart, and gate the ATC `error_on_no_macro` behaviour.
- **\$REBOOT (`hal.reboot`):** implemented by relaunching the simulator process in an ordered way, so firmware that reboots itself (e.g. after a settings change) comes back up instead of just exiting.

Files: `src/grbl_eeprom_extensions.c`, `src/driver.c`, `src/main.c`, `src/simulator.c`.

PR 5 3D machine view + material-removal carve (superset = integration)

Branch	pr/sim-view (= integration, 9f7fdab)
Contains	The sim-core base + PRs 1–4 + the 3D view. This is the branch <code>sim-latest</code> is built from.
Compare	https://github.com/grblHAL/Simulator/compare/master...stevenwood:Simulator:pr/sim-view

The flagship branch: adds an optional OpenGL **3D machine view** to the simulator and a stack of features on top of it. (Most of the bulk is `sim_view.c`.)

- **3D view (-view):** a window showing the machine, work envelope and tool; the simulator **runs standalone by default** (3D window on, default port 23, auto-load of the setup/EEPROM), and closing the window shuts the simulator down.
- **Material-removal carve:** a stock heightmap is lowered as the cutter passes (rendered via a GPU display list), shaded by depth and by cutter type (flat / ball / V); with *Reset Stock*, *Flip Stock* (turn over to a fresh top) and a configurable carve resolution. Stock size is taken from a (`STOCK X= Y= Z=`) g-code comment.
- **UI:** a real menu bar (*Settings / Format LittleFS / Show Log*), an editable Settings dialog (machine description → window title, carve resolution), a dedicated Show-Log window, a carve-status overlay, a build date/time stamp in the title, window-position persistence, and an application icon.
- **ATC / tool table:** `hal.probe.select` (fixes error:39 on G65 P5), end-of-line (`T00L ...`) comment parsing, and a tool-table format spec (`T00L_TABLE_FORMAT.md`) for the CAM post / add-in.
- **-setup <file> fixtures:** define the spoilboard / stock / toolsetter explicitly and write G28 / G30 / G59.3 at boot (decouples the spoilboard from `Z_max_travel`, fixing Alarm 5 on tall-Z machines).

Key files: `src/sim_view.c/.h`, `src/sim_setup.h`, `src/driver.c`, `src/main.c`, `src/sim.rc/sim.ico`, `T00L_TABLE_FORMAT.md`, `CMakeLists.txt`. Builds with CMake + MinGW (`LITTLEFS_ENABLE=2`).

SUBMODULE **core: mount littlefs at /littlefs + named-sub search path**

Repo	grblHAL/core (fork stevenrwood/core)
Branch	simulator-littlefs-named-sub @ fe16cb9 — submodule at src/grbl
Compare	https://github.com/grblHAL/core/compare/master...stevenrwood:core:simulator-littlefs-named-sub

The named-sub (0<name> CALL) resolver searched only the root filesystem. In the simulator's combined config littlefs mounts at /littlefs (root being the SD card), so macros stored on littlefs were never found — the open failure surfaced misleadingly as `error:81`. This fork makes the resolver search /littlefs, so uploaded ATC macros resolve. Consumed by [PR 3](#) and [PR 5](#) via the src/grbl submodule pointer.

SUBMODULE Plugin_SD_card: YModem init-before-publish race fix

Repo	grblHAL/Plugin_SD_card (fork stevenrwood/Plugin_SD_card)
Branch	simulator-y modem-init-fix @ e33441a — submodule at src/sdcard
Compare	https://github.com/grblHAL/Plugin_SD_card/compare/master...stevenrwood:Plugin_SD_card:simulator-y modem-init-fix

trap_initial_soh published `grbl.on_execute_realtime = protocol_loop` *before* initialising `y modem.next_timeout / process`. In the simulator (whose grbl loop runs on a separate thread) that ordering let a spurious timeout NAK fire before block 0, so ioSender retransmitted block 0 out of sequence — the transfer stalled or flooded into an `OutOfMemoryException`. Fixed by initialising the YModem state **before** publishing the realtime hook. This is what makes ATC macro upload work at all; it pairs with [PR 1](#) on the simulator side. Consumed via the `src/sdcard` submodule pointer.

Generated 2026-06-20. Branch tips: `pr/y modem-socket` 0f15ed5 · `pr/sim-probe` 4df72ca · `pr/littlefs` 73b3e74 · `pr/persistence-reboot` cadca97 · `pr/sim-view` 9f7fdab (= integration). Upstream base `grblHAL/Simulator` master 171a661.