
Kestrel user guide

Kestrel takes a single video input (usually a locked-off wide of a stage), lets you draw as many **regions of interest** on it as you like, and sends each region back out of a Blackmagic DeckLink, cropped and scaled to the output raster.

One wide shot in, several tighter shots out. A kestrel hovers over a wide field and picks out one thing at a time, and so does this.



The operator window on its own synthetic bars: one region drawn on the wide, four outputs black because there's no DeckLink in this machine, and the control server listening. Captured from the build on this Mac by window, the first time the layout has been looked at rather than served.

> **Before you rely on this:** the GPU path is verified by **pixel readback** (14 tests, including a raster whose rows need padding), the control API end to end, and the Companion module against an actual running Kestrel, with 49.99 fps sustained at 1080p50 with the GUI open.
>
> **No DeckLink has ever been connected to this code.** Every line of SDI (capture, playback, pre-roll, format detection, profile handling) is written against the SDK headers and is unproven here. **Windows and Linux have never been run.**
>
> This codebase was created with AI assistance, directed and reviewed by a human author.

The rule everything else follows

Every output produces a frame, every frame, always.

That's every output, routed or not. An SDI output that *stops* is an output the switcher downstream has to re-lock, and re-locking costs frames on air. So:

- An output with **nothing routed** to it carries its **idle fill**: legal black by default, or bars, or the whole input as a confidence feed.
- The **global outputs kill** blacks every output at once and **leaves every crosspoint intact**. The signals keep running, and nothing downstream notices anything but the picture.
- **Losing the input blacks the routed outputs rather than freezing them.** A frozen last-good frame looks live to anyone watching, which is worse than black.
- An output with **no card assigned** is still planned and still rendered. It just has nowhere to go.

Anything you might otherwise read as odd behaviour (a kill that doesn't clear routing, black rather than a freeze) is that rule at work.

Running it

```
kestrel-gui
```

With no DeckLink in the machine it runs on generated colour bars with a sweeping marker, and everything except the SDI works: regions, routing, the matrix, the Companion module, the previews. That's on purpose, so you can build the show's layout on a laptop and then take it to the rack.

Headless, for a rack:

```
kestrel run --http 0.0.0.0:9720
```

And to see what the machine has:

```
kestrel devices
```

The screen

- **A large preview** of the input, with the regions drawn on it and draggable.
- **A row of output previews** along the bottom, each showing just what's on that wire, with a **scale percentage** saying how far the source is being blown up. That percentage is the

number to watch, because it's what tells you a region has been pushed further than the source can stand.

- **A crosspoint matrix** (regions down the side, outputs across the top) on its own tab.

SDI support is opt-in at build time

The DeckLink SDK is a free but licence-gated download and isn't mine to redistribute, so nothing from it is vendored. Point the build at your copy:

```
DECKLINK_SDK_DIR="/path/to/Blackmagic DeckLink SDK 12.9" cargo build --release
```

SDK **11.0 or newer**. Without one the build succeeds and reports `DeckLink: not compiled in`, which the app is careful to keep apart from `no devices found`, because the two have completely different fixes.

Profiles, which is the thing that wastes an afternoon

A multi-sub-device card presents all its sub-devices whatever profile it's in, and the ones the profile has switched off support no display modes at all.

A DeckLink Duo 2 in its two-sub-device profile shows four sub-devices, two of which are dead, and trying to open one of those **looks just like a broken card**.

Kestrel wants one input and several outputs at once, which on a Duo 2 means the **four-sub-device half-duplex profile**. `kestrel devices` says which sub-devices are inactive and why, and the UI greys them out with the reason rather than showing an empty menu.

Control API

HTTP for commands and a WebSocket for pushed state.

`GET /api/state`	the whole state
`WS /ws`	the same, pushed when it changes
`POST /api/route`	`{"output":1,"roi":2}`, or `"roi":null` to clear
`POST /api/output/enable`	`{"enabled":false}` or `{"toggle":true}`
`POST /api/roi`	create; `POST` / `DELETE /api/roi/{id}` to edit or remove
`POST /api/output/{id}`	label, idle fill, fit mode

> **A refused command comes back as HTTP 200 with `ok:false` and a populated `error`. Check the body, not the status code.**

> **There's no authentication.** Anyone who can reach the port can re-route every output and kill the lot. Keep it on a management interface.

The Stream Deck end is companion-module-kestrel.

How a frame gets across

Four GPU stages, all fragment shaders:

1. **decode:** UYVY to full-raster RGB, BT.709 limited range, chroma **interpolated** rather than nearest-sampled. Once per *captured* frame.
2. **crop:** a rectangle of that, scaled to the output raster, Catmull-Rom bicubic or bilinear. Once per output per *output* frame.
3. **fill:** black or bars, for an output carrying nothing.
4. **pack:** RGB back to UYVY, into a half-width target whose rows are byte for byte the layout DeckLink wants.

Stage 4 is why **the CPU never touches a pixel**: it only copies rows out of a mapped buffer. Everything in between is linear, never sRGB. These pixels arrived over SDI already encoded, and a gamma re-encode on the way through would shift every colour on the output.

If something is wrong

Symptom	Cause
`DeckLink: not compiled in`	The build had no SDK. Different problem from no devices found.
A sub-device will not open, card looks broken	Wrong profile. On a Duo 2, use four-sub-device half-duplex. `kestrel devices` says which are inactive.
An output went black rather than freezing	The input was lost. That is deliberate — a frozen frame looks live.
Killing outputs did not clear my routing	Also deliberate. The crosspoints stay; only the picture goes.
A command returned 200 and did nothing	Read `ok` and `error` in the body.
The output is soft	Check the scale percentage under that output preview.