SimpleCue user guide


SimpleCue is an audio cue player for theatre, live events and installations. You build a list of cues and press **GO**.

> **Before a show:** the playback engine is verified sample by sample and the control layer is driven end to end over real sockets, 404 checks in all. But SimpleCue **has never been run on a live show**. No MIDI, lighting or streaming hardware has ever been connected to it, and only the macOS/CoreAudio build has been used with real audio hardware. Rehearse with it before you trust it with a performance.

The basics

A **cue** is an audio file with an in point, an out point, a gain and a pre-wait. The cue list runs top to bottom, and **GO** fires whatever's on standby.

Everything else is about how cues start, stop and hand over to each other.



*Cue 3 is vamping: there's the yellow **VAMP 1** badge on the row, its **Devamp** sub-cue showing underneath, and **Release vamp** lit in the transport. Note the cue numbers too: `3.5` and `7.5` sit*

between whole numbers, the way they do in a prompt book.

Cue numbers

Cue numbers are **free text**, so they don't have to be whole numbers: `12`, `12.5`, `PRE`, `INTERVAL`. Insert a cue between 12 and 13 and call it 12.5, the way any prompt book ends up once rehearsals have had their way with it.

Fades

Each cue has a **fade in** and a **fade out** time, and a **shape**, with five curves to choose from. A linear fade sounds like it dips in the middle, and the other shapes are there because different material wants different curves.

Show-wide defaults for fade times and shape mean you only set your house style once.

Links: how one cue leads to the next

This is the bit that turns a list into a show.

- **Fire the next cue immediately:** the moment this one starts.
- **Fire at the end:** an auto-follow.
- **Crossfade into it:** this cue fades out while the next fades in, over a set duration.

A link with **no target** means *the next cue in the list*, so inserting a cue between two linked cues does what you'd expect rather than breaking the chain.

> **Delay is ignored on a crossfade.** The crossfade's own duration sets the timing.

Loops

Repeat a section a set number of times, or **forever**, which is what a loop count of zero means. Handy for pre-show music and ambient beds.

Vamps — the one worth understanding

A **vamp** goes round a section of a cue until the operator calls for it to carry on.

It's the feature for live theatre not running to time, which is to say live theatre. Underscore a scene change, or hold music under an entrance, and it goes round and round until you press GO. Then it leaves the loop and carries on, rather than cutting.

Set the vamp region (start and end) and enable it. That's the **Vamp from** and **Vamp to** fields under the waveform, drawn on it as the shaded region between the `V<` and `>V` markers. While the cue is vamping, its **Devamp** step appears, and GO releases it.

Cue lifecycles and GO

A cue expands into the steps it actually needs:


- **Play:** always
- **Devamp:** only if the cue has a vamp
- **Fade / Stop:** always

GO walks these one at a time. That's why a vamping cue takes an extra GO to release: the first GO devamps, the next moves on.

By default, firing a cue also plays it, and standby skips straight past the Play step, so you're never offered the same audio twice.

Output routing

Each cue has a routing matrix mapping **source file channels to device output channels**, with a gain at each point. A stereo file can go to outputs 3 and 4, a mono effect to a single speaker, and one channel can feed several outputs.



Audio is resampled to the device rate **at load time**, which is what makes the loop and vamp maths exact integer sample arithmetic. The catch: **changing the device sample rate reloads every cue in the show.** Do it before a show, not during one.

Cues without explicit routing get a sensible default from the file's channel count and your device's outputs.

Remote control

SimpleCue can be driven by other kit, and can drive it too:

- **OSC:** in and out, with Bitfocus Companion support
- **MIDI:** notes, CCs and program changes
- **MIDI Show Control (MSC)** and **MIDI Machine Control (MMC)**
- **Art-Net and sACN:** trigger cues from a lighting desk

The full details are in `control.md`.

Two things to know as an operator:

Lighting-desk triggers are edge-detected. A cue fires when the level *crosses* the threshold, rather than on every frame the desk sends. Without that, a desk holding a channel at full would keep re-firing the cue.

DMX addresses cues by their position in the list, not by cue number. DMX can only count, so it has no way to send `12.5`. Every other protocol uses the cue number. **So inserting or deleting a cue shifts what your DMX triggers point at.** Re-check your triggers after editing the list.

Show files

A show saves as a single `.cueshow` file: plain, readable JSON.

- **Audio paths are stored relative to the show file**, so a show folder can be copied to another machine and still work.
- **Saving is atomic.** The show is written to a temporary file and moved into place, so a crash or a pulled USB stick mid-save can't destroy the show already on disk. At a venue that file is often the only copy.
- Shows saved by an older version open fine. A show saved by a *newer* version is **refused** rather than partially loaded. I'd rather give you an error than a show that behaves a bit differently from the one you built without telling you.

Older `cue-player` show files still open.

Practical notes

Changing the audio device's sample rate reloads every cue. Audio is resampled once, at load, which is what makes all the loop and vamp timing exact. Expect a pause, and do it before the show rather than during it.

Set your audio device first, then build the show.

Platforms

macOS (universal), Windows (x64 and arm64), Linux (x64 and arm64). Only the macOS/CoreAudio build has been run with real audio hardware.