OPENMANET FIELD EXTENSION · FIELD CARD

Node web page: **http://<node>:8787** (default node 10.41.0.1) · OpenMANET page: **:8080** · ATAK plugin: ManetNode FE (PTT · STATUS · LORA · SET)

STATUS LIGHT

Purple	Mesh + internet
Green	Mesh only (other nodes heard)
Cyan	Internet only: no mesh neighbours and no LoRa radio
Blue slow blink	LoRa only: no mesh neighbours; the LoRa radio carries the team
Amber	No mesh, no internet, no LoRa
White	Maintenance: being updated or worked on. Don't unplug
Red solid	Starting up, or a fault
Red quick blink	Shutting down cleanly
Red pulse	Battery below 20 % (on battery)
Red fast blink	Battery critical: charge now
Blue 2 s flash	GPS has a fix (every ~10 s, over the colour above)
Green blinks	Charging: every 10 s, 1 blink per 20 % (1 = 0–20 %, 5 = 80–100 %)

> Turn the light off or dim it: web page Status LED, or plugin SET tab.

JOIN A PHONE

1. Join the node's Wi-Fi (name on the web page, EUD Wi-Fi tile).
2. Open ATAK. The ManetNode FE plugin finds the node by itself; the corner dot shows its light colour.
3. No plugin? Open **http://10.41.0.1:8787** in the browser, or use the ManetNode app.
4. Phone Internet: **AUTO** uses the node's internet when it has some, else the phone's cellular; **CELL** always uses cellular. Phones switch at their next Wi-Fi reconnect.

CHARGING & POWER

- Charge from the case port with a **5 V / 3 A** supply and a short cable. The battery tile shows % and time left (set the pack size: web page Maintenance).
- % shown while charging moves slowly on purpose; the voltage is the honest number (3.4–3.5 V ≈ 15–35 %).
- Auto power-on ON: the node starts by itself when the charger is plugged in after a full drain.
- Off: hold the PiSugar button (light blinks red, then off), or Shutdown in the plugin. On: short-press the button.

> Some USB-C chargers give 0 V to the case port until it has two 5.1 kΩ resistors (CC1→GND, CC2→GND). A USB-A-to-C cable always works.

LORA (MESHTASTIC RADIO)

AUTO	Positions and chat go over LoRa when the mesh is down, or while a LoRa-only teammate is heard.
ALWAYS	Also while the mesh is up.
OFF	Radio left alone.
DARK	Team channel only, frequency from the team name. Works with older nodes on a custom layout.
COVERT	Team + public channel; your position never goes on the public channel. Public frequency.
OPEN	Team + public channel; public radios see you. Public frequency.

> OPEN / COVERT move the radio to the public LongFast frequency: nodes on a custom layout stop hearing it. Use DARK in a mixed team.

> "Change every node" ON sends team channel and mode changes to every node over LoRa. OFF changes only this node.

ADD A LORA-ONLY TEAMMATE

1. They need a Meshtastic radio paired to their phone, ATAK, and the Meshtastic ATAK plugin.
2. Plugin LORA tab → Team channel → **QR** (or web page → Share code). It holds the team key: only show it to your team.
3. They scan it in the Meshtastic app (Channels → QR). Same region and speed as the team.
4. Their dot and chat appear for everyone on the mesh; yours reach them over LoRa.

> LoRa is slow (~1 kbit/s): positions about once a minute, chat up to 200 characters, map markers yes; photos, video, files and voice no.

SOMETHING'S WRONG?

- Plugin says "not answering": check you're on the node's Wi-Fi; long-press the node name to set the address.
- Amber light: no other node heard. Move closer or check the other node is on.
- LoRa "not connected": reseat the radio's USB cable; the node retries and power-cycles the port itself.
- Node changes ask for the node password (same as the OpenMANET page).