PortableTAK Quick Reference

Addresses, ports and everyday tasks.

Where to connect

Where the drive is	Phones / WinTAK use	Dashboard
OpenMANET node (on its Wi-Fi)	`10.41.250.10`	`https://10.41.250.10:8444` (QR on the drive)
OpenMANET node (from elsewhere on the mesh)	`10.41.250.10`	`https://10.41.250.10:8444`
Windows computer	The address shown in the Start window	Opens automatically: `http://localhost:8090` (desktop shortcut)
Mac (Apple Silicon)	The address shown in the Start window	Opens automatically: `http://localhost:8090`
Linux computer / Raspberry Pi (64-bit)	The address shown by `sudo bash "Start PortableTAK (Linux).sh"`	`http://localhost:8090` on that computer; `https://<address>:8444` elsewhere
Anywhere, over cellular (after Remote Access is turned on; Tailscale app on)	Tailscale address shown under **Remote Access** (same on every host)	`https://<Tailscale address>:8444`

Ports

Port	Use	Port	Use
8089 TCP (SSL)	TAK clients (CoT)	8554 TCP	Video: RTSP
8443 TCP	TAK web / Marti API	1935 TCP	Video: RTMP
8444 TCP	PortableTAK dashboard (sign-in)	8888 / 8889 TCP	Video: HLS / WebRTC
8446 TCP	Certificate enrollment (QR setup)	8890 UDP/TCP	Video: SRT
1883 TCP	Meshtastic radios (MQTT, when turned on)	8189 UDP	Video: Watch in the browser (WebRTC)

Accounts and passwords

- **Dashboard:** user `administrator` + the administrator password chosen at setup.
- **Client password:** protects the certificate packages; phones use it during QR enrollment.
- **Phone users:** created in **Users**. Passwords: 8+ characters (12+ recommended).

- Too many wrong sign-ins lock sign-in for a few minutes (per device).

Everyday tasks (dashboard)

Task	Where
Add a person / device	**Users** → **Create User**, then a package or QR under **Manage User / Download Setup Package**
iPhone over cellular	**iTAK QR Setup** with "Phone is on: Tailscale", or the **iTAK Remote Package**
iPhone QR, once per drive	**iPhone Trust Profile** (Safari) → install → Settings → General → About → **Certificate Trust Settings** → switch it **on**. Skipping the switch gives "error connecting to the server".
Use the server over cellular / from anywhere	**Remote Access** → **Enable remote access** (Tailscale), then **Finish setup**
Link with another PortableTAK	**Federation** → **Invite a server**, send the code; they use **Join a server**
Link with an official TAK Server	**Federation** → **Connect to a TAK Server**, then send their admin the sheet shown
See everything on a map	**Live Map** (top of the dashboard). Offline: while online, **Offline maps** → name → **Download this area**
Aircraft and ships	**Live Feeds**: set the area, tick the sources, Save. In ATAK: user receives the ADS-B / AIS channel
Give phones a plugin	**ATAK Plugins** → Upload plugin (APK). Phones: ATAK → Plugins → ⋮ → Sync
Send a file to phones	**Data Packages** → Upload (any file or ATAK data package) → **Send** → pick connected phones
Watch a video feed	**Video Feeds** → **Watch** (live feeds only). ATAK: Video → load from server
Link Meshtastic radios	**Meshtastic** → Turn on → Apply now; enter the card's MQTT settings in each radio
Back up / restore	**Backup / Restore** (keep a copy of backups off the drive)
Stop / start the TAK server	**Server** → **Stop Server / Start Server**
Unplug the drive (node)	**Server** → **Safe Remove**, wait for "safe to remove"
Return the drive to brand new	**Erase Drive** (administrator password + type ERASE). Cannot be undone.

Video (drones, TAK ICU, cameras)

1	Dashboard → **Video Feeds** → add a name (lowercase letters, numbers, dashes), e.g. `skydio1`.
2	Controller on the server's Wi-Fi → Menu → Sharing → RTSP → External: name `skydio1`, IP = server address, port **8554** → Start Stream.
3	ATAK/WinTAK → Video → pick the feed (no sign-in needed).
Map	User `skydio1` → **Device TLS Package** → controller: Sharing → TAK/CoT → Add a Connection (port 8089, SSL, values in README.txt).
Hotspot	Drone team on cellular, server elsewhere: Video Feeds → **Drone far from this server** → paste the command into Termux on the ATAK phone; the controller uses the address it prints.
TAK ICU	Add feed type **TAK ICU**. TAK ICU → Broadcast Preferences: Local Area Network, delivery RTSP, RTSP Server Address `<server>:8554/_in/<feed>`.
Camera	Add feed type **Camera / stream URL** with the camera's address, e.g. `rtsp://user:pass@192.168.1.20:554/stream1`.

Remote access (cellular) checklist

1	One free Tailscale account for everything (tailscale.com).
2	Remote Access → Enable remote access → approve link → Finish setup (server needs internet). Once per drive; the same on node, Windows and Mac.
3	Tailscale app on every phone, same account, switched **on**.
4	Set up phones afterwards: ATAK QR Setup or ATAK Package (both add the Tailscale server); iPhone: iTAK QR Setup with "Phone is on: Tailscale", or the iTAK Remote Package.
5	Test with the phone's Wi-Fi off.

Windows, Mac and Linux shortcuts

Start PortableTAK (Windows) / **(Mac)**	On the drive. Starts the server and opens the dashboard.
Stop PortableTAK	Desktop. Stops safely and releases the drive; then unplug. (Dashboard "Stop Server" only pauses the TAK services.)
PortableTAK Dashboard / **PortableTAK Status**	Desktop.
`sudo bash "Start PortableTAK (Linux).sh"`	Linux / Raspberry Pi, in a terminal on the drive: first start (then it starts by itself when the drive is plugged in).
`sudo portabletak stop` / `start` / `status`	Linux / Raspberry Pi: stop safely before unplugging; start or check by hand.

Rules of thumb

- Every device needs its **own callsign**; two devices with the same callsign cannot both connect.
- Make each drive with **PortableTAK Setup**. Never clone a set-up drive: clones share keys and users.
- A node with internet on its Ethernet shares it with its Wi-Fi clients automatically.
- Phones keep cellular for internet when the node has none.