

Z-Wave Products

There are over 4256 interoperable Z-Wave products throughout the world, and over 94 million Z-Wave products have been sold since our beginnings in 2001. All of them work together regardless of brand, because they're all based on the common Z - Wavestandard.Browse our Product Finder to see what Z -Wave can do for you.

Z-Wave Configuration Capabilities

Model: Ring Keypad v2 (Keypad v2)

Z-Wave Certification Number: ZC12-20050056

Parameter Number	Parameter Size	Parameter Name	Description		
1	1	Heartbeat Interval	This parameter is the number minutes between heartbeats. Heartbeats are automatic battery reports on a timer after the last event.		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
70	1	70	No	No	Yes
Value			Description		
1			This parameter is the interval between heartbeats in minutes.		

Parameter Number	Parameter Size	Parameter Name	Description		
10	1	Button Press Display Timeout	Timeout in seconds when any button is pressed, but a sequence is not completed and buttons are no longer being pressed		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
5	0	30	No	No	Yes
Value			Description		
0			This parameter is the Timeout in seconds when any button is pressed.		

Parameter Number	Parameter Size	Parameter Name	Description		
11	1	Status Change Display Timeout	Timeout in seconds when indicator command is received from the hub to change status		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
5	1	30	No	No	Yes
Value			Description		
1			This parameter is the Timeout in seconds when indicator command is received from the hub to change status		

Parameter Number	Parameter Size	Parameter Name	Description		
12	1	Security Mode Brightness	Adjusts the brightness of the security mode buttons		

Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
100	0	100	No	No	Yes
Value			Description		
0			This parameter adjusts the brightness of the security mode buttons		

Parameter Number	Parameter Size	Parameter Name	Description		
13	1	Key Backlight Brightness	Adjusts the brightness of the keypad backlight. Used for Key Backlight LEDs only		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
100	0	100	No	No	Yes
Value			Description		
0			This parameter adjusts the brightness of the keypad backlight. Used for Key Backlight LEDs only		

Parameter Number	Parameter Size	Parameter Name	Description		
14	1	Ambient Light Sensor Level	Light threshold where keypad will stop backlighting if higher than		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
20	0	100	No	No	Yes
Value			Description		
0			This parameter is the light threshold where keypad will stop backlighting if higher than		

Parameter Number	Parameter Size	Parameter Name	Description		
15	1	Proximity On/OFF	Turn On and Off the Proximity Detection.		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
1	0	1	No	No	Yes
Value			Description		
0			This parameter is the Turn On and Off the Proximity Detection.		

Parameter Number	Parameter Size	Parameter Name	Description		
16	1	Ramp Time Config	Ramp time in units of ten milliseconds each to turn the LEDs on/off. Applies to all LEDs on the keypad		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
50	0	255	No	No	Yes

Value		Description
0		This parameter is the ramp time to turn the LEDs on/off in milliseconds.



Parameter Number	Parameter Size	Parameter Name	Description		
17	1	Low Battery Threshold	The percentage level at which the display would turn on the yellow battery indicator (whenever the display is on).		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
30	0	100	No	No	Yes
Value			Description		
0			This parameter is the percentage level at which the display would turn on.		



Parameter Number	Parameter Size	Parameter Name	Description		
18	1	Languages Set	Sets the language on the keypad		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
0	0	31	No	No	Yes
Value			Description		
0			This parameter sets the language on the keypad		



Parameter Number	Parameter Size	Parameter Name	Description		
19	1	Warn Battery Threshold	The percentage level at which the display would turn on the red battery indicator (whenever the display is on).		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
10	0	100	No	No	Yes
Value			Description		
0			This parameter is the percentage level at which the display would turn on the red battery indicator.		



Parameter Number	Parameter Size	Parameter Name	Description		
2	1	Application Retries	Number of application level retries attempted for messages either not ACKed or messages encapsulated via supervision get that did not receive a report.		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
1	0	5	No	No	Yes
Value			Description		
0			This parameter is the number of application level retries attempted for messages		



Parameter Number	Parameter Size	Parameter Name	Description		
20	1	System Security Mode Blink Duration	Configurable ON time for the blink for config #22 which allows us to modify the time for the LED to be active when set to blink on a period per config 22.		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
2	1	60	No	No	Yes
Value			Description		
1			This parameter is the Configurable ON time for the blink.		

Parameter Number	Parameter Size	Parameter Name	Description		
21	2	Supervision Report Timeout	The number of milliseconds waiting for a Supervisory Report response to a Supervisory Get encapsulated command from the sensor before attempting a retry.		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
10000	500	30000	No	No	Yes
Value			Description		
500			This parameter is the number of milliseconds waiting for a Supervisory Report response to a Supervisory Get encapsulated command from the sensor before attempting a retry.		

Parameter Number	Parameter Size	Parameter Name	Description		
22	2	System Security Mode Display	System Security Mode Display: (Always, Sometimes, Never). 601 = Always On 1 - 600 = periodic interval 0 = Always Off, except when there's activit		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
0	0	601	No	No	Yes
Value			Description		
0			This parameter is the System Security Mode Display options.		

Parameter Number	Parameter Size	Parameter Name	Description		
23	4	Languages Supported	Returns bitmask of languages supported. Bits set to 1 indicate that the language is supported		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
37	0	4294967295	Yes	No	Yes

Parameter Number	Parameter Size	Parameter Name	Description		
24	1	Calibrate Speaker	When set to 1, calibrates the speaker		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced

0	0	1	No	No	Yes
Value			Description		
0			This parameter is the Speaker calibration value.		

Parameter Number	Parameter Size	Parameter Name	Description		
3	1	Application Level Retry Base Wait Time Period	The number base seconds used in the calculation for sleeping between retry messages.		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
5	1	60	No	No	Yes
Value			Description		
1			This parameter is the Base seconds used in the calculation for sleeping between retry messages.		

Parameter Number	Parameter Size	Parameter Name	Description		
4	1	Announcement Audio Volume	Announce audio volume adjustment		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
7	0	10	No	No	Yes
Value			Description		
0			This parameter is the Announce audio volume adjustment		

Parameter Number	Parameter Size	Parameter Name	Description		
5	1	Key Tone Volume	Key Tone Volume adjustment		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
6	0	10	No	No	Yes
Value			Description		
0			This parameter is the Key Tone Volume adjustment		

Parameter Number	Parameter Size	Parameter Name	Description		
6	1	Siren Volume	Siren Volume adjustment		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
10	0	10	No	No	Yes
Value			Description		
0			This parameter is the Siren Volume adjustment		

Parameter Number	Parameter Size	Parameter Name	Description		
7	1	Long press emergency duration (seconds)	This parameter allows a user to configure the duration in seconds for the hold time required to capture a long press . This includes Emergency Buttons + Mode Buttons (Police, Fire, Medical, Disarmed, Home, Away)		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
3	2	5	No	No	Yes
Value			Description		
2			This parameter is the special key long press duration - hold time required to capture a long press in seconds.		

Parameter Number	Parameter Size	Parameter Name	Description		
8	1	Long press number pad duration (seconds)	This parameter allows a user to configure the duration in seconds for the hold time required to capture a long press . This includes Number Pad + Check & X (0-9, Check, X)		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
3	2	5	No	No	Yes
Value			Description		
2			This parameter is the hold time required to capture a long press in seconds.		

Parameter Number	Parameter Size	Parameter Name	Description		
9	1	Proximity Display Timeout	Timeout in seconds when proximity is detected and no input is received		
Default Value	Minimum Value	Maximum Value	Read Only	Re-Inclusion	Advanced
5	0	30	No	No	Yes
Value			Description		
0			This parameter is the Timeout in seconds when proximity is detected and no input is received		