

Refrigerator Temperature Control

To adjust the freezer temperature on the refrigerator, press the Freezer button on the control panel. Each press lowers the set temperature by 1 degree Celsius. The recommended freezer temperature is -18C. The refrigerator compartment is typically set between 1C and 7C. Wait 24 hours after adjustment for the temperature to stabilize.

Refrigerator Defrosting

How to defrost the refrigerator when frost has built up: unplug the appliance, remove all food, and leave the doors open. Place towels to catch melt water. Do not use sharp objects to chip ice. Once frost is gone, wipe dry, plug in, and restore food after the temperature returns to normal.

Refrigerator Noise Troubleshooting

Noise from the refrigerator may be caused by the compressor starting, refrigerant flow, or an uneven floor. Ensure the unit is level. Check that bottles are not vibrating against each other. A rattling sound can come from the condenser fan; clean dust from the rear grille. Contact service if grinding persists.

Washing Machine Spin-Dry Issues

When the washing machine will not spin-dry, check that the load is balanced and redistribute clothes evenly. Ensure the drain hose is not clogged and that the lid or door is fully closed. Excessive suds can also prevent spinning; run a rinse cycle with no detergent.

Washing Wool Clothing

The correct way to wash wool clothing is to use the Wool or Delicate cycle with cold water. Use a mild wool detergent. Do not wring or tumble dry on high heat. Lay flat to dry. Turn garments inside out and avoid fabric softener on wool.

Washing Machine Drum Cleaning

Clean the washing machine drum once a month. Run a Tub Clean or sanitize cycle with an empty drum. Wipe the door seal and detergent drawer with a damp cloth. Leave the door ajar after use to prevent mold.

Air Conditioner Filter Cleaning

To clean the air conditioner filter, turn off power, open the front panel, and slide out the filter. Wash with lukewarm water, dry completely in shade, then reinstall. Clean every two weeks during heavy use.

Air Conditioner Water Drip

Water dripping from the air conditioner is often due to a clogged drain hose or dirty filter causing ice melt overflow. Clear the drain line, clean the filter, and ensure the indoor unit is slightly tilted toward the drain. Check outdoor unit drainage as well.

Air Conditioner Energy-Saving Mode

To use the air conditioner energy-saving mode, press the Energy Saver or Eco button on the remote. This mode raises the set temperature slightly and reduces compressor duty cycle. Combine with fan-only when cooling needs are low.

Microwave Auto-Defrost

To use the microwave auto-defrost function, press Auto Defrost, enter the food weight, and press Start. Turn or separate food when the oven beeps mid-cycle. Cover food to prevent splatters. Do not use metal containers.

Oven Baking Temperature

The proper temperature setting when baking in the oven is usually 170C to 180C for cakes and 200C to 220C for bread. Preheat for 10 to 15 minutes. Use the middle rack unless the recipe specifies otherwise. Avoid opening the door frequently.

Dishwasher Detergent Amount

How much detergent to use in the dishwasher: fill the main detergent cup to the line for a normal load, about 20 to 25 ml of powder or one tablet. Use rinse aid in the dispenser. Reduce detergent for soft water.

Dishwasher Cleaning Problems

When dishes are not cleaned properly in the dishwasher, check the spray arms for blockages, scrape large food scraps, load items so water can reach all surfaces, and ensure the filter is clean. Use the correct wash cycle for soil level.

Warranty and Service

The product warranty period is typically one year for parts and labor from the date of purchase. To request service, have your model number and proof of purchase ready and contact the authorized service center. Warranty does not cover misuse, commercial use, or unauthorized repairs.

Power Cord Safety

Precautions when replacing the power cord: unplug the appliance first. Use only the manufacturer-specified cord. Do not splice damaged cords. Ensure the ground wire is connected. If unsure, have a qualified technician replace the cord.