Power Supply Calculator
Calculator: power-supply-calculator | Engine version: 1
Raw engine values: full numeric precision; no display rounding or sampled rows.
Units appear only where supplied by the calculation or bound display metadata.
Embedded Unicode glyphs are readable.
Unsupported characters and controls use explicit Unicode escapes.
Tagged PDF; PDF/UA conformance: UNVERIFIED.
Text follows document order; charts include complete numeric text alternatives.

INPUTS
System load (W) [W]
input["systemLoadWatts"] = 500
Headroom (%) [%]
input["headroomPercent"] = 20

RESULTS
Planning wattage [W]
output["value"] = 600
output["steps"][0] = "Power Supply = 600"

METHODOLOGY
Deterministic calculation using the reviewed Technology & Computing engine.\u000aTechnical calculation revision: technology.power-supply@1\u000a\u000aPlanning wattage from measured/estimated system load plus explicit headroom; not a PSU model recommendation.\u000a
Required W = system load × (1 + headroom %)

DECLARED FORMULAS
power-supply-calculator: Required W = system load × (1 + headroom %)
Planning wattage from measured/estimated system load plus explicit headroom; not a PSU model recommendation.

SOURCES
NIST SP 330 — watt (unit of power)
https://www.nist.gov/pml/special-publication-330/sp-330-appendix-1
NIST defines the watt as a unit of power. The calculator applies only the user-selected headroom to a supplied load; it does not encode a mandatory PSU-sizing standard or recommend a hardware model.