## InstaController Product Configuration Details.

### **ARSI31074**:



**Image: Front Panel** 



Image: Rear Panel

### **RSI552:**



**Image: Front Panel** 



**Image: Back Panel** 



Power Adaptor 12v/2A adaptor.

# **D-Link DIR-615 Roter configure for Insta Controller.**




Use only 5V Power adaptor for this Model.



- 1) LAN cable to the LAP or PC, Power ON, login to the D-LINK router, 192.168.0.1
- 2) go to the advanced settings.
- 3) admin password set to peoplelink
- 4) ssid set to peoplelink
- 5) wifi password set to peoplelink
- 6) LAN IP set to 192.168.2.1
- 7) set DHCP range set to 192.168.2.100 to 192.168.2.200.

Apply changes , Reboot .

## **InstaController Board Major Components:**



1. InstaController V3.09 apk application install on Tab , Third Party app installations Permisions need to enable.

Tab Image:



7" Tab size InstaController Application version 3.0.9

## **InstaController TAB settings and Apk Installation**


1) Power on TAB, configure settings:

settings -> display -> sleep-> never,

settings -> security -> screen lock -> none


Enable settings -> Security-> unknown sources to install the APK

2) Connect USB data cable to tab, plug in to PC, open QUAD-CORE A33 yh device




3) Copy <u>InstaController V 3.0.9</u> APK file to Download folder,

Open menu : ES file Explorer -> Download-> click on InstaController APK file and install.



4) Open Internal storage ->Android ->com.peoplelinkvc.instacontroller -> data -> Files

Copy the **cnf** folders default configuration files to this Files folder





**Note**: apk file copied by default to download folder for future use and below steps executed while production testing. **Update option**: New devices updated files can be downloaded through Bluetooth or from the internet download link to the tab, replace it in the specified folder.

# App Configurations:




Default User Name: Admin Password: abcd







Ports 1-3 Settings all are Serial, 4-7 IR or Serial, IR Tx module required for Ports configured as IR, settings saved in InstaController SD card memory.





Screen shots given is testing Purpose configured as IR.



Port Configuration : Select the devices and its configuration files from the data base.







#### Note:

- 1) Pro Audio DSP ports 1 or 2 or 3, Baud rate 115200 (PL\_PRODSP\_115200)
- 2) S86 Display ports 1 or 2 or 3, Baud rate 38400, R Display-115200 \*
- 3) Peoplelink AIO DSP ports 1-7, Baud rate 9600 (PL MDSP N)
- 4) Peoplelink- Camera ports 1-7, Baud rate 9600
- 5) BenQ Projector ports 1-7, Baud rate 9600 (Projector also need to set same rate)
- 6) Peoplelink Android 8 (S\_A8), Android 10(S\_A10), Peoplelink-R Displays IR control Ports 4 to 7.
- 7) Changed device config names with baudrate/model info (30<sup>th</sup> May2024)

\*Peoplelink R Series Display/Monitor Updated on 30th May 2024