

2 -Fuel injection - ignition system

The electrical components of the fuel injection-ignition system are listed below: indicated reference number refers to the diagram in Sect. P 1, [Key to wiring diagram](#):

Key to fuel injection–ignition system diagram

- 3) Horizontal cylinder spark plug
- 4) Vertical cylinder spark plug
- 6) Starter contactor
- 7) Battery
- 8) Main fuse
- 15) Fuel tank
- 18) Self-diagnosis/DDA
- 19) Horizontal cylinder coil
- 20) Vertical cylinder coil.
- 23) Horizontal cylinder injector
- 24) Vertical cylinder injector
- 25) Throttle position sensor
- 26) Timing/rpm sensor
- 29) Side stand
- 32) Oil pressure switch
- 34) ECU
- 35) Fuses
- 40) Air temperature sensor
- 47) Stepper motor