

Symcli Commands

Quick Reference Guide

Compiled by Rajesh V U

Refer the latest Solution Enabler document from EMC or command help, to make sure the full syntax and accuracy of commands.

symaccess	
symaccess -sid 1234 list	List all Initiator, Port and Storage Groups Created for Array 1234
symaccess -sid 1234 list -v	List all Initiator,Port and Storage Groups Created for Array 1234 along with related Masking Views
symaccess -sid 1234 list -type storage	List all Storage Groups Created for Array 1234
symaccess -sid 1234 list -type initiator	List all Initiator Groups Created for Array 1234
symaccess -sid 1234 list -type port	List all Port Groups Created for Array 1234
symaccess -sid 1234 list view	List masking views Created for Array 1234 with related groups details
symaccess -sid 1234 list assignment -dev 9A0:9AF	Shows the masking details of devices from 9A0 to 9AF
symaccess -sid 1234 -wwn xxxx replace -new_wwn yyyy	Replace all occurrence of wwn xxxx with yyyy in array 1234
symaccess -sid 1234 list logins -wwn xxxx	Check whether wwn xxx logged in to any of the FAs on array 1234.
symaccess -sid 1234 list -type initiator -wwn xxxx	Check whether the HBA WWN xxxx is a member of any Initiator Group.
symaccess -sid 1234 list -type storage -dev AAA	Check whether the device AAA is part of of any Storage Groups.
symaccess -sid 1234 list no_assignments -dirport 12f:1	Shows the devices are mapped to 12f:1 but not part of any masking view.
symaccess -sid 1234 list -name MyGroup	List all groups named MyGroup
symaccess -sid 1234 list -name MyGroup -v	List all groups named MyGroup and also shows the related Masking Views
symaccess -sid 1234 list devinfo -ig MyInitiator	List the details of devices assigned to the initiatorgroup MyInitiator
symaccess -sid 1234 show MyStorageGroup -type storage	Shows the contents of storage group MyStorageGroup Created on Array 1234
symaccess -sid 1234 show MyInitiatorGroup -type initiator	Shows the contents of initiator group MyInitiatorGroup Created on Array 1234
symaccess -sid 1234 show MyPortGroup -type port	Shows the contents of port group MyPortGroup Createdon Array 1234
symaccess -sid 1234 show view MyView	Shows the contents of view MyView Created on Array 1234
symaccess -sid 1234 -f MyBackup.txt backup	Creates a file MyBackup containing all the group and view information currently on the Symmetrix array 1234
symaccess -sid 1234 -f MyBackup.txt restore	Restores all the group
symaccess -sid 1234 -type initiator -name Host1 create - wwn 100000000000000001	Creates and initiator group called Host1 by adding the specified wwn
symaccess -sid 1234 -type initiator -name Host1 rename - new_name Host2	Rename the Initiator Gorup Host1 as Host2

symaccess -sid 1234 -type port -name 3E0_4E0_13E0_14E0 -dirport 3e:0,4e:0,13e:0,14e:0 create	Create the portgroup E0_4E0_13E0_14E0 with specified ports
symaccess -sid 1234 -type port -name 3E0_4E0_13E0_14E0 rename -new_name 3E1_4E1_13E1_14E1	Rename the Port Gorup 3E0_4E0_13E0_14E0 as 3E1_4E1_13E1_14E1
symaccess -sid 1234 -type storage -name Host1 create devs AAA:AAB	Create the storage group Host1 with specified range of devices
symaccess -sid 1234 -type storage -name Host1 add devs AAA:AAB	Add the devices AAA:AAB to storage group Host1. goto utility
symaccess -sid 1234 -type storage -name Host1 remove devs AAA:AAB	Remove the device AAA to AAB from storage group Host1
symaccess -sid 1234 -type storage -name Host1 remove devs AAA:AAB -unmap	Remove the device AAA to AAB from storage group Host1 and also unmap from the FAs
symaccess -sid 1234 -type storage -name Host1 rename -new_name Host2	Rename the Storage Gorup Host1 as Host2
symaccess -sid 1234 create view -name Host1_Allocation -sg Host1 -pg 3E0_4E0_13E0_14E0 -ig Host1	Create a masking view combined with specified groups
symaccess -sid 1234 view -name Host1_Allocation rename -new_name Host2_Allocation	Rename name of view Host1_Allocation as Host2_Allocation
symaccess -sid 1234 delete view -name Host1_Allocation	Delete view Host1_Allocation.
symaccess -sid 1234 delete view -name Host1_Allocation -unmap	Delete view Host1_Allocation and also unmap all the device in associated storage group.
symaccess -sid 1234 -name PG_1_2_15_16_E0_Group -type port -dirport 1e:0,16e:0 remove	Remove ports 1e:0 and 16e:0 from port group 'PG_1_2_15_16_E0_Group'.
symaccess -sid 1234 -name PG_1_2_15_16_E0_Group -type port -dirport 1e:0,16e:0 remove	Remove ports 1e:0 and 16e:0 from port group 'PG_1_2_15_16_E0_Group'.
symaccess -sid 1234 -name IG_Server_A -type initiator -wwn xxxx remove	Remove HBA WWN 'xxxx' from Initiator Group 'IG_Server_A'
symaccess -sid 1234 -name IG_Servers -type initiator -ig IG_Server_A remove	Remove Initiator Group 'IG_Server_A' from parent Initiator Group 'IG_Servers'
symaccess list hba	Shows the wwn of the local HBA and the devices assigned to those.
symaccess -sid 1234 view -name Host1_Allocation rename -new_name Host2_Allocation	Rename name of view Host1_Allocation as Host2_Allocation
symaccess -sid 1234 -f Total_views backup	This command will backup all the Maksing Views information for array 1234 to file Total_views.
symaccess -sid 1234 -f Total_views restore	This command will restore all Masking view information for Vmax Array 1234 from file Total_views , which is earlier created by "backup" option.

<code>symaccess -sid 1234 -type initiator -name Host1 add -wwn 1000000000000002</code>	Add another HBA WWN to the existing Initiator group(IG) "Host1".
<code>symaccess -sid 1234 -type port -name MyPorts add -dirport 6e:0</code>	Add an additional port 6e:0 to the existing port group(PG) "MyPorts".
<code>symaccess -sid 1234 -type initiator -name Host1_Host2_IG add -ig Host2_IG</code>	Add a child Initiator Group(Host2_IG) to the parent Initiator Group(Host1_Host2_IG).
<code>symaccess -sid 1234 show MyInitiatorGroup -type initiator -detail</code>	By including '-detail' option will shows the Flag settings like 'FCID Lockdown' , 'Consistent Lun'.. for each WWN number in the initiator group.
<code>symaccess -sid 1234 show view MyView -detail</code>	This command is the best option to see both parent and child initiator groups(cascaded initiator group) and associated devices for a masking view.
<code>symaccess -sid 1234 show view Server_A_B_View -ig Server_B_IG</code>	Displays the content of view 'Server_A_B_View' with the WWN details of child-Initiator group 'Server_B_IG'.
<code>symaccess -sid 1234 remove -login -wwn 1000000000000001 -dirport 12g:1</code>	Delete the wwn 1000000000000001 on port 6g:1 from the login history table of vmax 1234
<code>symaccess -sid 1234 delete -name MyStorageGroup -type storage</code>	Delete/Remove an empty storage group.The "-force" must be used if the storage group(SG) is not empty.We can't delete SG if it is part of a Masking View.
<code>symaccess -sid 1234 delete -name MyPortGroup -type port</code>	Delete/Remove an empty port group.The "-force" must be used if the port group(PG) is not empty.We can't delete PG if it is part of any Masking View.
<code>symaccess -sid 1234 delete -name MyInitiator -type init</code>	Delete/Remove an empty initiator group.The "-force" must be used if the initiator group(IG) is not empty.We can't delete IG if it is part of a Masking View.
<code>symaccess -sid 1234 -file Views_Groups_1234.txt backup</code>	Backup all the view and group information currently on VMAX 1234 to the file Views_Groups_1234.txt.
<code>symaccess -sid 1234 -file Views_Groups_1234.txt restore</code>	Restores all the groups, views, and security informations from the previously(created using backup option) file.
<code>symaccess -sid 1234 -file Views_Groups_1234.txt list</code>	Lists all the Group(storage,port,initiator) information from the backup file "Views_Groups_1234.txt".
<code>symaccess -sid 1234 -file Views_Groups_1234.txt list view</code>	Lists all the views from the backup file "Views_Groups_1234.txt".
<code>symaccess -sid 1234 -type initiator -name Host1 create -consistent_lun</code>	Create the Initiator Group Host1 and enable the LUN id consistency at the same time.
<code>symaccess -sid 1234 -type initiator -name Host1 set consistent_lun on</code>	Enable the LUN id consistency on an existing IG.
<code>symaccess -sid 1234 list view -name Host1_Allocation -v</code>	This command shows more readable information about the associated Storage Group,Initiator Groups and Port Groups.
<code>symaccess -sid 1234 -type storage -name Host1 remove devs AAA:AAB -unmap -celerra</code>	Remove the celerra device AAA to AAB from storage group Host1 and also unmap from the FAs

symaccess -sid 1234 -type storage -name Host1 add devs AAA:AAB -celerra	Add the Celerra devices AAA:AAB to storage group Host1.
symaccess -sid 1234 -wwn 1000000000000001 rename - alias Host1/HBA01	Create/Rename Node Name(Host1) and Portname(HBA01) in Access-logix database for given WWN.
symaccess -sid 1234 verify	Verify the ACLX database in VMax 1234 is consistent.
symaccess -sid 1234 remove -login -wwn 1000000000000001	Completely remove the wwn 1000000000000001 from the login history table of vmax 1234
symapierr	
symapierr 0	SYMAPI return code '0' is the success code.This command will shows the text version of the error code ie, "SYMAPI_C_SUCCESS" and the respective message.
symbcv	
symbcv -sid 1234 list	Lists all the BCV devices in array 1234 along with details like BCV-STD device,Status of the pair etc.
symbcv -sid 1234 -g TestDg associate dev BBB	Add the BCV device BBB to the Device Group TestDg.
symbcv -g TestDg disassociate dev BBB	Remove/Disassociates the device BBB from DG TestDg.
symcfg	
symcfg discover	Scans all the devices in hosts looking for new symmetrix devices and rebuilds the symmetrix configuration database .
symcfg list	A brief description of the all connected Symmetrix boxes.
symcfg -sid 1234 verify	Check whether the SYMAPI database is in sync with the current configuration of array 1234.
symcfg list -status	Check the configuartion and SYMAPI database status of all arrays.
symcfg -db	Shows the configuration information about the current symapi database.
symcfg -sid 1234 remove	Remove the array 1234 from symcfg list.
symcfg -sid 1234 list -lockn all	List all the external locks held in Symmetrix array 1234.
symcfg -sid 1234 -lockn 15 release -force	Release the lock 15 held on array 1234 .
symcfg -sid 1234 list -v	Displays detailed information about the Symmetrix Array 1234.
symcfg -sid 1234 list -dir all	Displays the online status of all directors(Frontend+Backend).
symcfg -sid 1234 list -sa all	Displays the online status of all Front-end directors.

<code>symcfg -sid 1234 list -da all</code>	Displays the online status of all Back-end directors.
<code>symcfg -sid 1234 list -fa all</code>	Displays wwn of all front-end director ports.
<code>symcfg -sid 1234 list -fa all -port</code>	Displays online and connection status of all front-end director ports.
<code>symcfg -sid 1234 list -ra all</code>	List all RA ports with details like rdfig number , remote array sid and online status.
<code>symcfg -sid 1234 -dir 4a -p 0 list -addr -avail</code>	List the LUN information / availability of lun ids on port 4a0 in array 1234 .
<code>symcfg -sid 1234 list -rdfig all</code>	List details about all the rdf groups in array.
<code>symcfg -sid 1234 list -rdfig 3</code>	List details about rdf group 3 .
<code>symcfg -sid 1234 list -rdfig all -dynamic</code>	List details about all the dynamic rdf groups in array .
<code>symcfg -sid 1234 list -rdfig all -static</code>	List details about all the static rdf groups in array .
<code>symcfg -sid 198 list -rdfig 10 -rdfa</code>	Shows the specific SRDF/A information about the rdf group 10.
<code>symcfg -sid 1234 list -env_data</code>	Dispalys the information and status of arrays physical components like powersupply units Fans etc.
<code>symcfg -sid 1234 list -thin -pool -GB</code>	List all the thinpools in array 1234.
<code>symcfg -sid 1234 show -pool My_Pool -thin -GB</code>	List all the datadevices in thinpool My_Pool on array 1234.
<code>symcfg -sid 1234 list -tdev -GB</code>	List all the thin devices in array 1234.And also shows the thinpools associated to each device with the binding status.
<code>symcfg -sid 1234 list -tdev -gb -thin -pool My_Pool</code>	List all the thin devices assoicated with thinpool My_Pool
<code>symcfg -sid 1234 -SA 6h -P 1online</code>	Make the front-end port 6h:1 to online.
<code>symcfg -sid 1234 -SA 6h -P 1offline</code>	Make the front-end port 6h:1 to offline.
<code>symcfg -sid 1234 list -memory</code>	shows the amount and details of memory configure in the array .
<code>symcfg -sid 1234 list -tdev -GB -detail</code>	With "detail" option ,this commands will displays the multiple thin pools that each TEVS binded with.
<code>symcfg -sid 1234 list -datadev -GB</code>	Displays the datadevices in array 1234 along with the pool information of each device is associated with.
<code>symcfg -sid 1234 list -tdev -bound -GB</code>	Lists all the thin devices in array 1234 which are bounded to a thin pool.
<code>symcfg -sid 1234 list -tdev -unbound -GB</code>	Lists all the thin devices in array 1234 which are not bounded to any thin pools.
<code>symcfg -sid 1234 list -tdev -range AAA:AAB -GB</code>	Lists thin devices starting from AAA to ABB and the pools which are bounded with.

symcfg -sid 1234 list -tdev -sg MySg	Lists all the TDEVs in Storage Group MySg with the bounded poolname and other useful details.
symcfg -sid 1234 list -tdev -sg MySg -detail	Lists all the TDEVs in Storage Group MySg with the bounded poolname and other useful details. This also displays actual bounded pool and also the pool which currently moved due to "rebind" or FAST Policy.
symcfg -sid 1234 list -connections	Lists all the hosts along with the OS version, connected to array 1234. This also give the information about the Service Processor of 1234.
symcfg -sid 1234 list -thin -pool -GB -detail	List all the thinpools in array 1234 along with Subscription percentage for each thin pool. subscription percentage=Total Bounded TDEV capacity/Total Thin Pool Capacity*100.
symcli	
symcli	Displays the version of symapi.
symcli -v	Shows the version of symapi and total list of symcli commands with a short description.
symcli -env	The list of environmental variable that can be set for a SYMCLI session.
symcli -def	List of currently defined environmental variables .
symclone	
symclone -g TestDg create DEV001 sym Id DEV002	Create a clone copy session between the devices DEV001(source) and DEV002(target) in regular diskgroup TestDg. By default this will create a differential session. That means, we can do a incremental recreate or restore later. This command will make the target device in Not Ready(NR).
symclone -g TestDg create DEV001 sym Id DEV002 - precopy	Create a clone copy session between the devices DEV001(source) and DEV002(target) in regular diskgroup TestDg. This will start background copy from DEV001 to DEV002 after making the target device as NotReady(NR).
symclone -g TestDg create DEV001 sym Id DEV002 - nocopy	Create a "CopyOnAccess" clone session between the devices DEV001(source) and DEV002(target) in regular diskgroup TestDg. This wont start any background copying from source to target device even after activating the session.
symclone -g TestDg activate DEV001 sym Id DEV002	Activate the clone session. This will make the target devices in ReadWrite(RW) mode. If the session created with a "-copy" option (default create option is copy), this will start the background copy from source to target device. There won't be any background copy if the session created with "-nocopy" option.
symclone -g TestDg terminate DEV001 sym Id DEV002	This will terminate the clone session between DEV001 and DEV002, deletes the pairing information from the storage array and removes any hold on target device. You have to 'Terminate' while the pair in 'Copied' state to get a fully valid data.
symclone -g TestDg recreate DEV001 sym Id DEV002	Recreate a previously activated clone session. The session SHOULD NOT be created with a "-nocopy" or "-nondifferential" option.

symclone -g TestDg recreate DEV001 sym Id DEV002 -precopy	Recreate a previously activated clone session. The session SHOULD NOT be created with a "-nocopy" or "-nondifferential" option. This will start an "incremental" background copy still keeping the target device in NR state.
symconfigure	
symconfigure -sid 1234 list -v	Shows the configuration informations like the micro-code version , whether the Dynamic RDF is enabled or not etc..
symconfigure -sid 1234 list -freespace -units mb	Shows the Formatted and Unformatted freespace in MegaBytes on array 1234
symconfigure -sid 1234 query	Check the status of a running configuration change.
symconfigure -sid 1234 -f command_file.txt preview	Validates the syntax of the commands in 'command_file.txt' and also verify the configuration changes.
symconfigure -sid 1234 -f command_file.txt prepare	The prepare option will validate the command syntax and Verify the appropriateness of the changes and operations.
symconfigure -sid 1234 -f command_file.txt commit	Apply the changes defined in the command file.
create dev count=10, size=18414, emulation=FBA, data_member_count=3, config=RAID-5, disk_group=2, dynamic_capability=dyn_rdf;	Create 10 RAID-5 devices of size 18414 cylinders , as emulation FBA from diskgroup 2 and also set the dynamic bit on those.
create dev count=10, size=20GB, emulation=FBA, config=TDEV;	Create 10 thin devices of size 20GB with emulation type as FBA.
create dev count=10, size=1025, emulation=FBA, config=TDEV;	Create 10 thin devices of cylinder size 1025(around 1GB) with emulation type as FBA.
create dev count=10, size=10GB, emulation=FBA, config=TDEV, binding to pool=MyPool;	Create 10 thin devices of size 20GB with emulation type as FBA and also bind to thin pool MyPool.
create dev count=10, size=10GB, emulation=FBA, config=TDEV, binding to pool=MyPool, preallocate size=5GB ;	Create 10 thin devices of size 20GB with emulation type as FBA , bind to thin pool MyPool and preallocate 5GB.
bind tdev AAA:AAB to pool MyPool;	Bind the TDEVs AAA and AAB to thin pool MyPool.
bind tdev AAA:AAB to pool MyPool preallocate size =5GB ;	Bind the TDEVs AAA and AAB(of 10GB each) to thin pool MyPool and preallocate 5GB for each device.
start allocate on tdev AAAA:AABB start_cyl=0 end_cyl = last_cyl;	Allocate the tdevs AAAA to AABB to 100% of its defined size.
set device ABCD emulation=FBA;	Convert a CELERA_FBA device to FBA.(the existing emulation type of device ABCD is CELERA_FBA)
set device ABCD emulation=CELERRA_FBA;	Convert FBA Device ABCD to a CELERA Device.(The current emulation type of the device ABCD is FBA.)
bind tdev in SG Server1_SG to pool My_Pool;	Bind the devices in Storage Group "Server1_SG" to thin pool "My_Pool"

set disk_group 5, disk_group_name = Tier2_400GB;	Assign a name "Tier2_400GB" to disk group 5.
convert rdf dev AAA to dynamic;	convert static SRDF device AAA to dynamic device.
delete dev AAA:AAB;	delete the symdevs AAA:AAB.
set symmetrix concurrent_rdf=ENABLE;	Enables the concurrent SRDF Feature in a Symmetric Array.This will enable to create SRDF-R1 devices with multiple R2s.
set symmetrix dynamic_rdf=ENABLE;	Enables the Dynamic RDF capability of the array.
set symmetrix dynamic_concurrent_rdf=ENABLE;	enables the concurrent SRDF capability in the array level, where can have multiple R2s for a single R1 dynamic rdf device.
bind tdev AAA to pool MyPool preallocate size=ALL ;	Bind the device AAA to thin pool MyPool and prelocate the entire size of device.
symconfigure -sid 1234 -cmd "set dev AAA attribute=dyn_rdf;" preview	With 'cmd' option we can mention the commands to be executed along with the symconfigure command itself and thus avoid the creation of a command file.
symconfigure -sid 1234 abort	Abort a configuration session started earlier.
symconfigure -sid 1234 verify	Verify the current symmetrix configuration is ready for a configuration change.
create pool ThinPool1 type =thin;	Create thinpool named "ThinPool1"
create dev count=4, config=RAID-5, data_member_count=3, attribute=datadev, emulation=FBA, size=2GB, disk_group=1;	Create 4 RAID-5 DATADEVs of 2GB each in diskgroup1 with FBA emulation.
delete pool MyThinPool , type=thin;	Delete an empty thin pool called MyThinPool.
add dev AAA:AAB to pool MyThinPool, type=thin, member_state=ENABLE;	Add the DATA devices AAA to AAB to MyThinPool and enable its state.
remove dev AAA from pool MyThinPool, type=thin;	Remove DATA device AAA from MyThinPool.AAA must be disabled before executing this command.
enable dev AAA:AAB in pool MyThinPool, type=thin;	Enable the DATA devices AAA and AAB in MyThinPool.Once enabled , a data device in a thin pool , can be use to allocate extents to its bounded thin devices.
disable dev AAA:AAB in pool MyThinPool, type=thin;	Disable DATA devices AAA and AAB in MyThinPool. If the DATA device to be used for thin extent allocation , it should be on enabled state. Once it is disabled , we can remove the DATA devices from thin pool. Symmetrix automatically initiates drain operation on disabled DATA devices without any disruption to the application. Once all the allocated extents are drained to other DATA devices, the disabled DATA devices can be removed from the thin pool.
rename pool MyOldThinPool to MyNewThinPool type = thin;	Rename thin pool MyOldThinPool to MyNewThinPool .
symconfigure -sid 1234 list -reserved	List the reserved devices in array 1234.

symconfigure -sid 1234 -cmd "reserve dev AAA;" -owner Rajesh -comment "Reserved for Migration" reserve -nop	Reserve the device AAA for migration.
symconfigure -sid 1234 release -reserve_id 10 -nop	Release the reservation on device(s).
set pool MyThinPool, type=thin, max_subs_percent=150;	set the maximum over subscription ratio of thin pool to 150%. If want to keep unlimited ratio , give value as "none".
set dev AAAA device_name='testdevice' ;	set the device_name identifier for device "AAAA" as "testdevice". These devices can be listed by command "symdev -sid 1234 list -identifier device_name" .
set dev AAAA NO device_name ;	Remove the device_name identifier ,"testdevice" for device AAAA.
start reclaim on tdev AAA:AAF;	Reclaim the allocated but unused space as well as the pool space completely written with zeros.
start reclaim on tdev AAA:AAF allocate_type = persistent;	Reclaim the allocated but unwritten space as well as the allocated thin pool space completely written with zeros, even it is allocated as persistent .
start free on tdev AAA:AAF start_cyl =0 end_cyl = last_cyl;	Reclaim the allocated but unwritten space of thin pool space for the mentioned tdevs.
form meta from dev AAA, config=striped, stripe_size=1920; add dev AAB to meta AAA;	Create a 2 member striped meta; AAA as meta head and AAB as member. utility for DMX , utility for Vmax
create gatekeeper count=10,emulation=FBA;	Create 10 thick gatekeeper devices of FBA emulation. The size of each device will be ~3MB/3 cylinders.
create gatekeeper count=10,emulation=FBA,type=thin;	Create 10 thin GateKeeper devices of emulation FBA. The size of each device will be ~3MB/3 cylinders.
form meta from dev AAAA, config=striped, stripe_size=1920;add dev AAAB to meta AAAA;	Create 2 member striped meta , device AAAA as meta head.
form meta from dev AAAA, config=concatenated;add dev AAAB to meta AAAA;	Create 2 member concatenated meta device , AAAA as meta head.
dissolve meta dev AAAA:AAAF,BBBB;	dissolve meta heads AAAA to AA AF and BBBB.
enable rdfa on ra_group 100;	Enable RDF Asynchronous on rdf group 100
enable rdfa on ra_group 100,make_group_swappable=TRUE;	Enable RDF Asynchronous on rdf group 100 and make that role swappable.
map dev AAAA to dir 3e:0 lun=AF;	Map device AAAA to FA port 3e:0 , with lun id as AF
remove dev AAAB from meta AAAA;	Remove a meta member AAAB from meta AAAA.
unbind tdev AAAA:AAAB from pool T2_2TB;	Unbind thin devices AAAA to AAAB from it bounded thin pool T2_2TB.
unbind tdev in DG Server_1_dg from pool T2_2TB;	Unbind all the thin devices as part of device group Server_1_dg, from its bounded thin pool ,T2_2TB.

unbind tdev in SG Server_1_sg from pool T2_2TB;	Unbind all the thin devices as part of Storage group Server_1_wg, from its bounded thin pool ,T2_2TB.
unmap dev AAAA:AAAB from dir ALL:ALL;	Unmap devices AAAA and AAAB from all the mapped FA ports.
unmap dev AAAA:AAAB from dir 3e:0;	Unmap devices AAAA and AAAB only from the mapped FA port, 3e:0.
unmap dev AAAA:AAAB from dir 3e:ALL;	Unmap devices AAAA and AAAB only from the mapped FA ports, 3e:0 and 3e:1.
unmap dev AAAA:AAAB from dir ALL:ALL,devmask_access = remove;	unmap devices AAAA and AAAB from all the mapped FA ports, also removes the masking.
create pool My_Snap_pool ,type = snap;	Create a SNAP pool for snapshot operations.
create pool My_DSE_pool ,type = rdfa_dse;	Create a DSE pool for RDF/Asynchronous operations.
create pool My_Thinpool ,type = thin;	Create a thin pool .
delete pool My_Snap_pool ,type = snap;	Delete SNAP pool My_Snap_pool.
delete pool My_Thinpool ,type = thin;	Delete thin pool My_Thinpool.
delete pool My_DSE_pool ,type = rdfa_dse;	Delete DSE pool My_DSE_pool.
rename pool My_Thinpool to My_New_Thinpool type =thin;	Rename thin pool My_Thinpool to My_New_Thinpool.
add dev AAAA:AAAB to pool MySnapPool, type=snap, member_state=ENABLE;	Add SAVEDEVices AAAA:AAAB to SANP pool MySnapPool and enable.
add dev AAAA:AAAB to pool MyDSEPool, type=rdfa_dse, member_state=ENABLE;	Add SAVEDEVices AAAA:AAAB to DSE pool MyDSEPool and enable.
activate dev AAAA:AAAB in pool MyThinPool , type = thin;	Activate DATA devices AAAA:AAAB in thin pool for use.Reads and writes can be done on allocated or unallocated space on Activated DATA devices.
deactivate dev AAAA:AAAB in pool MyThinPool , type = thin;	Activate DATA devices AAAA:AAAB in thin pool for use.Reads and writes can be done on already allocated space on Activated DATA devices.No new allocations can be done on deactivated DATA devices.
rebind tdev AAAA:AAAB to pool T2_2TB;	Bind devices AAAA:AAAB , which are already bounded to a thin pool , to another thin pool T2_2TB.The already written data on the earlier bounded pool will not migrated to the newly bounded pool.The upcoming writes will go to the newly bounded pool.
symdev	
symdev -sid 1234 list -all	List all devices in symmetrix 1234.
symdev -sid 1234 list -noport	List the devices which are not mapped to any ports.
symdev -sid 1234 list -noport -meta	List all unmapped meta devices .

symdev -sid 1234 list -dynamic	List all devices whose dyn_rdf attribute set .
symdev -sid 1234 list -emulation celerra	List all celerra devices .
symdev -sid 1234 list -emulation FBA	List all FB devices .
symdev -sid 1234 list -hotspare	Checks whether hotspare invoked in the array .
symdev -sid 1234 list -inventory	Lists the grouped list of various devices like RAID-5 2-Way_Mirror etc..
symdev -sid 1234 show ABC	show the detailed information about device ABC.
symdev -sid 1234 list -range ABC:ABE -v	show the detailed information of devices ABC to ABE.
symdev -sid 1234 list -range ABC:ABE -multiport	List the devices from ABC:ABE with the mapped FA information if they are assigned to more than one FA port.
symdev -sid 1234 write_disable ABC -SA all	Write disable the device ABC from through all directors.
symdev -sid 1234 write_disable ABC -SA 3a -p 0	Write disable the device ABC on FA port 3a:0.
symdev -sid 1234 not_ready ABC	set the device status as "Not Ready".
symdev -sid 1234 ready ABC	Set the status of the device ABC to "Ready".
symdev -sid 1234 list -tdev	list all thin devices in array 1234
symdev -sid 1234 list -tdev -noport	list all thin devices in array 1234 which are not mapped
symdev -sid 1234 list -datadev	This commands will provide the list of DATA devices created in array 1234.
symdev -sid 1234 list -identifier device_name	List the symdevs along with its Name
symdev -sid 1234 list -sg MySg	Lists all the devices in Storage Group "MySg" along with its type,state and size.
symdev -sid 1234 list -N 10	Lists first 10 devices in array 1234.
symdev -sid 1234 list -range AAA:AAC	List the devices AAA to AAC along with the informations like ConfigType,Status,Size etc.
symdev -sid 1234 list -devs AAA:AAC,BBB,CCC	List the devices AAA to AAC,BBB and CCC along with the informations like ConfigType,Status,Size etc.
symdev -sid 305 list -dldev	Lists all the diskless devices(DLDEV) in array 1234.
symdev -sid 1234 list -vcm	Lists the VCM Devices in DMX and Accesslogix devices in Vmax Array.
symdev -sid 1234 list -aclx	Lists the VCM Devices in DMX and Accesslogix devices in Vmax Array
symdev -sid 1234 list -nomember	Lists all the devices in array 1234 , except meta members.(all the meta heads and non-meta devices)

symdev -sid 1234 list -tdev -bound	Lists all the tdevs in the array 1234 , which are binded with a thinpool.
symdev -sid 1234 list -tdev -unbound	Lists all the tdevs in the array 1234 , which are NOT binded with any thinpool.
symdev -sid 1234 list -datadev -nonpooled	Lists all the free DATADEVs , those are not assigned to any thinpool.
symdev -sid 1234 list -firstport	Lists the devices , those mapped to atleast one FA port.
symdev -sid 1234 list -r1	List all the RDF1 devices.
symdev -sid 1234 list -r1 -dynamic	Lists all the dyn_rdf1 enabled devices.
symdev -sid 1234 list -r2	List all the RDF2 devices.
symdev -sid 1234 list -r2 -dynamic	Lists all the dyn_rdf2 enabled devices.
symdev -sid 1234 list -r21	List all the RDF21 devices.
symdev -sid 1234 list -spare	Checks whether hotspare invoked in the array .
symdev -sid 1234 list -notrdf	Lists all the non-srdf devices.
symdev -sid 1234 list -fast	Lists all the devices which are FAST controlled.
symdev -sid 1234 list -pinned	Lists all the devices which are user pinned devices(User Pinned devices will not be moved by FAST Controller , but may be moved by Optimizer or Symmmigrate)
symdev -sid 1234 pin AAA	Pin the device AAA on Vmax 1234.User Pinned devices will not be moved by FAST Controller , but may be moved by Optimizer or Symmmigrate
symdev -sid 1234 unpin AAA	Unpin the device AAA on Vmax 1234.User Pinned devices will not be moved by FAST Controller , but may be moved by Optimizer or Symmmigrate .
symdev -sid 1234 list -nobcv	Lists all the standard, non-bcv devices .
symdev -sid 3624 list -technology FC	Lists all the FC thick devices on VMax 1234
symdev -sid 3624 list -technology SATA	Lists all the SATA thick devices on VMax 1234
symdev -sid 3624 list -technology EFD	Lists all the FLASH thick devices on VMax 1234
symdev -sid 1234 write_disable -devs AAA:BBB,BBD -SA all	Write disable the devices AAA:BBB and BBD on all directors.
symdev -sid 1234 ready -devs AAA:BBB	Set ready the status of all devices from AAA to BBB .
symdev -sid 1234 not_ready -devs AAA:BBB	Make "Not Ready" the devices AAA to BBB.
symdev -sid 1234 list -rdfg 10	Lists all the SRDF device belongs to RDF Group 10

symdev -sid 1234 -dev AAA:AAC,DDD bind -pool MyThinPool	Bind devices AAA:AAC and DDD to thin pool MyThinPool .(required SE 7.6+ and Enginuity 5876+)
symdev -sid 1234 -dev AAA:AAC,DDD unbind	Unbind the devices AAA:AAC,DDD from its respective binded thin pools.(required SE 7.6+ and Enginuity 5876+)
symdev -sid 1234 -dev AAA:AAC,DDD rebind -pool MyThinPool	Rebind devices AAA:AAC,DDD to the thin pool , MyThinPool.(required SE 7.6+ and Enginuity 5876+)
symdg	
symdg -sid 1234 list	List device groups which include the devices from array 1234.
symdg create mydg -type rdf1	Create device group mydg of rdf1 type .
symdg show mydg	Shows members/details of mydg.
symdg rename mydg yourdg	Renames the mydg to yourdg.
symdg -sid 1234 export mydg -f mydgfile.txt	Export mydg to file mydgfile.txt.
symdg -sid 1234 import mydg -f mydgfile.txt	Create mydg from the file mydgfile.txt which created earlier using export option.
symdg -sid 1234 exportall -f mydgfile.txt	Export all device groups created in array 1234 to file mydgfile.txt.
symdg -sid 1234 importall -f mydgfile.txt	Create all device groups from the file mydgfile.txt which created earlier using exportall option.
symdg -sid 1234 -g mydg move DEV002 yourdg	Move the device DEV003 from mydg to yourdg(both DGs must be in same RDFG.
symdg -sid 1234 -g mydg moveall yourdg	Move all the devices from mydg to yourdg(both DGs must be in same RDFG.
symdg delete mydg -force	Delete device group mydg.
symdg -g MyDg -sid 1234 addall -devs AAA,BBB,CCC,DDD:DDF	Add devices AAA,BBB,CCC,DDD:DDF to devicegroup MyDg
symdg -g MyDg -sid 1234 rmall -devs AAA,BBB,CCC,DDD:DDF	Remove devices AAA,BBB,CCC,DDD:DDF from devicegroup MyDg
symdg -g MyDg remove ld DEV002	Remove logical device DEV002 from device group MyDG.
symdg -sid 1234 list -v	This will list all the devicegroups belongs to 1234 , and also the devices in it. This is equal to "show" each device groups in the array.
symdisk	
symdisk -sid 1234 list	List of total disks in the array.

symdisk -sid 1234 show 1A:C12	Shows the detailed information like speed and HYPERS of the disk 1A:C12.
symdisk -sid 1234 show 1A:C12 -gaps	Shows the available space(GAPS) on the disk 1A:C12.
symdisk -sid 1234 show 1A:C12 -gaps_only	Shows only the available space(GAPS) on the disk 1A:C12.
symdisk -sid 1234 list -hotspares	List Hotspares configured in the array.
symdisk -sid 1234 list -v -spare_info	Displays the details of all hotspare in the array.
symdisk -sid 1234 list -by_diskgroup	Displays all the disks in array by disk groups.
symdisk -sid 1234 list -disk_group 1	Displays all the disks in disk group 1.
symdisk -sid 1234 list -dskgrp_summary	This provides a brief summary of all diskgroups in array 1234 along with speed , size and type of disks.
symdisk -sid 1234 list -failed	Lists all the failed drives in array 1234.
symdisk -sid 1234 list -isspare	List Hotspares configured in the array.
symfast	
symfast -sid 1234 list -fp	Lists all the FAST Policies in array 1234 along with the number of Tiers and Storage Groups(SG) .
symfast -sid 1234 show -fp_name Tier1	Lists all the storage groups and Tiers associated with the FAST Policy in array 1234
symfast -sid 1234 list -fp -vp	Lists all the FAST Policies in array 1234 , which contains Virtual Pool Tiers.
symfast -sid 1234 list -fp -dp	Lists all the FAST Policies in array 1234 , which contains Disk Group Tiers.
symfast -sid 1234 list -association -demand -sg MySg	Shows the Tier usage of devices in MySG.
symfast -sid 1234 create -name F_Policy1	Create a FAST Policy "F_Policy1" in array 1234
symfast -sid 1234 create -name F_Policy1 -tier_name Tier0 -max_sg_percent 60	Create a FAST Policy "F_Policy1" in array 1234 and add tier "Tier0" with a capacity of 30% of a storage group.
symfast -sid 1234 -fp -fp_name F_Policy1 add -tier_name Tier2 -max_sg_percent 30	Add a Tier "Tier2" to an existing Policy "F_Policy1" with 30% SG Capacity.
symfast -sid 1234 -fp -fp_name F_Policy1 modify -tier_name Tier2 -max_sg_percent 20	Modify the limit of the tier capacity available to a storage group to 20%.
symfast -sid 1234 -fp -fp_name F_Policy1 remove -tier_name Tier2	Remove the tier "Tier2" from the associated policy "F_Policy1"
symfast -sid 1234 -fp -fp_name Tier2 rename -name Tier2_New	Rename the FAST Policy "Tier2" to "Tier2_New"

symfast -sid 1234 -fp -fp_name F_Policy1 delete	Delete the FAST Policy "F_Policy1". This policy should not be associated with any Storage Groups.
symfast -sid 1234 -fp -fp_name F_Policy1 delete -force	Delete the FAST Policy "F_Policy1" which has tiers on it. This policy should not be associated with any Storage Groups.
symfast -sid 1234 -fp_name F_Policy1 associate -sg MySg -priority 2	Associate Storage Group "MySg" with FAST Policy "F_Policy1" and assign priority 2.
symfast -sid 1234 -fp_name F_Policy1 disassociate -sg MySg	Disassociate Storage Group "MySg" from FAST Policy "F_Policy1".
symfast -sid 1234 -fp_name F_Policy1 modify -sg MySg -priority 1	Change the priority of "MySg" in policy "F_Policy1" to 1
symfast -sid 1234 list -state	Displays the state of both Disk Provisioning(DP) and Virtual Provisioning(VP) FAST Controller.
symfast -sid 1234 enable -vp	Enable FAST controller for disk group provisioning.
symfast -sid 1234 enable -dp	Enable FAST controller for Virtual Pool provisioning.
symfast -sid 1234 disable -vp	Disable FAST controller for disk group provisioning.
symfast -sid 1234 disable -dp	Disable FAST controller for Virtual Pool provisioning.
symgate	
symgate list	Lists all Gatekeeper devices in the local host.
symgate -sid 1234 define dev 00AA	Define the symdev 00AA as Gatekeeper Device.
syminq	
syminq	Lists all physical devices attached to local host.
syminq hba	Shows the HBA details of the local host like HBA Name , WWN etc..
syminq -mapinfo	Lists all physical devices with target ports which are mapped.
syminq -symmids	List the local devices along with the serial number of corresponding array.
syminq -wwn	Lists all physical devices with its corresponding WWNs attached to local host.
symld	
symld -g mydg -sid 1234 add dev ABC DEV006	Add the RDF device ABC to device group mydg as DEV006
symld -g mydg remove DEV006	Remove DEV006 form device group mydg.

<code>symld -g mydg -sid 1234 addall -range AAA:AAC,AAF</code>	Add multiple devices to DG "mydg"
<code>symld -g mydg -sid 1234 rmall -range AAA:AAC,AAF</code>	Remove multiple devices from DG "mydg"
<code>symld -g mydg rename DEV001 DEV002</code>	Rename the logical dev DEV001 to DEV002 in DG mydg.
<code>symld -g mydg -sid 1234 addall -devs AAA:AAC,AAF</code>	Add multiple devices to DG "mydg"
<code>symld -g mydg -sid 1234 rmall -devs AAA:AAC,AAF</code>	Remove multiple devices from DG "mydg"
symlmf	
<code>symlmf list -type se</code>	List the Tradition Solution Enabler License.
<code>symlmf add -type se -license FFFF-FFFF-FFFF-FFFF</code>	Register the Tradition Solution Enabler License key FFFF-FFFF-FFFF-FFFF.
<code>symlmf delete -type se -license FFFF-FFFF-FFFF-FFFF</code>	Delete the Tradition Solution Enabler License key FFFF-FFFF-FFFF-FFFF.
symmask	
<code>symmask list hba</code>	List HBA details of the host.
<code>symmask -sid 1234 -dir 4a -p 0 list logins</code>	List out wwns logged through port 4a0 .
<code>symmask -sid 1234 list logins -wwn xxx</code>	Check whether wwn xxx logged in to any of the FAs on array 1234.
<code>symmask -sid 1234 delete -logins -wwn xxx</code>	Delete the login history of wwn xxx from all FA logged ports.
<code>symmask -sid 1234 refresh</code>	Refresh the VCM Data Base after a masking and unmasking operation.
<code>symmask -sid 1234 -wwn xxxx -dir 4a -p 0 add devs ABC,ABD</code>	Mask the devices ABC and ABD to given wwn in 1234 array .
<code>symmask -sid 1234 -wwn xxxx -dir 4a -p 0 remove devs ABC,ABD</code>	Unmask the devices ABC and ABD from given wwn in 1234 array .
<code>symmask -sid 1234 -wwn xxxx replace yyyy</code>	Replace all occurrence of wwn xxxx with yyyy in array 1234.
<code>symmask -sid 1234 -wwn 1000000000000001 rename Host1/HBA01</code>	Create/Rename Node Name(Host1) and Portname(HBA01) in VCMDB for given WWN.
symmaskdb	
<code>symmaskdb -sid 1234 -dev ABC list assign</code>	List the masking details of the dev ABC .
<code>symmaskdb -sid 1234 -wwn xxxxxxx list devs</code>	List the devices masked to given wwn number .
<code>symmaskdb -sid 1234 -awwn hba_alias list devs</code>	List the devices masked to given alias hba name .

symmaskdb -sid 1234 list database -v	Lists the detailed VCMDB database which includes all the FA ports , the WWN associated with it and the devices masked to those. Also shows the flag status like "Visibility", " Lun Offset" ect ..
symmir	
symmir -g TestDg establish -full	Establish the relationship between the standard and BCV devices in Device Group TestDg.
symmir -g TestDg split	Split the pair in device group TestDg
symmir -g TestDg cancel	Terminate the relationship between the standard and BCV devices in device group TestDg.
symmir -sid 1234 -g TestDg attach DEV001 BCV Id BCV001	Attach the standard device in DG TestDg with the BCV device BCV001. This will become the preferred BCV device to be paired with the standard device when a full establish or full restore action is issued.
symmir -sid 1234 -g TestDg detach DEV001 BCV Id BCV001	Detach the standard device DEV001 in the TestDg from the BCV device BCV001.
symmir -g TestDg query	Query the device Group TestDg
symqos	
symqos -sid 1234 list	List the Background copy priority of devices in array 1234.
symqos -g MyRDFDg list	Shows all the devices in MyRDFDg along with background copy priority for each devices.
symqos -g MyRDFDg set RDF pace URGENT	Set the background copy priority of the devices in MyRDFDg to the maximum.
symqos -g MyRDFDg set RDF pace STOP	Stop the background initiated copy of the devices in MyRDFDg.
symqos -g MyRDFDg set RDF pace 8	Set the background copy priority of the devices in MyRDFDg to priority 8. priority can be set between 0(Fastest) to 16(Slowest).
symqos -sid 1234 list -devs AAA:BBB,EEE	Lists the background copy priorities(CLONE,BCV,RDF etc) of devices.
symqos -sid 1234 set RDF pace 8 -devs AAA:BBB,EEE	Set the background copy priority of the given RDF devices to priority 8. priority can be set between 0(Fastest) to 16(Slowest).
symrdf	
symrdf -sid 1234 -rdg 3 -type rdf1 -file rdf.txt -g mydg createpair -establish	Establish the SRDF relation between the devices given in the file rdf.txt from array 1234(R1) and remote box according to the rdf group .This command start sync between R1 and R2 and also add these devices after creating the device group mydg
symrdf -sid 1234 -rdg 3 -file rdf.txt query	Query the Devices by using device pair file.
symrdf -g mydg query	Query device group.

<code>symrdf -g mydg split</code>	Split the srdf pair for devices given in mydg.
<code>symrdf -sid 1234 -rdfg 3 -file rdf.txt deletepair -force</code>	Delete the srdf pairing between R1/R2 and return them to stanadard.
<code>symrdf -sid 1234 -rdfg 3 -file rdf_pair.txt query -i 5</code>	Queries the pair devices mentioned in the pairfile "rdf_pair.txt" in every 5 seconds.This command also shows the estimated time to sync up all the devices if those are currently in "sync in progress" state.
<code>symrdf -sid 1234 -rdfg 3 -file rdf.txt movepair -new_rdfg 4</code>	Moves the SRDF devices from rdf group 3 to 4.We need to split the pair before doing this operation.
<code>symrdf -sid 1234 -rdfg 3 -file rdf.txt set mode acp_disk</code>	Change the current SRDF mode of the pair file devices to Adaptive disk mode.
<code>symrdf -g mydg establish -full</code>	Establish a full copy on the devices in MyDg
<code>symrdf -sid 1234 -rdfg 3 -file rdf.txt set mode sync</code>	Change the current SRDF mode of the pair file devices to Synchronous
<code>symrdf -sid 1234 list -rdfg all</code>	This command will list all the SRDF devices in all rdf groups.
<code>symrdf -sid 000000001234 -label dynagrp150 -dir 3h,4h,13h,14h -rdfg 100 -remote_sid 000000005678 -remote_dir 7h,8h,9h,10h -remote_rdfg 100 addgrp</code>	This command will create a dynamic rdf group 150 from array 1234(RA Port- 3h,4h,13h,14h ->5678(RA Port 7h,8h,9h,10h) with label 'dynagrp150'.
<code>symrdf -sid 1234 removegrp -rdfg 100</code>	Remove dynamic RA group 100 from array 1234.
<code>symrdf -sid 1234 ping</code>	Ping the array 1234 through SRDF links and check the links are up and and running.
<code>symrdf -sid 1234 -rdfg 3 -file rdf.txt set mode acp_wp</code>	Change the current SRDF mode of the pair file devices to Adaptive Copy write pending mode.
<code>symrdf -sid 1234 list -dynamic -both</code>	Lists the SRDF swappable devices in array 1234.
<code>symrdf -sid 1234 list -concurrent</code>	Lists all the RDF devices in array 1234 as part of a concurrent SRDF setup(both R1 and R2).
<code>symrdf -sid 1234 list -diskless_rdf</code>	View all the diskless rdf devices(DLDEV) in array 1234.
<code>symrdf -sid 1234 -rdfg 3 -type rdf1 -file rdf.txt createpair -invalidate R2</code>	Establish the SRDF relation between the devices given in the file rdf.txt from array 1234(R1) and remote box according to the rdf group .This command can be used to just create the pair without starting the data copy from R1 to R2 .
<code>symrdf -sid 1234 -rdfg 3 -type rdf1 -file rdf.txt createpair -establish -rdf_mode sync</code>	Establish the SRDF relation between the devices given in the file rdf.txt from array 1234(R1) and remote box according to the rdf group .This command start copying between R1 and R2 in SYNC mode.(default is acp_disk mode)
<code>symrdf -sid 1234 -rdfg 3 -type rdf1 -file rdf.txt establish -full</code>	This command start full copy from R1 to R2 devices. The SRDF pairs are already created .
<code>symrdf -sid 1234 -rdfg 3 -type rdf1 -file rdf.txt suspend</code>	Suspend the replication from R1 to R2 devices.R1 will be in R/W, R2 in W/D and link will be in NR state.

<code>symrdf -sid 1234 -rdfg 3 -type rdf1 -file rdf.txt resume</code>	Resume the suspend the replication from R1 to R2 devices.R1 will be in R/W, R2 in W/D and link will be in ready state.
<code>symrdf -sid 1234 -rdfg 3 -type rdf1 -file rdf.txt split</code>	Split the R1 and R2 devices by stopping the replication. This will make R2 also in Read/Write mode along with R1 . The link will go to NotReady(NR) state.
<code>symrdf -sid 1234 -rdfg 3 -type rdf1 -file rdf.txt failover</code>	This will make the R1 devices Write Disabled , R2 Write Enabled to host , and logical connections between R1 to R2 in to Not Ready state.
symsg	
<code>symsg -sid 1234 list</code>	Lists all the storage groups in Vmax array 1234 along with informations like whether the SG a member of Masking View and is a part of FAST Policy.
<code>symsg -sid 1234 list -v</code>	the -v options displays the member devices of Storage Groups along with other details given by list.
<code>symsg -sid 1234 create MyStorageGroup</code>	Create a new SG,'MySrorageGroup' in Vmax Array 1234
<code>symsg -sid 1234 delete MyStorageGroup</code>	Deletes the empty SG 'MySrorageGroup' from 1234.The SG should not be associated with any Masking View.
<code>symsg -sid 1234 delete MySrorageGroup -force</code>	Deletes the SG 'MySrorageGroup' which contains devices but not associated with any Masking View.
<code>symsg -sid 1234 show MyStorageGroup</code>	Shows the devices in MyStorageGroup along with its Masking View and FAST Policy association status.
<code>symsg -sid 1234 export MyStorageGroup -file mystoragegroup.txt</code>	export the device information from SG to the text file.
<code>symsg -sid 1234 exportall -storagegroups.txt</code>	exports the device information from all the SGs from 1234 array to the text file storagegroups.txt
<code>symsg -sid 1234 import MyStorageGroup -file MystorageGroup.txt</code>	Create SG 'MyStorageGroup' from the earlier exported file MystorageGroup.txt.
<code>symsg -sid 1234 importall -file MystorageGroups.txt</code>	Create storage groups from the earlier exported file MystorageGroup.txt.Storage Group names will be created according to the names in text file.
<code>symsg -sid 1234 rename MyStorageGroup MyNewStorageGroup</code>	Rename SG MyStorageGroup to MyNewStorageGroup
<code>symsg -sid 1234 -sg MyStorageGroup ready</code>	Set the status of all devices in SG 'MyStorageGroup' to READY.
<code>symsg -sid 1234 -sg MyStorageGroup not_ready</code>	Change the status of all the devices in SG 'MyStorageGroup' from READY to NOT READY.
<code>symsg -sid 1234 -sg MyStorageGroup rw_enable</code>	Write enable all the devices in SG 'MyStorageGroup'
<code>symsg -sid 1234 -sg MyStorageGroup write_disable</code>	Write Disable all the devices in SG 'MyStorageGroup'

<code>symmsg -sid 1234 -sg MyStorageGroup add dev AAAA</code>	Add a single device to MyStorageGroup
<code>symmsg -sid 1234 -sg MyStorageGroup remove dev AAAA</code>	Remove a single device from MyStorageGroup
<code>symmsg -sid 1234 -sg MyStorageGroup addall devs -dev AAAA:AAAF,BBBB</code>	Add more than one devices to MyStorageGroup.
<code>symmsg -sid 1234 -sg MyStorageGroup rmall devs -dev AAAA:AAAF,BBBB</code>	Remove more than one devices from MyStorageGroup.
<code>symmsg -sid 1234 -sg MyStorageGroup add sg ChildSG1,ChildSG2,ChildSG3</code>	Add child Storage Groups to the parent SG MyStorageGroup.
<code>symmsg -sid 1234 -sg MyStorageGroup remove sg ChildSG1,ChildSG2,ChildSG3</code>	Remove child Storage Groups from the parent SG MyStorageGroup.
<code>symmsg -sid 1234 -sg MyStorageGroup set -bw_max 500</code>	Set the maximum HOST I/O limit in MB per second to maximum 500MB/s for MyStorageGroup .(can be set from from 1 to 100000 MB/s)
<code>symmsg -sid 1234 -sg MyStorageGroup set -bw_max NOLIMIT</code>	Set the maximum HOST I/O limit in MB per second to UNLIMITED MB/s for MyStorageGroup .
<code>symmsg -sid 1234 -sg MyStorageGroup set -iops_max 1000</code>	Set the maximum HOST I/O limit in I/O per second to maximum 1000 IO/second for MyStorageGroup .(can be set from 100 to 100000 IO/sec)
<code>symmsg -sid 1234 -sg MyStorageGroup set -iops_max NOLIMIT</code>	Set the maximum HOST I/O limit in I/O per second to UNLIMITED IO/second for MyStorageGroup .
<code>symmsg -sid 1234 sg2dg MyStorageGroup MyDg -R1</code>	Create a new device group MyDg which contains all the RDF1 devices from Storage Group MyStorageGroup.
symstat	
<code>symstat -sid 1234 list -dev AAAB -i 5</code>	Displays the I/O statistics for device AAAB, in an interval of 5 seconds.
symtier	
<code>symtier -sid 1234 list</code>	Lists all the storage tiers in array 1234.(both DiskGroup(DP) and Virtual Pool(VP) Tiers)
<code>symtier -sid 1234 list -vp</code>	Lists only VirtualPool(Thin Pool) provisioned Tiers.
<code>symtier -sid 1234 list -dp</code>	Lists only DiskGroup provisioned Tiers.
<code>symtier -sid 1234 create -name Tier1 -inc_type static -tgt_raid5 -tgt_prot 3+1 -technology EFD -dsk_grp 1</code>	Create Diskrroup Povisioned(DP) tier named "Tier1" from disk_group 1 of type RAID-5.The type of the disk in disk_group 1 is EFD.
<code>symtier -sid 234 create -name Tier3 -tgt_raid5 -tgt_prot 3+1 -technology SATA -vp -pool TP3_2000GB</code>	Create a Virtual Provisioned(VP) tier named "Tier3" from Thin Pool TP3_2000GB of type RAID-5(3+1)
<code>symtier -sid 1234 -tier_name Tier1 add -dsk_grp 3</code>	Add disk_group 3 to the existing Storage Tier "Tier1".
<code>symtier -sid 1234 -tier_name Tier1 remove -dsk_grp 3</code>	Remove disk_group 3 from the existing Storage Tier "Tier1".

<code>symtier -sid 1234 -tier_name Tier3 add -pool TP3_1000GB</code>	Add thin pool TP3_1000GB to the existing Storage Tier "Tier3".TP3_1000GB should not be included in any other Tier.
<code>symtier -sid 1234 -tier_name Tier3 remove -pool TP3_1000GB</code>	Remove thin pool TP3_1000GB to the existing Storage Tier "Tier3".We cannot remove all thin pools from a VP tier if the tier is part of a FAST policy. And also, we cannot remove a pool from a tier if the tier is in an associated policy,and a device in the storage group is bound to the pool.
<code>symtier -sid 1234 rename -tier_name Tier0 -name Tier0_New</code>	Rename tier "Tier0" to "Tier0_New".
<code>symtier -sid 1234 delete -tier_name Tier0</code>	Delete tier "Tier0" .
<code>symtier -sid 1234 delete -tier_name Tier2 -force</code>	Delete non-empty static DP tier "Tier2"
<code>symtier -sid 1234 show -tier_name Tier0</code>	Displays detailed information about tier "Tier0".