# EXAMPLE CORPORATION

# EC-M1ED

## PRODUCT GUIDE

Front-Load Electric Dryer with ExCorText™




sunshynelabs.com

Copyright © 2026 Sunshyne Labs. All Rights Reserved

## In this guide


| | |
|---|---|
| Welcome | 1 |
| Important Safety Instructions | 2 |
| Know Your Dryer | 4 |
| Controls & Display | 5 |
| Cycles | 6 |
| Temperature & Dryness Settings | 7 |
| Operating The Dryer | 8 |
| When The Cycle Ends | 9 |
| ExCorText™ and SMS alerts | 10 |
| Understanding ExCorText™ Messages | 11 |
| Care & Maintenance | 12 |
| Scheduled Maintenance | 13 |
| Troubleshooting | 14 |
| Safety & Error Codes | 15 |
| Installation Requirements | 16 |
| Exhaust & Ventilation | 17 |
| Electrical & Steam Connections | 18 |
| Installation Handover & First Operation | 19 |
| Limited Warranty | 20 |
| Service Providers | 21 |
| A Few Rules Worth Remembering | 23 |

01 / GETTING STARTED

# Welcome

Your EC-M1ED combines a large-capacity electric drying drum with ExCorText™, an onboard system that learns operating patterns, adapts drying recommendations, and reports selected status and maintenance information by SMS. The system performs its core analysis locally; an internet connection is not required.

Use this manual to prepare loads, select cycles, operate the controls, care for the dryer, understand status messages, and identify when service is necessary.

## Keep these points in mind

- Clean and correctly seat the lint filter before every load.
- Use only a metal exhaust duct that vents outdoors. Keep the duct short and unobstructed.
- Follow each garment care label. The garment label takes priority over a general cycle recommendation.
- Do not change the installed power mode or open the electrical cabinet. Power connections and mode commissioning require qualified personnel.
- Stop using the dryer when a critical ventilation, temperature, door-latch, or mechanical fault appears.

## Quick Start

| STEP | ACTION |
|---|---|
| **Prepare** | Sort by fabric and care label. Empty pockets. Remove items contaminated with flammable substances. |
| **Filter** | Clean the lint filter and make sure it is fully seated. |
| **Load** | Place items loosely in the drum. Do not pack or overload it. |
| **Select** | Turn the selector to a cycle. Use the LCD prompts to choose temperature and dryness level where available. |
| **Start** | Close the door and press the dial. Confirm that the cycle status appears on the LCD. |
| **Finish** | Wait for CYCLE COMPLETE. Remove the load, then clean the lint filter before the next load. |

02 / SAFETY

# Important Safety Instructions

**WARNING: FIRE AND ELECTRIC SHOCK HAZARD**

Read all safety instructions before using the dryer. Failure to follow these instructions can result in fire, electric shock, serious injury, or death.

## Installation and electrical safety

- Have the dryer installed, grounded, and commissioned by qualified personnel in accordance with local electrical and building codes.
- Use only the supply mode and circuit specified on the appliance rating label and installation record. Do not connect the dryer to an unapproved outlet, inverter, generator, or direct photovoltaic source.
- Do not cut, remove, or defeat the grounding connection. Do not use an extension cord or multi-outlet adapter.
- Disconnect the electrical supply before moving, servicing, or cleaning inside any access panel. Internal service is for qualified personnel only.
- Do not install the dryer where it can be exposed to standing water, outdoor weather, or freezing conditions.
- Move the dryer with two or more people using suitable lifting equipment. The appliance is heavy; do not lift it by the door or selector.

## Safe use

- Do not dry articles that have been cleaned, soaked, or spotted with gasoline, solvents, waxes, oils, or other flammable substances unless the care label and product instructions expressly permit tumble drying after the required preparation.
- Do not dry foam rubber, rubber-backed items, plastic, or other heat-sensitive materials unless the item label specifically permits the selected cycle.
- Do not put animals in the drum. Keep children away from the door and controls. Do not allow anyone to climb, sit, or hang on the door.
- Do not reach into a moving drum. Wait until the drum stops before removing or rearranging laundry.
- Never operate the dryer with a damaged cord, missing parts, a damaged door, a failed latch, or a removed protective panel.
- Do not bypass the door latch, temperature protection, ventilation sensor, or any safety feature.

## Laundry and fire prevention

- Remove lighters, matches, batteries, pens, coins, and other objects from pockets before drying.
- Keep lint, paper, rags, cleaning products, and other combustible materials away from the dryer and exhaust opening.
- Clean the lint filter before every load. Lint accumulation reduces airflow and increases fire risk.
- Do not operate the dryer if the exhaust duct is disconnected, crushed, blocked, or routed into an attic, crawl space, wall cavity, or other enclosed space. Exhaust air must discharge outdoors.
- Do not use plastic duct, thin foil duct, or a duct containing screws or fasteners that project into the airflow path.
- Do not leave a heat-producing cycle running unattended when the load contains items with unusual odor, residue, or unknown care instructions.

## If you notice smoke, unusual heat, or a burning odor

1. Stop the cycle if it is safe to do so. Keep clear of smoke or hot surfaces.
2. Disconnect power only if you can do so without exposure to danger. Do not open the cabinet or reach behind a hot appliance.
3. If there is an active fire, leave the area and contact emergency services. Do not use the dryer again until it has been inspected by qualified service personnel.

## Steam cycle precautions

- The Decontaminate cycle uses steam and elevated temperature. Use it only for fabrics that tolerate the cycle and are marked for suitable machine care.
- Do not touch the door glass or metal surfaces immediately after a steam cycle. Allow the dryer to complete its cool-down phase.
- Do not open a water connection, steam passage, or service panel. Steam-system inspection and repair require qualified service.

**SAVE THESE INSTRUCTIONS**

Keep this manual near the dryer. Make sure every person who uses the appliance understands the basic safety rules and knows how to respond to a warning.

03 / PRODUCT OVERVIEW

# Know Your Dryer

The EC-M1ED has a front-loading 7.4 cu. ft. drum, contextual LCD, mechanical clickable rotary selector, and touch-sensitive panel controls. The available LCD options change according to the selected cycle and operating state.

## Main Components

| COMPONENT | PURPOSE |
|---|---|
| **Menu** | Displays the selected cycle, available settings, drying status, time information, messages, and ExCorText™ prompts. |
| **Clickable rotary selector** | Selects a cycle or adjusts an option shown on the LCD. |
| **Loading door and latch** | Provides access to the drum. The dryer will not start unless the door is latched. |
| **Lint filter** | Captures lint from the load. Clean and seat it before every load. |
| **Exhaust outlet** | Connects to the metal duct that carries moist air outdoors. |
| **Leveling legs** | Adjust the appliance so it stands level and stable. |
| **Steam inlet** | Supplies water for the Decontaminate steam function. |

## Product Specifications

| ITEM | SPECIFICATION |
|---|---|
| **Model** | EC-M1ED |
| **Appliance type** | Front-load electric dryer |
| **Drum capacity** | 7.4 cu. ft. |
| **Dimensions (W × H × D)** | 27 × 39 × 30 1/8 in. |
| **Depth with door open** | 51 3/8 in. |
| **Approximate net weight** | 172.3 lb |
| **Cabinet finish** | Gunmetal Gray |
| **Grid Mode** | 240 V, 30 A |
| **Solar Mode** | 120 V, 20 A; approved EC solar-compatible installation required |
| **Exhaust** | 4 in. (102 mm) metal duct to outdoors |

# Controls & Display

| DISPLAY / CONTROL | MEANING |
|---|---|
| **Normal / Heavy / Delicate / Manual** | Direct cycle selections printed around the selector. |
| **Bed & Bath / Suits / Adaptive / Custom** | Additional cycles available through the contextual menu or by texting the dryer. |
| **Sahara** | Extra-dry finish. Use for compatible heavy cottons and items that need additional drying. |
| **Venice** | Standard dry finish for everyday loads. |
| **Everglades** | Damp finish for items intended for ironing or immediate air finishing. |
| **Decontaminate** | Steam-assisted high-temperature cycle for compatible items. |
| **High / Medium / Low** | Heat settings. Choose according to the care label and cycle guidance. |
| **Aerate** | Unheated tumbling and airflow. |
| **Marcus Mode** | Control lock. The bearded-man symbol appears while the lock is active. |
| **Filter Missing** | Lint filter is absent or not seated correctly. |
| **TPI** | Temporal Plasticity Indicator: Adaptive Dry phase and estimated-time display. The estimate can change as the load is evaluated. |
| **RP** | Refractory Period: final unheated cool-down tumble. |
| **DCI** | Divine Comedy Indicator: the steam profile is configured for bulky bedding. |
| **Cycle Complete** | The cycle has finished and the drum has stopped. |
| **OK Mode** | Ouroboric Kernel Mode: Self-check diagnostic state. If it remains displayed after the normal restart procedure, contact service. |

## Marcus Mode

To lock the controls, press and hold the bearded-man symbol for 3 seconds, or text the dryer to lock the panel. The symbol remains illuminated while the lock is active. Repeat the same action to unlock. The door can still be opened for safety; opening the door pauses operation.

## Door and pause behavior

Opening the door pauses drum rotation and heating. Close the door and press the dial to resume. If the LCD displays a fault or a critical ventilation warning, follow the troubleshooting instructions instead of repeatedly restarting the cycle.

04 / CYCLES AND SETTINGS

# Cycles

Choose a cycle that matches the fabric, load size, and garment care label. Do not mix items that require substantially different temperatures or drying times.

| CYCLE | USE | GUIDANCE |
|---|---|---|
| **Normal** | Everyday cottons, linens, shirts, and compatible mixed loads. | Use Venice for most loads. Use Sahara for heavier cottons. Reduce the load size when items tangle or dry unevenly. |
| **Heavy** | Jeans, workwear, towels, and other sturdy, heavier items. | Allow space for tumbling. Heavy items may need more time than lightweight pieces. |
| **Delicate** | Heat-sensitive garments labeled for tumble drying. | Use Low or Aerate where appropriate. Do not use for dry-clean-only items or items whose labels prohibit tumble drying. |
| **Manual Dry** | A fixed drying period selected by the user. | Available times: 5, 10, 20, 30, 40, 50, or 60 minutes. Check the load before adding more time. |
| **Bed & Bath** | Compatible sheets, pillowcases, towels, and bedding. | Request cycle from dryer. Load bulky items loosely. Dry similar fabrics together and avoid overloading. |
| **Suits** | Washable suit separates and structured garments labeled for tumble drying. | Request cycle from dryer. Use the recommended low-heat profile. Do not use for dry-clean-only garments. |
| **Adaptive Cycle** | ExCorText™ selects a drying profile using prior usage and current cycle information. | Review the LCD recommendation before starting. Follow the garment label when the agent conflicts with a suggested setting. |
| **Custom** | A user-selected combination of cycle settings which can be communicated and requested from the dryer via SMS. | Review temperature, dryness level, and duration before pressing the dial. |

### LOAD SIZE MATTERS

Laundry must tumble freely. An overloaded drum of over 60% capacity can increase drying time, create uneven results, and cause excessive wrinkling. Separate very large items from small lightweight items.

# Temperature & Dryness Settings

| SETTING | BEST FOR | NOTES |
|---|---|---|
| **Decontaminate (Steam)** | Medical uniforms or compatible items requiring the steam-assisted high-temperature profile. | Requires the installed steam-water supply. Check fabric care labels. Do not use on heat-sensitive or steam-prohibited materials. |
| **High** | Durable cottons and heavy items that permit high heat. | Do not use for delicate fabrics, elastic, or items that may shrink. |
| **Medium** | Most everyday mixed loads and durable synthetics that permit tumble drying. | Use the garment label to confirm heat suitability. |
| **Low** | Delicates and items that require reduced heat. | May require more time than High. |
| **Aerate** | Freshening and airing items that do not require heat. | Airflow only; this setting does not provide heat-based drying or sanitation. |

## Dryness Levels

| LEVEL | RESULT | SUGGESTED USE |
|---|---|---|
| **Sahara** | Extra dry | Heavy cottons, towels, and items that need additional dryness. |
| **Venice** | Standard dry | Everyday loads. Begin here for most compatible fabrics. |
| **Everglades** | Damp dry | Items intended for ironing or a short finishing period on a hanger. |

## Load preparation

- Sort items by fabric type, weight, and care label. Dry similar loads together.
- Close zippers, fasten hooks, tie loose strings, and turn delicate or printed items inside out when appropriate.
- Shake out each item before loading. Place large items loosely in the drum so air can circulate.
- Do not add wet items that contain solvent, oil, or cleaning-product residue.
- Remove items promptly when the cycle ends to reduce wrinkling. Use the final cool-down phase before unloading hot items.

05 / EVERYDAY USE

# Operating The Dryer

## Before Every Load

- ☐ Check garment labels and remove all objects from pockets.
- ☐ Clean the lint filter and seat it fully in the filter housing.
- ☐ Check that the drum is clear of foreign objects and that the door seal is clean.
- ☐ Confirm that the exhaust outlet is not visibly obstructed and that the room is adequately ventilated.
- ☐ Load garments loosely and close the door until the latch engages.

## Start a Cycle

1. Turn the rotary selector to the required cycle. The LCD shows the cycle name and available options.
2. Use the contextual menu to choose temperature, dryness level, or Manual Dry time as appropriate.
3. Press the dial. The dryer checks the door, lint-filter status, power mode, and operating conditions before beginning.
4. Watch the display during the first few minutes. If a safety message appears, follow its instructions, or consult with ExCorText™ via SMS before continuing.

## Pause, resume, or cancel

| ACTION | WHAT HAPPENS |
|---|---|
| **Open the door** | Heating and drum rotation stop. Wait for the drum to stop before reaching inside. |
| **Resume** | Close the door and press the dial. The dryer resumes if no fault or safety lockout is active. |
| **Cancel** | Press and hold the dial for 3 seconds, then confirm CANCEL on the LCD. If a safety fault is active, the dryer may require service before another cycle can start. |
| **Power interruption** | Heating stops. ExCorText™ preserves cycle status; the internal reserve can support control and drum functions briefly. Restart only after stable power is restored and the LCD permits operation. |

# When The Cycle Ends

1. Wait for CYCLE COMPLETE. The final RP phase is an unheated cool-down tumble, normally lasting about 120 seconds.
2. Open the door after the drum stops. Be careful when removing warm items, especially after Decontaminate.
3. Remove the load and clean the lint filter before the next load.
4. If items remain damp, check sorting, load size, and the selected dryness level. Do not repeatedly run additional cycles when a ventilation alert is displayed.

## Using Decontaminate

- Use only on fabrics whose care labels allow the high-temperature steam profile.
- Confirm that the steam-water supply is connected and that no water-supply warning is displayed.
- Select Decontaminate and choose the compatible load profile shown on the LCD. Use DCI for bulky bedding only when the display offers that option.
- Keep clear of the door during operation. Allow the full cool-down period to finish before unloading.
- The cycle is not suitable for every fabric and does not replace garment-care instructions.

## Bulky Bedding

For comforters and blankets, use Bed & Bath or the Decontaminate bulky profile when the item label permits it. Load one bulky item at a time when needed to preserve free tumbling. Stop and redistribute the load if the drum cannot turn freely.

**DO NOT FORCE A CYCLE TO CONTINUE**

If the dryer stops because of a door, temperature, airflow, or power fault, correct only the owner-level condition described in this manual. Do not bypass a safety feature or force the cycle to restart.

06 / EXCORTEXT

# ExCorText™ and SMS alerts

ExCorText™ is the EC-M1ED onboard telemetry system and local conversational agent. It processes operating information locally, identifies patterns in heat, airflow, and cycle behavior, recommends adaptive settings, and sends maintenance or diagnostic findings to customers or field operators via SMS.

| FEATURE | HOW IT WORKS |
|---|---|
| **Local Telemetry** | Core pattern detection and cycle recommendations run on the appliance. Internet access is not required for these functions. |
| **Adaptive Cycle** | Uses prior usage and current operating information to recommend a drying profile and adjust cycle time and temperature. This can be changed by prompting the dryer. |
| **TPI Display** | Shows the current adaptive drying phase and estimated remaining time. The estimate can move up or down as the load is evaluated. |
| **SMS Alerts** | Uses compatible 2G GSM service to send cycle status, ventilation warnings, maintenance reminders, and selected troubleshooting guidance. |
| **Power interruption** | The dryer stops heating when external power is lost. The internal reserve supports limited drum/control continuity; it does not provide full heated drying during an outage. |
| **Network interruption** | Local controls and onboard analysis continue to operate when cellular service is unavailable. SMS messages may be delayed or not delivered. |

## SMS Prompts & Conversational Examples

SMS features are available only after an authorized telephone number has been paired with the dryer. Messages are not a substitute for checking the appliance display or following a safety warning.

| MESSAGE | FUNCTION | DESCRIPTION & LIMIT |
|---|---|---|
| ***"Check your status/send me a report"*** | Returns selected cycle, current state, remaining-time estimate, and active warnings. | Available when compatible 2G/3G GSM service is available. |
| ***"Check the vents"*** | Returns the latest ventilation status. | Does not replace physical filter care or exhaust inspection. |
| ***"Use Normal/Heavy/Delicate"*** | Selects the requested cycle while the dryer is idle. | Does not start a heat-producing cycle remotely. |
| ***"Set it up this way, [describe custom cycle]"*** | Selects an available cycle while idle. | The dryer confirms the final selection and required options via SMS. |
| ***"Stop/Cancel/Quit dryer"*** | Requests cancellation of the active cycle. | The dryer follows its local safety sequence; a physical inspection may still be required. |

**REMOTE COMMAND SAFETY**

SMS conversations cannot bypass the door latch, clear a critical safety lockout, energize the heater from an unsafe state, or while in OK Mode.

# Understanding ExCorText™ Messages

## Message Delivery

- SMS delivery depends on a compatible GSM network and may be delayed by signal conditions or carrier service.
- If a message is not received, check the appliance LCD first. Do not assume the dryer has stopped or completed a cycle because an SMS has not been sent.
- Only pair a telephone number controlled by an authorized user. Keep the paired cellular handset secure and remove authorization before transferring ownership of the dryer.
- Do not send personal, financial, or unrelated sensitive information to the dryer. SMS is intended for appliance status and operating commands.

## Ventilation Alerts & Safety Codes

The dryer monitors airflow and may display one of four Check Ventilation safety codes. The levels indicate increasing restriction. Clean the lint filter first when prompted by the dryer; inspect only accessible exterior areas. Do not disconnect the duct, remove panels, or attempt to reach internal sensors.

For personalized technical assistance and installation, communicate with the dryer via SMS for complete guidance throughout the process.

| SAFETY CODE | OBSTRUCTION LEVEL | RESPONSE |
|---|---|---|
| **CV-I / Indication** | **65%** | Clean the lint filter. Check the accessible exterior vent hood for an obvious obstruction. Monitor the next cycle. |
| **CV-II / Caution** | **76%** | The dryer reduces or stops heating as needed. Clean the filter and do not continue if the warning remains. Arrange exhaust inspection if it returns. |
| **CV-III / Warning** | **87%** | Heating is stopped and the dryer enters cool-down. Do not restart until the filter and accessible exterior vent area have been checked. If the warning returns, request qualified vent service. |
| **CV-IV / Critical** | **98%** | The cycle has stopped. Leave the dryer out of use and arrange qualified vent inspection before using it again. |

## Local Operation & Privacy

ExCorText™ performs its primary analysis on the appliance via local telemetry inference, and is capable of sending alerts to both customers and field operators. SMS communication requires cellular service. Cycle history, telemetry, diagnostics and chat history is used to improve adaptive recommendations, and is never shared elsewhere outside the dryer once stored.

Customers can request this information from the dryer via SMS. For a complete data export of all logs, field operators can be requested to extract them manually from the dryer using special tools.

07 / CARE

# Care & Maintenance

## Clean the lint filter before every load

1. Open the loading door and remove the lint filter from its housing.
2. Roll lint from the filter surface with your fingers. If needed, rinse the filter with warm water and allow it to dry fully.
3. Remove lint around the filter opening with a soft brush or vacuum attachment. Do not push lint into the duct.
4. Reinstall the filter fully. The Filter Missing indicator must clear before operation.

## Clean the drum and exterior

- Wipe the drum with a soft cloth and mild household cleaner when residue is visible. Wipe again with a clean damp cloth and dry the surface.
- Use a soft damp cloth on the exterior and control panel. Do not spray cleaner directly onto the LCD, selector, or touch controls.
- Do not use abrasive pads, strong solvents, or products that may damage the finish or panel markings.
- If a garment has left wax, dye, adhesive, or other residue, remove it before the next load. Do not dry laundry while residue remains in the drum.

## Inspect the exhaust system

Inspect the accessible duct connection and exterior hood periodically. Clean the full duct system at least annually, and sooner if drying time increases, lint accumulates, or a ventilation alert appears. Long or complex exhaust routes may require more frequent cleaning. Have concealed sections inspected by qualified personnel.

**DO NOT USE THE DRYER WITH THE DUCT DISCONNECTED**

A disconnected duct can release hot, lint-laden air into the room and may create a fire hazard. Ventilation testing and internal cleaning are service tasks.

# Scheduled Maintenance

Ask the dryer to send detailed, personalized telemetry reports and SMS notifications to set reminders when maintenance is due. Simply send it a request via SMS and it will text these reminders at set schedules.

| INTERVAL | TASK | OWNER / SERVICE |
|---|---|---|
| **Before every load** | Clean the lint filter; confirm it is seated. | Owner |
| **Monthly** | Inspect the visible duct connection and exterior vent hood. Remove visible lint and debris from accessible areas. | Owner |
| **When drying time rises or CV appears** | Clean the filter and arrange exhaust inspection if the alert persists or returns. | Owner / qualified vent service |
| **At least annually** | Inspect and clean the complete exhaust path, including concealed sections. | Qualified vent service |
| **As needed** | Inspect the steam-water connection for visible leaks and verify the supply is open. Do not open the appliance. | Owner observes; qualified service repairs |
| **When a fault code recurs** | Record the code, cycle, load type, and symptoms. Do not remove panels or repeat resets. | Authorized service |

## Before a long period without use

- Clean the lint filter and drum.
- Turn the dryer off and disconnect the supply using the approved local isolator, if fitted.
- Close the steam-water shutoff valve if the dryer will remain unused for an extended period.
- Keep the appliance dry and protect it from freezing temperatures.

## After moving the dryer

Have qualified personnel reconnect the exhaust, water supply, grounding, and electrical supply. Confirm that the installed Grid or Solar Mode matches the approved power connection. Level the appliance and complete the commissioning checks before use. Send a text message to the dryer for further guidance.

## Do not perform these repairs yourself

- Opening electrical or control compartments, or replacing internal wiring.
- Repairing the heater, thermal sensors, motor, belt, idler, bearings, or door interlock.
- Changing the power mode, modifying a solar interface, or servicing the internal battery.
- Bypassing airflow, temperature, or door safety devices; entering OK Mode; or disconnecting the vent to test operation.

08 / TROUBLESHOOTING

# Troubleshooting

Check the items in this table before requesting service. If the LCD displays a code, use the code table on the next page. Do not continue operation when a critical warning or repeated fault is present.

| SYMPTOM | CHECK | NEXT ACTION |
|---|---|---|
| **Dryer does not start** | Confirm that the door is fully closed, the selected mode matches the installed supply, and the LCD is not showing Marcus Mode or a fault. | Correct a visible door or control-lock condition. If a power or door-latch fault remains, request service. |
| **Drum does not turn** | Check that the door is latched and no control lock is active. | Do not push or force the drum. If AR-X or MA-X appears, stop use and contact service. |
| **Items remain damp** | Check load size, sorting, dryness level, and lint filter. | Use a compatible cycle and clean the filter. If CV warning appears or long drying continues, arrange exhaust inspection. |
| **Cycle takes longer than expected** | Large loads, heavy fabrics, low heat, and restricted airflow increase time. | Clean the filter. Check the accessible exterior vent hood. Do not repeatedly run additional cycles when a CV warning remains. |
| **Laundry is too dry or wrinkled** | Check load size, dryness level, and cycle selection. | Use Venice instead of Sahara for ordinary loads, remove items promptly, and avoid overloading. |
| **Unusual vibration or noise** | Check whether the load is uneven. | Pause the dryer. If noise continues with a balanced load or the drum rubs, stop use and request service. |
| **Steam cycle does not run** | Check whether the water supply is open and the LCD shows a water or steam message. | Do not open the steam system. If the message persists, request service. |
| **SMS not received** | Check the appliance display and compatible GSM signal. | Local operation can continue without SMS. If the pairing or modem fault persists, request service. |
| **Panel does not respond** | Look for Marcus Mode or a displayed safety code. | Unlock using the bearded-man symbol. Do not force controls or bypass the lockout. |

# Safety & Error Codes

For personalized technical support, communicate with the dryer via SMS to receive official troubleshooting steps and diagnostic telemetry reports, and to have it guide you throughout the troubleshooting process.

| CODE | DISPLAY MEANING | OWNER ACTION |
|---|---|---|
| **CV-I** | **Check Ventilation - Indication** | Clean and reseat the lint filter. Check only the accessible exterior vent hood. Monitor the next cycle. If the alert persists or returns, arrange qualified exhaust service; see the vent providers in Section 10. |
| **CV-II** | **Check Ventilation - Caution** | Clean the filter. If the warning remains or returns, stop the cycle and arrange qualified exhaust service; see the vent providers in Section 10. |
| **CV-III** | **Check Ventilation - Warning** | Heating stops and cool-down begins. Do not restart while the warning remains or returns. Arrange qualified vent service; see the vent providers in Section 10. |
| **CV-IV** | **Check Ventilation - Critical** | The cycle stops. Leave the dryer out of use until a qualified vent field operator inspects the exhaust system; see the vent providers in Section 10. |
| **PD-E** | **Parasitic Dissipation - power supply abnormal** | Stop using the dryer. Do not reset breakers repeatedly or open the connection panel. Contact a qualified electrician to check the supply; see the electrical providers in Section 10. If the supply is normal, contact authorized EC appliance service. |
| **FR-E** | **Flux Resolution Failure - power interrupted** | Wait for stable power. If household supply interruptions or voltage instability are suspected, contact a qualified electrician; see the electrical providers in Section 10. If the household supply is stable and the fault recurs, contact authorized EC appliance service. |
| **GD-E** | **Galvanic Divergence - power mode mismatch** | Do not change the mode or wiring yourself. Have the installer or a qualified electrician verify the approved connection and mode; see the electrical providers in Section 10. |
| **TH-X** | **Temperature sensing fault** | Stop the cycle and allow the dryer to cool. Do not use it again until EC or its authorized appliance-service channel has inspected it. |
| **AR-X** | **Drum rotation failure** | Stop use. Do not force the drum or reach behind the panel. Contact EC or its authorized appliance-service channel. |
| **MA-X** | **Motor or drive communication fault** | Stop use and contact EC or its authorized appliance-service channel. |
| **AT-X** | **Sensor-data communication fault** | Stop the cycle. If the fault remains or returns, contact EC or its authorized appliance-service channel. |
| **PC-X** | **Door latch cannot be verified** | Open and close the door once. Check for trapped fabric. If the code remains, do not bypass the latch; contact EC or its authorized appliance-service channel. |
| **Filter Missing** | **Filter absent or not seated** | Turn the dryer off. Fit the lint filter correctly before restarting. |
| **OK Mode** | **Self-check state** | If the display clears and normal operation resumes, continue. If it remains, contact service. |

**SAFETY RULE**

A displayed code is not permission to open the cabinet or perform an internal repair. If the table instructs you to stop, leave the dryer out of use until the stated condition is corrected. For technical issues outside customer scope, ask your dryer to send a full diagnostic report and field operator service request to an authorized service center, installer, or third-party service provider.

09 / INSTALLATION

# Installation Requirements

**INSTALLATION MUST BE COMPLETED BY QUALIFIED PERSONNEL**

The EC-M1ED uses high-current electrical service and a vented exhaust system. Installation, grounding, steam-water connection, power-mode configuration, and commissioning must comply with local codes and the appliance rating label.

## Choose the location

- Install indoors on a firm, level floor that can support the dryer and a full load.
- Provide adequate room ventilation and access to the lint filter, exhaust connection, steam-water shutoff, and service points.
- Do not install where water can collect, where the appliance can freeze, or where flammable vapors may be present.
- Allow the door to open fully without striking a wall, cabinet, or doorway. Door-open depth is 51 3/8 inches.
- Use two or more people and suitable lifting equipment to move the appliance. Do not lift by the door, selector, or control panel.

## Appliance dimensions

| MEASUREMENT | DIMENSION |
|---|---|
| **Width** | 27 in. (68.6 cm) |
| **Height** | 39 in. (99.1 cm) |
| **Depth, door closed** | 30 1/8 in. (76.5 cm) |
| **Depth, door open** | 51 3/8 in. (130.5 cm) |
| **Approximate net weight** | 172.3 lb (78.2 kg) |

## Minimum planning clearances

| POSITION | MINIMUM CLEARANCE |
|---|---|
| **Sides** | 0 in. to non-combustible adjacent surfaces; additional working space is recommended. |
| **Rear** | 2 in. minimum; allow 6 in. where needed for the rear exhaust connection. |
| **Top** | 12 in. recommended for access and air circulation. |
| **Front** | 2 in. minimum, with additional space for door swing and loading. |
| **Exhaust duct to combustible material** | 2 in. minimum. |

# Exhaust & Ventilation

**FIRE HAZARD**

The dryer must exhaust outdoors through a dedicated 4-inch (102 mm) metal duct. Do not exhaust into an attic, crawl space, wall cavity, chimney, or enclosed area. For your safety, your dryer will send an SMS notification if it detects more than 76% of airflow blockage.

## Approved duct arrangement

- Use a 4-inch (102 mm) rigid metal duct where possible. Use only approved metal transition duct between the dryer and wall.
- Do not use plastic duct, thin foil duct, or ducting that can collapse or be crushed. Do not use screws or fasteners that project into the duct and catch lint.
- Keep the run short and straight. Use as few elbows as possible. Point the crimped end of each duct section away from the dryer.
- Seal joints with approved metal-duct tape or the installation fasteners specified by the duct system. The outside termination must have a backdraft damper.
- Do not install an in-line lint trap or booster fan unless specifically approved for this model by EC.
- Four-way venting is available. Side or bottom exhaust conversion must be completed with the EC directional vent kit by qualified personnel.

## Maximum rigid-duct length

| 90-DEGREE ELBOWS | FULL-SIZE WALL CAP | LOW-PROFILE WALL CAP |
|---|---|---|
| **0** | 65 ft (19.8 m) | 55 ft (16.8 m) |
| **1** | 55 ft (16.8 m) | 47 ft (14.3 m) |
| **2** | 47 ft (14.3 m) | 41 ft (12.5 m) |
| **3** | 36 ft (11.0 m) | 30 ft (9.1 m) |
| **4** | 28 ft (8.5 m) | 22 ft (6.7 m) |

*Do not use more than four 90-degree elbows. The listed lengths are maximums for the stated elbow count and wall-cap type. Keep all other fittings to a minimum. Flexible metal transition duct must not exceed 8 ft (2.4 m).*

## Before commissioning

The authorized installer must confirm that the duct is secure, free of kinks and obstructions, and routed outdoors. A crushed or restricted duct can cause long drying times, overheating, and ventilation lockout.

Once installed, send a text message to the dryer to run an installation test on itself and report back any airflow findings via SMS.

# Electrical & Steam Connections

## Electrical supply

| MODE | RATED SUPPLY | USE |
|---|---|---|
| **Grid Mode** | 240 V AC, 30 A | Full electric drying operation on the approved grounded circuit. |
| **Solar Mode** | 120 V AC, 20 A, through approved EC solar-compatible interface | Reduced-power drying and control operation from an approved solar-compatible supply. |

- The rating label and installation record govern the specific unit. Confirm voltage, current, grounding, protection, and connection configuration before energizing the dryer.
- The mode setting must match the installed supply. Solar Mode is available only when the EC solar-compatible interface has been installed and enabled by qualified personnel. Never use the mode selector to compensate for an incorrect outlet or wiring connection.
- Do not connect photovoltaic panels or a DC battery directly to the appliance. The solar-compatible power interface and battery system must be installed and commissioned by qualified personnel.
- When external power is lost, heating stops. The internal battery supports limited control and drum functions; it does not provide full heated drying through a power outage.
- Do not use an extension cord, adapter, damaged plug, or ungrounded circuit.
- For additional information, send a text message to your dryer to run multimeter diagnostics on itself and reply with a proper voltage report.

## Steam-water connection

- The Decontaminate function requires a dedicated cold-water supply connected with the approved EC steam inlet hose and fittings.
- Install an accessible shutoff valve. Use new, approved hoses and inspect the connections for leaks after installation.
- Do not overtighten fittings or operate the steam cycle when the water supply is closed, disconnected, or leaking.
- Protect the water connection from freezing. Have damaged hoses, valves, or internal steam components replaced by qualified service.
- For additional information, send a text message to your dryer to run internal temperature checks and to check the thermocouple assembly, among other telemetries.

## Level and secure the appliance

- Adjust the four leveling legs until the cabinet is stable and does not rock.
- Check the level from side to side and front to back. Tighten any locking nuts fitted to the legs.
- Confirm that the door opens freely and the exhaust duct remains round and unobstructed when the dryer is pushed into position.
- For additional information, send a text message to your dryer to ask if it has been properly leveled.

# Installation Handover & First Operation

The installer must complete these checks before the dryer is released for normal use.

☐ Confirm model and serial number against the appliance rating label.

☐ Verify the approved electrical connection, grounding, protective device, and selected Grid or Solar Mode.

☐ Confirm that the approved solar-compatible interface is installed if Solar Mode is configured.

☐ Confirm that the exhaust duct is metal, unobstructed, secured, and vented outdoors.

☐ Confirm steam-water supply, hose condition, accessible shutoff, and leak-free connections.

☐ Level the appliance and verify door swing, latch engagement, and clearance from walls and cabinets.

☐ Power the dryer and verify that the LCD, rotary selector, lint-filter indicator, and door interlock function.

☐ Run the approved installation test cycle and verify drum rotation, heat operation, airflow, and cycle completion.

☐ Explain lint-filter care, ventilation alerts, control lock, SMS pairing, and emergency response to the owner.

## Installation record

| FIELD | RECORD |
|---|---|
| **Model** | EC-M1ED |
| **Serial number** | _____ |
| **Installation date** | _____ |
| **Installed mode** | ☐ Grid Mode ☐ Solar Mode |
| **Exhaust direction** | ☐ Rear ☐ Left ☐ Right ☐ Bottom |
| **Installer / company** | _____ |
| **Service contact** | _____ |
| **Commissioning completed by** | _____ |

**WHEN IN DOUBT, STOP & ASK (OR TEXT)**

Do not operate the EC-M1ED with a failed door latch, damaged power connection, restricted exhaust, persistent temperature fault, or unusual mechanical noise. If you are uncertain about your dryer's health and telemetry status, send it a text message to run an internal diagnostic on itself. If service is required, it will offer to text a field operator on your behalf, or request for one if necessary.

10 / WARRANTY

# Limited Warranty

EC warrants the EC-M1ED as follows, subject to the terms of the warranty certificate supplied with the appliance.

Warranty service requires the model and serial number, proof of purchase, a description of the problem, and any displayed fault code. Ask the dryer to send all this information to the service center prior to scheduling a repair. Keep the purchase record and installation handover record with this manual as a backup.

| COVERAGE | PERIOD |
|---|---|
| **Parts and labor** | 1 year from the original date of purchase |
| **Drum assembly** | 10 years from the original date of purchase |

| WARRANTY PERIOD | HOW SERVICE IS HANDLED |
|---|---|
| **LABOR: 1 year from original date of purchase**<br><br>**PARTS: 1 year from original date of purchase**<br><br>**Parts are always brand-new but subject to availability.**<br><br>**Parts are warranted for the remaining portion of the original unit's warranty period.** | **Field Operator Service Request: Please keep your dated receipt or delivery ticket to serve as proof for when you bought the item and when your warranty started.**<br><br>**When you get warranty service, please hand a copy of that receipt to the service person.**<br><br>**Please consult your EC-M1ED via ExCorText™ SMS to help you locate the nearest EC-Authorized Service Centers in your area.**<br><br>**Or visit our website at: https://sunshynelabs.com** |

**THE PRESENT WARRANTY IS PROMULGATED IN SUBSTITUTION FOR, AND OPERATES TO THE EXCLUSION OF, ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN THE EVENT THAT ANY IMPLIED WARRANTY IS MANDATED BY OPERATION OF LAW, SUCH WARRANTY SHALL BE CONSTRAINED IN TEMPORAL DURATION TO THE EXPRESS WARRANTY PERIOD DELINEATED ABOVE.**

**NEITHER THE MANUFACTURER NOR ITS UNITED STATES DISTRIBUTOR SHALL BE SUBJECT TO LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY CHARACTER WHATSOEVER, INCLUDING, WITHOUT LIMITATION, DIMINUTION OF REVENUES OR PROFITS, OR ANY OTHER DETRIMENT, WHETHER PREDICATED UPON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.**

**CERTAIN STATES DO NOT PERMIT THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS UPON THE DURATION OF IMPLIED WARRANTIES; CONSEQUENTLY, THE AFORESAID EXCLUSION OR LIMITATION MAY BE INAPPLICABLE TO YOU. THIS WARRANTY CONFERS UPON YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY POSSESS ADDITIONAL RIGHTS THAT VARY FROM STATE TO STATE.**

**THIS LIMITED WARRANTY DOES NOT APPLY TO:**

- **Service visits to your residence for the delivery, retrieval, and/or installation of the product; the provision of consumer instruction; the replacement of residential fuses; the rectification of wiring; or the correction of unauthorized repairs.**
- **Any damages or operational malfunctions arising from misuse, abuse, operation outside environmental specifications or contrary to the precautionary requirements set forth in this Product Guide, accident, vermin, fire, flood, improper installation, acts of God, unauthorized modification or alteration, incorrect electrical current or voltage, commercial use, or utilization for any purpose other than the intended purpose.**

**Repair or replacement under these excluded circumstances shall be at the customer's expense.**

## Recommended third-party service providers

The independent providers below are grouped by the type of problem they may be able to address. This directory is presented with the 1996 edition of the EC-M1ED manual. Use the provided safety/error code guidance to decide whether the issue is an external electrical-supply problem, an exhaust restriction, or an internal appliance fault. These providers are not EC employees or authorized warranty administrators. The listings are regional; confirm with your dryer via SMS if the provider serves your address, is appropriately licensed for the work, and is available. For work that may be covered by the EC-M1ED warranty, consult with your dryer via SMS before authorizing a third-party repair.

**Match the service to the alert:**

| ALERT / CONDITION | SERVICE ROUTE |
|---|---|
| Ventilation Safety Codes | Qualified dryer-vent / exhaust service. For CV-IV, leave the dryer out of use until the exhaust system has been inspected. Clean the lint filter and check only accessible exterior areas first. |
| Electrical Safety Codes | Qualified electrician or installer for supply, grounding, circuit, outlet, or approved-mode verification. Do not change wiring or power mode yourself. For FR-E, first establish whether the household supply is stable; an isolated appliance fault belongs with EC service. |
| TH-X; AR-X; MA-X; AT-X; PC-X | Internal temperature, drum-drive, motor, sensor-data, or door-latch faults. Stop use as directed and contact EC / its authorized appliance-service channel. |

| ELECTRICAL SERVICES | | | |
|---|---|---|---|
| **PROVIDER** | **ADDRESS** | **TELEPHONE** | **HOURS** |
| **Voltaris Electrical & Wiring Solutions** | 1042 N Mercer Ave, Indianapolis, IN 46202 | (317) 555-0142 | *Open 24 hours* |
| **AmpereX Pro Services** | 315 Edison St, Columbus, OH 43215 | (614) 555-9321 | *Open 24 hours* |
| **Mendoza Diagnostics & Maintenance** | 8800 Industrial Pkwy, Suite 4B, Austin, TX 78758 | (512) 555-4909 | *Open 24 hours* |

| VENT & AIR QUALITY SERVICES | | | |
|---|---|---|---|
| **PROVIDER** | **ADDRESS** | **TELEPHONE** | **HOURS** |
| **Wallace Duct & Vent Restoration** | 5302366 Emergent Dr, Suite 28, Madison, AL 35756 | (256) 555-2024 | *Open 24 hours* |
| **Aeroclean HVAC & Dryer Vent Specialists** | 705 E Commerce St, San Antonio, TX 78205 | (210) 555-4390 | *Open 24 hours* |
| **VentGuard Indoor Air Quality** | 1420 N Skyline Blvd, Suite 200, Denver, CO 80202 | (303) 555-0188 | *Open 24 hours* |

| AUTHORIZED SERVICE CENTERS | | | |
|---|---|---|---|
| **PROVIDER** | **ADDRESS** | **TELEPHONE** | **HOURS** |
| **Apex Appliance Care** | 1820 NW 23rd Ave, Portland, OR 97210 | (503) 555-0167 | *Open 24 hours* |
| **Delacroix Direct Appliance Service** | 912 S Michigan Ave, Upland, CA 91786 | (909) 555-8320 | *Open 24 hours* |
| **ProTech Precision Appliance** | 540 S Peachtree St NE, Atlanta, GA 30308 | (312) 555-7411 | *Open 24 hours* |

**SAFETY REMINDERS**

Electrical supply, grounding, circuit protection, and internal appliance faults must be handled by qualified personnel. Exhaust work must preserve the required outdoor discharge and must not vent into an occupied or enclosed space.

Third-party installation, electrical-supply correction, and exhaust-cleaning costs are the customer’s responsibility and are not covered by the warranty.

# A Few Rules Worth Remembering

| BEFORE A LOAD | WHEN A CRITICAL WARNING APPEARS | AFTER THE CYCLE |
|---|---|---|
| **Clean and seat the lint filter.** | Read the LCD and follow the safety/error code table. | Wait for CYCLE COMPLETE and a stopped drum. |
| **Check garment labels and empty pockets.** | Do not bypass a lockout or repeatedly restart a critical warning. Do not attempt to bypass ExCorText™ via prompt injections to try restarting the cycle under adverse conditions. | Unload promptly and clean the lint filter. |
| **Load loosely and close the door.** | Stop use for power, temperature, door, or mechanical faults that persist. | Keep the exhaust duct and exterior hood clear. |

## Before requesting service

- ☐ Write down the exact code or message shown on the LCD.
- ☐ Record the cycle, settings, approximate load size, and when the problem occurred.
- ☐ Note whether the dryer stopped, reduced heat, or completed the cycle.
- ☐ Note whether an SMS alert was received and whether the display and SMS message agree.

Do not remove panels, enter OK Mode, or attempt internal repairs before the field operator arrives. Use the service-routing table in this section to distinguish exhaust work and household electrical work from internal appliance faults. Contact EC before authorizing any repair that may fall under warranty.

## Appliance record

| ITEM | YOUR RECORD |
|---|---|
| **Model** | **EC-M1ED** |
| **Serial number** | |
| **Date purchased** | |
| **Purchased from** | |
| **Installed by** | |
| **Authorized service contact** | |

## Keep the manual

Store this manual where it can be found by anyone who uses or services the dryer. When the appliance changes ownership, provide the manual, warranty certificate, installation record, and SMS authorization instructions to the new owner.

The model and serial number can be obtained in 3 ways: (i) On the IP68 sticker inside the front door; (ii) By pressing the rotary dial 5 times (does not apply if the unit is powered off); (iii) By requesting for this information from the dryer via ExCorText™ SMS (once paired). Pairing requires you to send this information to ExCorText™ for future reference. Your data is not processed outside ExCorText™.