
## Configure RADIUS on WLC:

From WLC GUI, click Security. From the menu on the left, click RADIUS > Authentication. The RADIUS Authentication servers page appears. To add a new RADIUS Server, click New.



In the RADIUS Authentication Servers > New page, enter the parameters specific to the RADIUS server. Check Management radio button in order to allow the RADIUS Server to authenticate users who login to the WLC. In Server IP Address (Ipv4/Ipv6) type Cisco ISE IP 192.168.100.210



## 

**Port** 

1812

**TPSec** 

Disabled

**Admin Status** 

Enabled

Configure RADIUS Accounting Go to Security -> RADIUS -> Accounting. The RADIUS Accounting servers page appears. To add a new RADIUS Server, click New.

Server Address(Ipv4/Ipv6)

192.168.100.210

Management Proxy

0 1

Index



In the RADIUS Accounting Servers > New page, enter the parameters specific to the RADIUS server. In Server IP Address (Ipv4/Ipv6) type Cisco ISE IP 192.168.100.210

