



Passport 8600
Technical Config Guide
For ARP

PP8600 TCG ARP Version 1.1 May 2003

Copyright © 2003 Nortel Networks

All rights reserved. August 2003

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks Inc.

The software described in this document is furnished under a license agreement and may be used only in accordance with the terms of that license.

Trademarks

Nortel Networks, the Nortel Networks logo, the Globemark, Unified Networks, and PASSPORT are trademarks of Nortel Networks.

Adobe and Acrobat Reader are trademarks of Adobe Systems Incorporate.

Ta	Table of Contents				
1.	OVI	ERVIEW			
2.	ARI	P TIMERS & CLEARING ARP ENTRIES	3		
3.	CO	NFIGURATION EXAMPLES	3		
	3.1 3.2 3.3 3.4	STATIC ARP ENTRY TO BROUTER PORT STATIC ARP ENTRY TO VLAN DELETING AN ARP ENTRY SETTING ARP AGING TIME	3 4		
4. 5.	REI	FTWARE BASELINEFERENCE DOCUMENTATION:	4		

1. Overview

The Passport 8600 provides configuration for default ARP aging, enabling of Proxy ARP, and static ARP entries.

To configure the Passport 8600 to communicate with devices that do not respond to ARP requests, a static ARP entry can be configured. Or if you do not wish to age out an ARP entry, a static ARP entry can also be used in this case. A static ARP entry maps the devices IP address to its MAC address. When configuring a static ARP entry on the Passport 8600, you assign the IP address and MAC to the physical port and VLAN number if the physical port belongs to a VLAN.

2. ARP Timers & Clearing ARP Entries

The ARP table can be viewed by using the following command:

Passport-8610:5# show ip arp info

Note that when viewing the ARP table, the ARP age time is displayed in 10's of second. Since the default ARP timeout is 360 minutes, the timeout will be displayed as 2160, which actually is $21600 (360 \times 60 \div 10)$.

An IP ARP entry or entries can be cleared at a VLAN or port level by using the following commands:

- Passport-8610:5# clear ip arp vlan <vlan number>
- Passport-8610:5# clear ip arp port <slot/port>

3. Configuration Examples

3.1 Static ARP Entry to Brouter Port

To add a static ARP entry to a brouter port, the following command is used:

- PP8600A:6# config ip arp add ports <value> ip <value> mac <value>
 - Example:
 - PP8600A:6# config ip arp add ports 1/46 ip 172.2.2.13 mac 00:00:98:22:33:44

3.2 Static ARP Entry to VLAN

To add a static ARP entry to a VLAN, the following command is used:

- PP8600A:6# config ip arp add ports <*value*> ip <*value*> mac <*value*> [*vlan* <*value*>]
- Example:

 PP8600A:6# config ip arp add ports 1/48 ip 10.1.1.23 mac 00:00:11:43:54:23 vlan 10

3.3 Deleting an ARP Entry

To delete a static entry, use the following command:

- config ip arp delete <ip address>
- Example:
 - o PP8600A:6# config ip arp delete 172.2.2.13

3.4 Setting ARP Aging Time

The default ARP aging time is set for 360 minutes. To change this setting, use the following command:

- PP8600A:6# config ip arp aging <1 to 32767 minutes>

4. Software Baseline

This document is based on Passport 8600 Software Release 3.5.

5. Reference Documentation:

Document Title	Publication Number	Description
Configuring IP Routing	314720-C Rev	Technical Publication
<u>Operations</u>	00May 2003	
PP8600 TCG VRRP	n/a	Technical Config Guide
PP8600 TCG OSPF	n/a	Technical Config Guide
PP8600 TCG QoS Filters	n/a	Technical Config Guide
PP8600 TCG RIP	n/a	Technical Config Guide

Nortel Networks External Distribution 4

<u>PP8600 TCG ARP</u> <u>Version 1.1</u> May 2003

Copyright © 2003 Nortel Networks

All rights reserved. August 2003

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks Inc.

The software described in this document is furnished under a license agreement and may be used only in accordance with the terms of that license.

Trademarks

Nortel Networks, the Nortel Networks logo, the Globemark, Unified Networks, and PASSPORT are trademarks of Nortel Networks.

Adobe and Acrobat Reader are trademarks of Adobe Systems Incorporate.

Contact Us:

For product support and sales information, visit the Nortel Networks website at:

http://www.nortelnetworks.com

In North America, dial toll-free 1-800-4Nortel, outside North America, dial 987-288-3700.

Nortel Networks External Distribution 5