AIRCRAFT MAINTENANCE MANUAL - A320NEO (SYNTHETIC)

TASK 32-42-27-200-801-A Brake Wear Check

Effectivity: ALL. Revision 61. This task gives the procedure to check the wear of the main landing gear carbon brakes with the wear indicator pins. Reference ATA 32-42-27.

1. Reason for the Job

Do a check of the brake wear at each daily check and when the brake temperature is less than 150 deg.C. Use the wear pin method only with the parking brake applied.

2. Job Set-up Information

A. Fixtures, Tools, Test and Support Equipment: No specific tooling. P/N 98D32103500-000 wear gauge may be used for the dimension check.

WARNING: MAKE SURE THAT THE PARKING BRAKE IS SET AND THE WHEEL CHOCKS ARE IN POSITION. THE BRAKES CAN BE HOT AND CAN CAUSE BURNS.

(1) Apply the parking brake and make sure that the brake pressure indication shows at least 2000 psi on the triple indicator.

3. Procedure

(1) Measure the length of the wear indicator pin that extends from the housing face. (2) If the pin end is flush with the housing face or below it, replace the brake assembly per AMM TASK 32-42-27-000-801. (3) If the pin extends more than 0.0 mm but less than 1.0 mm, record the measurement in the technical log and check again at the next daily check. (4) Make an entry in the aircraft technical log for VT-EXA or the applicable registration.

CAUTION: DO NOT USE THE WEAR PIN READING WITH THE PARKING BRAKE RELEASED. THE READING WILL BE INCORRECT.

(5) Close-up: remove the wheel chocks only after the brake temperature check is complete.

AIRCRAFT MAINTENANCE MANUAL - A320NEO (SYNTHETIC)

TASK 32-42-27-200-801-B Brake Wear Check

Effectivity: ALL. Revision 61. This task gives the procedure to check the wear of the main landing gear carbon brakes with the wear indicator pins. Reference ATA 32-42-27.

1. Reason for the Job

Do a check of the brake wear at each daily check and when the brake temperature is less than 150 deg.C. Use the wear pin method only with the parking brake applied.

2. Job Set-up Information

A. Fixtures, Tools, Test and Support Equipment: No specific tooling. P/N 98D32103500-000 wear gauge may be used for the dimension check.

WARNING: MAKE SURE THAT THE PARKING BRAKE IS SET AND THE WHEEL CHOCKS ARE IN POSITION. THE BRAKES CAN BE HOT AND CAN CAUSE BURNS.

(1) Apply the parking brake and make sure that the brake pressure indication shows at least 2000 psi on the triple indicator.

3. Procedure

(1) Measure the length of the wear indicator pin that extends from the housing face. (2) If the pin end is flush with the housing face or below it, replace the brake assembly per AMM TASK 32-42-27-000-801. (3) If the pin extends more than 0.0 mm but less than 1.0 mm, record the measurement in the technical log and check again at the next daily check. (4) Make an entry in the aircraft technical log for VT-EXA or the applicable registration.

CAUTION: DO NOT USE THE WEAR PIN READING WITH THE PARKING BRAKE RELEASED. THE READING WILL BE INCORRECT.

(5) Close-up: remove the wheel chocks only after the brake temperature check is complete.

AIRCRAFT MAINTENANCE MANUAL - A320NEO (SYNTHETIC)

TASK 32-42-27-200-801-C Brake Wear Check

Effectivity: ALL. Revision 61. This task gives the procedure to check the wear of the main landing gear carbon brakes with the wear indicator pins. Reference ATA 32-42-27.

1. Reason for the Job

Do a check of the brake wear at each daily check and when the brake temperature is less than 150 deg.C. Use the wear pin method only with the parking brake applied.

2. Job Set-up Information

A. Fixtures, Tools, Test and Support Equipment: No specific tooling. P/N 98D32103500-000 wear gauge may be used for the dimension check.

WARNING: MAKE SURE THAT THE PARKING BRAKE IS SET AND THE WHEEL CHOCKS ARE IN POSITION. THE BRAKES CAN BE HOT AND CAN CAUSE BURNS.

(1) Apply the parking brake and make sure that the brake pressure indication shows at least 2000 psi on the triple indicator.

3. Procedure

(1) Measure the length of the wear indicator pin that extends from the housing face. (2) If the pin end is flush with the housing face or below it, replace the brake assembly per AMM TASK 32-42-27-000-801. (3) If the pin extends more than 0.0 mm but less than 1.0 mm, record the measurement in the technical log and check again at the next daily check. (4) Make an entry in the aircraft technical log for VT-EXA or the applicable registration.

CAUTION: DO NOT USE THE WEAR PIN READING WITH THE PARKING BRAKE RELEASED. THE READING WILL BE INCORRECT.

(5) Close-up: remove the wheel chocks only after the brake temperature check is complete.