Electric Kettle Safety Sheet

1. Safe use

Fill the kettle between the MIN and MAX marks only. Always place it on a flat, heat-resistant surface and close the lid before boiling.

2. Cleaning

Descale monthly with a citric acid solution. Never immerse the base or the cord in water.

3. Warranty

The kettle carries a 24-month warranty covering heating element failure. Limescale build-up is not covered.