Cessna 206H Stationair (C206H)

Lycoming IO-540-AC1A5, 300 hp · 6 seats · Typical 206H (1998+) POH procedures; fuel-injected engine, constant-speed propeller, cowl flaps, LEFT/RIGHT fuel selector (no BOTH), right-side double cargo doors. G1000 (2004+) wording noted where it differs.

V-speeds & limits

Vr	**55–65 KIAS**
Vx	**72 KIAS**
Vy	**88 KIAS**
Best glide	**80 KIAS (3,600 lb)**
Vs / Vso	**58 / 54 KIAS**
Vfe	**140 KIAS (10°) / 120 KIAS (10°–20°) / 100 KIAS (20°–40°)**
Va	**121 KIAS (3,600 lb) / 111 KIAS (3,000 lb) / 101 KIAS (2,500 lb)**
Vno	**149 KIAS**
Vne	**182 KIAS**
Approach	**80–90 KIAS flaps up / 70–80 KIAS flaps full / 68 KIAS short field**

Normal procedures

Before Start

Preflight inspection	**COMPLETE**
Fuel quantity	**CHECK visually (87 gal usable)**
Oil quantity	**CHECK (12 qt max, 9 qt min)**
Cargo / baggage	**SECURED, weight & balance checked**
Passenger briefing	**COMPLETE (belts, exits – rear cargo doors do not open with flaps extended, sterile cockpit)**
Seats, belts, harnesses	**ADJUST & LOCK**
Brakes	**TEST & SET**
Control lock	**REMOVE**
Circuit breakers	**CHECK IN**
Electrical equipment / autopilot	**OFF**
Avionics switch (BUS 1 & BUS 2 on G1000)	**OFF**
Fuel selector	**LEFT or RIGHT (fullest tank)**
Cowl flaps	**OPEN**
Standby battery	**TEST (20 s, green steady) then ARM (G1000)**
Master switch (ALT & BAT)	**ON**
Annunciators / PFD	**CHECK (LOW VOLTS on is normal before start)**

Engine Start

Throttle	**OPEN 1/4 inch**
Mixture	**IDLE CUTOFF**
Propeller	**HIGH RPM (full forward)**
Beacon	**ON**
Propeller area	**CLEAR**
Fuel pump	**ON**
Mixture	**RICH until fuel flow stable (3–5 s), then IDLE CUTOFF**
Fuel pump	**OFF**
Ignition switch	**START (release when engine fires)**
Mixture	**ADVANCE smoothly to RICH when engine fires**
Throttle	**ADJUST 1,000 RPM**
Oil pressure	**CHECK rising within 30 s (60 s cold)**
Ammeter / LOW VOLTS annunciator	**CHECK charging / light out**
Avionics switch (BUS 1 & BUS 2 on G1000)	**ON**

Before Taxi

Altimeter / barometric setting	**SET**
Radios / transponder / GPS	**SET**
Flaps	**CHECK operation, then UP**
Parking brake	**RELEASE**
Brakes	**CHECK during taxi**
Flight instruments	**CHECK during turns (HSI / DG, turn coordinator, compass)**

Before Takeoff

Parking brake	**SET**
Seats, belts, harnesses	**CHECK SECURE**
Cabin / cargo doors	**CLOSED & LATCHED**
Flight controls	**FREE & CORRECT**
Flight instruments / PFD	**CHECK & SET (no red X)**
Fuel quantity	**CHECK**
Fuel selector	**LEFT or RIGHT (fullest tank, do not switch just before takeoff)**
Mixture	**RICH (below 3,000 ft; lean for field elevation above)**
Elevator / rudder trim	**TAKEOFF**
Cowl flaps	**OPEN**
Throttle	**1,800 RPM**
Magnetos	**CHECK (max drop 150 RPM, max 50 RPM differential)**
Propeller	**CYCLE from high to low RPM 2–3 times (RPM drop ~300–500, pressure recovery)**
Engine instruments / ammeter	**CHECK (oil press 50–90 psi green)**
Vacuum gauge (analogue)	**CHECK (4.5–5.5 in Hg)**
Annunciators	**CHECK (none lit)**
Throttle	**1,000 RPM**
Autopilot	**OFF**
Radios / transponder	**SET / ALT**
Strobe lights	**ON**
Wing flaps	**0°–20° (20° for short field)**
Takeoff briefing	**COMPLETE**

After Takeoff / Climb

Airspeed	**88 KIAS (Vy) / 72 KIAS (Vx, obstacles); cruise climb 95–105 KIAS**
Wing flaps	**UP (above 75 KIAS)**
Power	**25 in Hg / 2,500 RPM (full throttle / 2,700 RPM for max performance)**
Mixture	**RICH (lean above 3,000 ft per fuel flow placard)**
Cowl flaps	**OPEN**
Engine instruments	**CHECK (CHT / oil temp)**
Fuel pump	**OFF**

Cruise

Power	**15–25 in Hg, 2,200–2,500 RPM (80% max continuous)**
Elevator / rudder trim	**ADJUST**
Mixture	**LEAN as required (per fuel flow / EGT)**
Cowl flaps	**CLOSED / AS REQUIRED for CHT**
Fuel selector	**SWITCH tanks at intervals to keep balance (max 1 hr per tank suggested)**
Engine instruments	**CHECK**
Fuel quantity / endurance	**CHECK**

Descent

Altimeter / barometric setting	**SET**
Power	**AS DESIRED (avoid rapid cooling – reduce 1–2 in Hg per minute)**
Mixture	**ADJUST for smooth operation**
Cowl flaps	**CLOSED**
Approach briefing	**COMPLETE**

Before Landing

Seats, belts, harnesses	**SECURE**
Fuel selector	**FULLEST TANK**
Mixture	**RICH**
Propeller	**HIGH RPM (full forward)**
Cowl flaps	**CLOSED (OPEN if go-around likely in hot conditions)**
Landing / taxi lights	**ON**
Autopilot	**OFF**
Airspeed	**80–90 KIAS (flaps up)**
Wing flaps	**AS DESIRED (10° below 140 KIAS, 20° below 120 KIAS, 40° below 100 KIAS)**
Airspeed	**70–80 KIAS (flaps full)**

After Landing

Wing flaps	**UP (required before cargo doors can be opened)**
Cowl flaps	**OPEN**
Strobe / landing lights	**OFF / AS REQUIRED**

Shutdown

Parking brake	**SET**
Electrical equipment / autopilot / pitot heat	**OFF**
Avionics switch (BUS 1 & BUS 2 on G1000)	**OFF**
Mixture	**IDLE CUTOFF (pull full out)**
Ignition switch	**OFF (key removed)**
Master switch (ALT & BAT)	**OFF**
Standby battery	**OFF (G1000)**
Control lock	**INSTALL**
Wing flaps	**CONFIRM UP before opening cargo doors**

Abnormal procedures

LOW VOLTS / Alternator Failure

LOW VOLTS annunciator or ammeter discharge in flight

Avionics switch (BUS 1 & BUS 2)	**OFF**
Master switch (ALT only)	**OFF, then ON**
LOW VOLTS annunciator / ammeter	**CHECK**
Avionics switch (BUS 1 & BUS 2)	**ON**

▶ Charging restored?

Yes:

Ammeter / volts	**MONITOR**

No:

Master switch (ALT only)	**OFF**
Non-essential electrical equipment	**OFF (lights, autopilot, BUS 2 avionics)**
Standby battery	**CHECK ARMED – approx 30 min essential bus (G1000)**
Deferred: Alternator failed – battery / standby battery only, limited endurance. Land as soon as practical, lower flaps early while power remains.	**NOTED**

Low Oil Pressure

OIL PRESSURE annunciator or pressure below 50 psi green arc

Oil pressure / oil temperature	**CHECK**

▶ Oil temperature also rising?

Yes:

Power	**REDUCE to minimum required**
Propeller	**EXPECT governor loss – RPM may go to high pitch stop**
Engine failure	**EXPECT – plan a precautionary landing**
Deferred: Low oil pressure with high temperature – land as soon as possible, expect engine failure.	**NOTED**

No – temp normal:

Flight	**CONTINUE to nearest suitable airport, monitor**
Deferred: Low oil pressure indication – land as soon as practical, maintenance check.	**NOTED**

High Oil / Cylinder Head Temperature

Oil temperature or CHT in red arc

Cowl flaps	**OPEN**
Mixture	**RICH**
Power	**REDUCE**
Airspeed	**INCREASE (lower nose for cooling)**
Oil pressure	**MONITOR**

▶ Temperature returning to green arc?

Yes:

Flight	**CONTINUE, monitor**

No:

Deferred: High engine temperature – land as soon as practical, minimum power, cowl flaps open.	**NOTED**

Rough Running / Fuel Flow Fluctuation

Rough engine, fuel flow fluctuating (vapour) or power loss

Fuel pump ..... **ON**

Mixture ..... **ADJUST for smooth operation**

Fuel selector ..... **SWITCH to other tank**

▶ Running smooth?

Yes:

Fuel pump ..... **OFF when fuel flow stable (ON again if fluctuation returns)**

No:

Magnetos ..... **CHECK L / R / BOTH, select smoothest**

Alternate induction air ..... **OPENS AUTOMATICALLY (no action)**

Deferred: Rough running engine – land as soon as practical, be ready for engine failure. ..... **NOTED**

Propeller Overspeed

RPM above 2,700 and not responding to propeller control

Throttle ..... **RETARD**

Oil pressure ..... **CHECK**

Propeller control ..... **DECREASE RPM (full aft; set if governor responds)**

Airspeed ..... **REDUCE**

Throttle ..... **AS REQUIRED to keep RPM below 2,700**

Deferred: Propeller governor failed – RPM controlled with throttle and airspeed only, land as soon as practical. ..... **NOTED**

Flap Failure

Flap circuit breaker ..... **CHECK / RESET once**

Flap switch ..... **CYCLE**

▶ Flaps operable?

Yes:

Flap setting ..... **AS REQUIRED**

No – stuck up:

Approach ..... **FLAPS UP – 80–90 KIAS, flatter approach, longer runway**

Deferred: Flaps inoperative – flaps-up landing at 80–90 KIAS, increased landing distance. ..... **NOTED**

No – stuck down:

Airspeed ..... **KEEP BELOW Vfe for the flap position**

Passengers ..... **BRIEF – rear cargo doors will not open normally after landing; use crew door or aft door emergency release**

Deferred: Flaps stuck extended – speed limit, cargo doors blocked after landing (use emergency release). ..... **NOTED**

Door Open in Flight

Crew door or cargo door unlatched

Airspeed ..... **REDUCE (approx 85 KIAS)**

Aircraft ..... **CONTROL – door has little effect on handling**

▶ Which door?

Crew door:

Window ..... **OPEN (equalise pressure), then door CLOSE & LATCH**

Cargo door:

Door ..... **LEAVE – do not attempt to close in flight**

Wing flaps ..... **UP for landing (extended flap would contact an open forward cargo door)**

Loose articles ..... **SECURE**

Deferred: Cargo door open – flaps-up landing (80–90 KIAS), land as soon as practical. ..... **NOTED**

Vacuum / AHRS / PFD Failure

Vacuum gauge low or gyro flags (analogue); red X on PFD or display blank (G1000)

▶ Panel type?

G1000:

Display backup (red button) ..... **PRESS – reversionary mode on remaining display**

Standby airspeed / attitude / altimeter ..... **USE and cross-check**

Standby battery ..... **CHECK ARMED**

Deferred: G1000 display / AHRS failed – reversionary mode or standby instruments; avoid IMC. ..... **NOTED**

Analogue:

Vacuum gauge ..... **CHECK (4.5–5.5 in Hg)**

Attitude / heading indicators ..... **DISREGARD – cross-check**

Turn coordinator, compass, altimeter, airspeed ..... **USE for partial-panel flight**

Deferred: Vacuum failed – attitude and heading indicators unreliable; VMC only. ..... **NOTED**

IMC ..... **AVOID / EXIT**

Inadvertent Icing Encounter

Pitot heat	**ON**
Exit icing conditions	**TURN BACK / CHANGE ALTITUDE**
Cabin heat / windshield defrost	**FULL ON**
Power	**INCREASE / propeller RPM INCREASE to minimise propeller ice**
Mixture	**ADJUST (alternate induction air opens automatically)**
Airspeed on approach	**INCREASE (flaps up or 10° max with residual ice)**
Deferred: Residual airframe ice – flaps-up / 10° landing, approach 10–15 KIAS faster, expect higher stall speed.	**NOTED**

Emergency procedures

Engine Failure During Takeoff Roll

On the runway

Throttle (memory)	**IDLE**
Brakes (memory)	**APPLY**
Wing flaps (memory)	**RETRACT**
Mixture	**IDLE CUTOFF**
Ignition switch	**OFF**
Master switch (ALT & BAT)	**OFF**

Engine Failure After Takeoff

Airborne, insufficient runway remaining

LAND IMMEDIATELY

Airspeed (memory)	**80 KIAS flaps up / 75 KIAS flaps 10°–full**
Mixture (memory)	**IDLE CUTOFF**
Fuel selector (memory)	**OFF**
Ignition switch (memory)	**OFF**
Wing flaps (memory)	**AS REQUIRED (full recommended)**
Master switch (ALT & BAT) (memory)	**OFF**
Cabin door	**UNLATCH**

Land straight ahead with only small changes of direction. Do not attempt to turn back to the runway.

With flaps extended the rear cargo doors cannot be opened normally – evacuate via the crew door, or pull the aft cargo door emergency release handle.

Engine Failure in Flight

Loss of power with altitude available

LAND AS SOON AS POSSIBLE

Airspeed (memory)	80 KIAS (best glide)
Propeller (memory)	LOW RPM (full aft – reduces drag)
Fuel selector (memory)	SWITCH to other tank (check quantity)
Fuel pump (memory)	ON
Mixture (memory)	RICH (if restart not immediate: IDLE CUTOFF, then advance slowly)
Ignition switch (memory)	BOTH (START if propeller stopped)

▶ Engine restarted?

Yes:

Propeller	HIGH RPM, then as required
Power	AS REQUIRED
Fuel pump	OFF (ON if power fluctuates)
Engine instruments	MONITOR
Deferred: Engine restarted after in-flight failure – land as soon as possible, suspect fuel starvation (tank) or ignition.	NOTED

No – forced landing:

Forced landing without engine power:

Field / wind	SELECT & PLAN (into wind if possible)
Mayday / 7700	TRANSMIT (time permitting)
Passengers	BRIEF – exit via crew door; rear cargo doors blocked by extended flaps unless emergency release is pulled
Seats, belts, harnesses	SECURE
Airspeed	80 KIAS flaps up / 75 KIAS flaps down
Mixture	IDLE CUTOFF
Fuel selector	OFF
Ignition switch	OFF
Wing flaps	AS REQUIRED (full recommended)
Master switch (ALT & BAT)	OFF (when landing assured)
Doors	UNLATCH prior to touchdown
Touchdown	SLIGHTLY TAIL LOW
Brakes	APPLY HEAVILY

Engine Fire During Start

Cranking (memory)	CONTINUE (draw flames into engine)

▶ Engine started?

Yes:

Power	1,800 RPM for a few minutes
Engine	SHUT DOWN & INSPECT for damage

No:

Throttle	FULL OPEN
Mixture	IDLE CUTOFF
Cranking	CONTINUE
Fuel pump	OFF
Fuel selector	OFF
Ignition switch	OFF
Master switch (ALT & BAT)	OFF
Fire extinguisher	OBTAIN & USE
Aircraft	EVACUATE, inspect for damage

Engine Fire in Flight

LAND IMMEDIATELY

Mixture (memory)	IDLE CUTOFF
Fuel selector (memory)	OFF
Fuel pump (memory)	OFF
Master switch (ALT & BAT) (memory)	OFF
Cabin heat / air / cowl flaps (memory)	OFF / CLOSED (overhead vents open)
Airspeed (memory)	100 KIAS (increase if fire persists until incombustible)

Do not attempt an engine restart.

Forced landing	EXECUTE (see Engine Failure in Flight)

Electrical Fire in Flight

LAND AS SOON AS POSSIBLE

- Standby battery (memory) ..... **OFF (G1000)**
- Master switch (ALT & BAT) (memory) ..... **OFF**
- Vents / cabin air / heat (memory) ..... **CLOSED**
- Fire extinguisher ..... **ACTIVATE (if available)**
- Avionics switch (BUS 1 & BUS 2) ..... **OFF**
- All other switches (except ignition) ..... **OFF**

After discharging the extinguisher, ventilate the cabin.

▶ Fire out and electrical power necessary?

Yes:

- Master switch (ALT & BAT) ..... **ON**
- Standby battery ..... **ARM (G1000)**
- Circuit breakers ..... **CHECK – do not reset a faulted breaker**
- Avionics switch (BUS 1 then BUS 2) ..... **ON one at a time, with delay, check for smoke**
- Vents / cabin air / heat ..... **OPEN when fire is completely out**
- Deferred: Electrical fire – faulted circuit isolated, affected equipment unavailable. ..... **NOTED**

No:

Continue with master off. No flaps, radios or fuel gauges; standby instruments only (G1000). Flaps up means cargo doors open normally after landing.

- Deferred: Electrical power off – flaps-up landing (approach 85–90 KIAS), no radio; standby instruments only. ..... **NOTED**

Cabin Fire

LAND AS SOON AS POSSIBLE

- Master switch (ALT & BAT) (memory) ..... **OFF**
- Vents / cabin air / heat (memory) ..... **CLOSED**
- Fire extinguisher ..... **ACTIVATE**
- Cabin ..... **VENTILATE after fire is out**
- Land ..... **AS SOON AS POSSIBLE, inspect for damage**

For evacuation after landing, retract flaps so both cargo doors open, or use the aft cargo door emergency release.

Emergency Descent

- Throttle (memory) ..... **IDLE**
- Propeller (memory) ..... **HIGH RPM (full forward – maximum drag)**
- Mixture (memory) ..... **RICH**
- Wing flaps (memory) ..... **UP**
- Airspeed (memory) ..... **149 KIAS smooth air / 121 KIAS turbulence (Va)**
- Cowl flaps ..... **CLOSED (avoid shock cooling)**
- Power ..... **CLEAR ENGINE periodically**

Emergency Evacuation / Cargo Door Interlock

On the ground, rapid exit required

- Wing flaps (memory) ..... **UP (if electrical power available)**
- Mixture / fuel selector / master (memory) ..... **IDLE CUTOFF / OFF / OFF**
- Crew door (left) ..... **OPEN – primary exit**

▶ Flaps extended?

Yes:

- Forward cargo door ..... **BLOCKED by flap – do not force**
- Aft cargo door emergency release handle ..... **PULL (placarded), then push aft door open**

No:

- Forward cargo door ..... **OPEN first (handle forward)**
- Aft cargo door ..... **OPEN second**
- Passengers ..... **EVACUATE upwind, well clear**