Maule M-6-235 Super Rocket (M6-235)

Lycoming O-540-J1A5D (carbureted) or IO-540-W1A5D (fuel-injected), 235 hp · 4–5 seats · Typical M-6-235 (1980s) POH procedures: the shorter-fuselage predecessor of the M-7 with the long 30 ft 10 in wing, large manual flaps -7° reflex / 0° / 24° / 40° / 48° and 2,500 lb gross weight; conventional (tailwheel) gear on oleo-spring main legs with a spring tailwheel, constant-speed propeller; 2 × 20 gal main tanks (approx 40 gal) with a LEFT/RIGHT/OFF fuel selector, plus optional 2 × 15 gal auxiliary wing tanks transferred into the mains by electric transfer pumps. Carburettor-heat items apply to the O-540 only; alternate induction air to the IO-540. Figures are KIAS approximations of a POH written in MPH and vary by sub-model and year – verify against the aircraft's own POH. Floats or skis, if fitted, have their own supplement and are not covered here.

V-speeds & limits

Vr	**40–50 KIAS (STOL technique, tail-low, flaps 24°–40°; 50–55 KIAS normal) – verify**
Vx	**approx 55–60 KIAS**
Vy	**approx 75 KIAS**
Best glide	**approx 70 KIAS**
Vs / Vso	**approx 43 / 35 KIAS (verify in POH)**
Vfe	**approx 90 KIAS (24°) / 85 KIAS (40°) / 80 KIAS (48°) – verify; -7° reflex has no separate limit**
Va	**approx 110 KIAS (2,500 lb)**
Vno	**approx 135 KIAS**
Vne	**approx 160 KIAS**
Approach	**65–70 KIAS flaps 24° / 55–60 KIAS flaps 40° / 50–55 KIAS flaps 48° short field (three-point)**

Normal procedures

Before Start

Preflight inspection	**COMPLETE (oleo-spring main gear – strut extension even, no leaks; tailwheel tyre, leaf spring, steering chains & springs; brake lines; flap and strut attach points; fuel vents)**
Fuel quantity	**CHECK visually – mains 2 × 20 gal (approx 40 gal) and aux tanks 2 × 15 gal if installed; gauges cross-checked**
Fuel sumps	**DRAINED (mains, aux, gascolator)**
Oil quantity	**CHECK (12 qt max; add if below 8 qt)**
Cargo / baggage	**SECURED, weight & balance checked (2,500 lb gross; aft CG limits with rear load)**
Passenger briefing	**COMPLETE (belts & shoulder harnesses, door latches – both front doors and right-side rear cargo door, tail-low attitude on ground, sterile cockpit)**
Seats, belts, shoulder harnesses	**ADJUST & LOCK (harnesses on, all occupants)**
Doors	**CLOSED & LATCHED – left front, right front, rear cargo door (check from inside and out)**
Brakes	**TEST & SET**
Control lock	**REMOVE**
Electrical equipment / avionics master	**OFF**
Fuel selector	**LEFT or RIGHT (fullest main) – never OFF for start**
Aux fuel transfer switches	**OFF**
Flaps	**0° (check -7° reflex detent and full travel to 48°)**
Master switch	**ON**

Engine Start

Throttle ..... **OPEN approx 1/4 inch**

Propeller ..... **HIGH RPM (full forward)**

Mixture ..... **IDLE CUTOFF (IO-540) / RICH (O-540)**

Beacon ..... **ON**

Propeller area ..... **CLEAR (tail-low – check nose-high blind area)**

▶ Engine condition?

Cold / normal:

Fuel boost pump ..... **ON**

Prime ..... **IO-540: mixture RICH until fuel flow indicates (3–5 s) then IDLE CUTOFF; O-540: primer 2–3 strokes (cold), locked**

Ignition switch ..... **START (release when engine fires; max 10 s cranking)**

Mixture ..... **ADVANCE smoothly to RICH when engine fires (IO-540)**

Hot (IO-540):

Hot start: fuel in the injector lines has vaporised. Do not prime. If the engine has been shut down less than about 20 min it may start with no prime at all.

Throttle ..... **OPEN approx 1/2 inch**

Mixture ..... **IDLE CUTOFF**

Fuel boost pump ..... **OFF (ON briefly only if fuel flow shows zero, then OFF)**

Ignition switch ..... **START (max 10 s cranking)**

Mixture ..... **ADVANCE smoothly to RICH as engine fires, throttle back to 1,000 RPM**

▶ Engine started?

Yes:

No – use flooded procedure:

Mixture ..... **IDLE CUTOFF**

Throttle ..... **FULL OPEN**

Fuel boost pump ..... **OFF**

Ignition switch ..... **START – as engine fires: throttle RETARD smoothly, mixture RICH**

Allow the starter to cool (approx 2 min between 10 s attempts). After repeated failures treat the engine as flooded or seek a cold-soak and try the cold procedure.

Flooded:

Mixture ..... **IDLE CUTOFF**

Throttle ..... **FULL OPEN**

Fuel boost pump ..... **OFF**

Ignition switch ..... **START – as engine fires: throttle RETARD smoothly, mixture RICH**

Keep a hand on the throttle: the engine will surge to high RPM as it catches with the throttle open.

Throttle ..... **ADJUST 1,000 RPM**

Oil pressure ..... **CHECK rising within 30 s (60 s cold) – if not, SHUT DOWN**

Fuel boost pump ..... **OFF (fuel pressure steady)**

Ammeter / voltmeter ..... **CHECK charging**

Avionics master ..... **ON**

Before Taxi

Altimeter ..... **SET**

Radios / transponder / GPS ..... **SET**

Tailwheel steering ..... **CHECK – tailwheel follows rudder through steering springs, full-swivel releases only with brake and full rudder**

Parking brake ..... **RELEASE**

Brakes ..... **CHECK during initial taxi (differential braking available)**

Flight controls for wind ..... **POSITIONED – climb into headwind (stick back, aileron into wind), dive away from tailwind (stick forward, aileron away); long wing is sensitive to gusts**

Taxi speed ..... **SLOW – S-turns for forward visibility, no sudden braking (nose-over risk)**

Before Takeoff

Parking brake	**SET (aircraft into wind, stick HELD BACK during run-up)**
Seats, belts, shoulder harnesses	**CHECK SECURE**
Doors / windows	**CLOSED & LATCHED (both front doors, rear cargo door)**
Flight controls	**FREE & CORRECT**
Fuel quantity	**CHECK both mains**
Fuel selector	**FULLEST MAIN (do not change tanks just before takeoff)**
Aux fuel transfer switches	**OFF**
Mixture	**RICH (lean for field elevation above approx 3,000 ft)**
Elevator trim	**TAKEOFF**
Throttle	**1,800–2,000 RPM**
Magnetos	**CHECK L / R / BOTH (max drop 175 RPM, max 50 RPM differential)**
Propeller	**CYCLE high to low RPM 2–3 times (RPM drop approx 300–500, oil pressure recovers)**
Carb heat (O-540)	**CHECK RPM drop, then COLD**
Alternate air (IO-540)	**CHECK operation (if fitted), then CLOSED**
Engine instruments	**CHECK (oil press 55–95 psi, oil temp green, fuel press / flow steady)**
Suction	**CHECK green (approx 4.5–5.5 in Hg)**
Throttle	**1,000 RPM**
Fuel boost pump	**ON**
Tailwheel	**ALIGNED straight**
Radios / transponder	**SET / ALT**
Flaps	**SET – 0° or 24° normal; 24°–40° short / soft field (verify POH)**
Takeoff briefing	**COMPLETE (directional control with rudder, tail up or tail-low, rotate 40–55 KIAS by technique, abort / EFATO plan)**

▶ **Takeoff type?**

Normal:

Technique	**TAIL-LOW, lift off approx 50–55 KIAS, accelerate to 75 KIAS (Vy)**

Short field (STOL):

Flaps	**24° (40° for shortest ground roll, if POH permits)**
Technique	**BRAKES HELD to full power, release, stick back, lift off approx 40–50 KIAS, climb at approx 55–60 KIAS (Vx) until clear, then flaps up in stages above 65 KIAS**

Soft / rough field:

Flaps	**24°–40°**
Technique	**STICK FULL BACK initially, keep rolling, lift off at minimum speed, accelerate in ground effect, flaps up in stages above 65 KIAS**

After Takeoff / Climb

Airspeed	**75 KIAS (Vy) / 55–60 KIAS (Vx, obstacles); cruise climb 80–85 KIAS**
Flaps	**0° (retract in stages above 65 KIAS, clear of obstacles – expect sink as 40° comes up)**
Fuel boost pump	**OFF (above approx 1,000 ft AGL; check fuel pressure / flow steady)**
Power	**FULL THROTTLE / full RPM to 1,000 ft, then approx 25 in Hg / 2,400 RPM (verify red line – 2,400 RPM rated on both engines)**
Mixture	**RICH (lean above approx 3,000 ft per EGT / fuel flow)**

Cruise

Power	**SET (typical 2,300–2,400 RPM / 22–24 in Hg, approx 65–75%)**
Flaps	**-7° REFLEX for cruise (raises cruise speed; return to 0° before slowing below approx 80 KIAS)**
Mixture	**LEAN per EGT / fuel flow (approx 12–14 GPH at 65–75%)**
Fuel selector	**CHANGE MAINS at intervals (approx every 30–60 min) to keep balance; boost pump ON during change**
Aux fuel transfer (if installed)	**TRANSFER SWITCH ON for the side whose main is below approx 1/2; OFF when main full or aux empty (avoid venting overboard)**
Fuel quantity / endurance	**CHECK mains and aux against plan (approx 40 gal mains + 30 gal aux)**

Descent

Altimeter	**SET**
Flaps	**0° (out of reflex before slowing)**
Power	**REDUCE gradually (avoid rapid cooling)**
Carb heat (O-540)	**ON for low-power descent**
Mixture	**ENRICH progressively**
Approach briefing	**COMPLETE (wind, wheel or three-point landing, flap setting, go-around)**

Before Landing

Seats, belts, shoulder harnesses ..... **SECURE**

Fuel selector ..... **FULLEST MAIN**

Aux fuel transfer switches ..... **OFF**

Fuel boost pump ..... **ON**

Mixture ..... **RICH**

Propeller ..... **HIGH RPM (full forward)**

Carb heat (O-540) ..... **ON (COLD for go-around)**

Tailwheel ..... **STEERING ENGAGED / straight**

Flaps ..... **24° below approx 90 KIAS, 40° below approx 85 KIAS, 48° below approx 80 KIAS**

▶ Landing type?

Three-point:

- Airspeed ..... **55–60 KIAS (flaps 40°) / 50–55 KIAS (flaps 48°, short field), power as required**
- Touchdown ..... **ALL THREE WHEELS together, stick FULL BACK after touchdown, rudder for direction, brakes as required**

Wheel landing:

- Airspeed ..... **65–70 KIAS (flaps 24°–40°), slight power into the flare**
- Touchdown ..... **MAIN WHEELS tail-up, stick FORWARD slightly to pin mains (oleo legs – do not bounce), let tail settle as speed decays, then stick BACK**

Soft / rough field:

- Airspeed ..... **55 KIAS (flaps 40°–48°), power on**
- Touchdown ..... **THREE-POINT or tail-low at minimum speed, stick FULL BACK, minimum braking**

Flaps 48° give a steep, draggy approach with high sink rate – carry power and plan the go-around early; retract to 24° if power is applied for a go-around.

Crosswind ..... **WING LOW into wind, upwind wheel first, full aileron into wind as speed decays (reduce flap in strong crosswind)**

After Landing

Keep flying the aircraft until stopped – the landing is not over until the tailwheel is on the ground and the aircraft is at taxi speed. Any swing: immediate rudder, go-around or power if needed.

Directional control ..... **RUDDER first, brakes sparingly – stick FULL BACK, aileron into wind**

Flaps ..... **0° (after clear of runway, at taxi speed)**

Carb heat (O-540) ..... **COLD**

Fuel boost pump ..... **OFF**

Strobe / landing lights ..... **OFF / AS REQUIRED**

Shutdown

Parking brake ..... **SET (into wind, stick back)**

Electrical equipment / pitot heat / avionics master ..... **OFF**

Mixture ..... **IDLE CUTOFF (pull full out)**

Ignition switch ..... **OFF (key removed)**

Master switch ..... **OFF**

Aux fuel transfer switches ..... **OFF**

Fuel selector ..... **LEFT or RIGHT (OFF only for extended parking, per operator)**

Control lock ..... **INSTALL (or stick secured back with belt)**

Tie-downs / tail ..... **SECURE (tail tie-down in wind – long wing, light tail)**

Abnormal procedures

Alternator Failure / Low Voltage

Ammeter discharge, low-voltage light or voltmeter low

Alternator / field circuit breaker ..... **CHECK IN**

Master switch (ALT half, if split) ..... **OFF, then ON**

Ammeter / voltmeter ..... **CHECK**

▶ Charging restored?

Yes:

- Ammeter / voltmeter ..... **MONITOR**

No:

- Alternator ..... **OFF**
- Non-essential electrical equipment ..... **OFF (lights, second radio, pitot heat if not needed)**
- Aux fuel ..... **TRANSFER NOW if needed – transfer pumps are electric**

Deferred: Alternator failed – battery only, limited endurance. Land as soon as practical; flaps are manual, but fuel gauges, boost pump and aux transfer will be

Low Oil Pressure

Oil pressure below 55 psi green arc

Oil pressure / oil temperature ..... **CHECK**

▶ Oil temperature also rising?

Yes:

- Power ..... **REDUCE to minimum required**
- Propeller ..... **EXPECT governor loss – RPM may rise to high-RPM stop**
- Engine failure ..... **EXPECT – plan a precautionary landing (suitable field, three-point, flaps 40°–48°)**
- Deferred: Low oil pressure with high temperature – land as soon as possible, expect engine failure. ..... **NOTED**

No – temp normal:

- Flight ..... **CONTINUE to nearest suitable airport, monitor**
- Deferred: Low oil pressure indication – land as soon as practical, maintenance check before further flight. ..... **NOTED**

High Oil Temperature / CHT

Oil temperature or CHT approaching red line

Mixture ..... **RICH**

Power ..... **REDUCE**

Airspeed ..... **INCREASE (lower nose, 85–95 KIAS in climb)**

Oil pressure ..... **MONITOR**

▶ Temperature returning to green arc?

Yes:

- Flight ..... **CONTINUE, monitor**

No:

- Deferred: High engine temperature – land as soon as practical, minimum power. ..... **NOTED**

Rough Running / Carb Ice / Fuel Pressure

Rough engine, RPM or manifold pressure decay, fuel pressure fluctuating

Fuel boost pump ..... **ON**

Mixture ..... **ADJUST for smooth operation**

Fuel selector ..... **CHANGE MAIN (check quantity)**

▶ Engine variant?

O-540 (carbureted):

- Carb heat ..... **FULL ON – expect initial roughness as ice clears, leave on until smooth, then COLD (partial heat not recommended)**

IO-540 (injected):

- Alternate induction air ..... **OPEN / CHECK (if fitted) – suspect induction icing or filter blockage**

▶ Running smooth?

Yes:

- Fuel boost pump ..... **OFF when pressure stable (ON again if fluctuation returns)**

No:

- Magnetos ..... **CHECK L / R / BOTH, select smoothest**
- Deferred: Rough running engine – land as soon as practical, boost pump on, be ready for engine failure. ..... **NOTED**

Propeller Overspeed

RPM above red line (approx 2,400 RPM – verify) and not responding to propeller control

Throttle ..... **RETARD**

Oil pressure ..... **CHECK**

Propeller control ..... **DECREASE RPM (full aft; reset if governor responds)**

Airspeed ..... **REDUCE**

Throttle ..... **AS REQUIRED to keep RPM below red line**

Deferred: Propeller governor failed – RPM controlled with throttle and airspeed only; land as soon as practical. ..... **NOTED**

Aux Fuel Will Not Transfer / Fuel Imbalance

Main not filling with transfer switch on, aux gauge not falling, or heavy wing

Transfer pump circuit breaker ..... **CHECK IN**

Main tank quantity ..... **CHECK – transfer stops when the 20 gal main is full; wait for room**

Other side transfer switch ..... **TRY (if that aux has fuel)**

▶ Transfer working?

Yes:

- Fuel plan ..... **REVISE – keep mains balanced, select heavy side**

No:

- Usable fuel ..... **RECOMPUTE on MAINS ONLY (approx 40 gal) – aux fuel is unusable**
- Fuel selector ..... **HEAVY SIDE to reduce imbalance**
- Deferred: Aux fuel unusable – endurance on main tanks only; divert if required, expect lateral imbalance. ..... **NOTED**

Flap Handle Jammed / Asymmetry

Manual flap handle will not move or flaps asymmetric

Airspeed ..... **REDUCE below approx 80 KIAS (less load on the handle)**

Flap handle ..... **RETRY – positive detent engagement, do not force**

▶ Flaps operable?

Yes:

Flap setting ..... **AS REQUIRED**

No – stuck at 0° or -7°:

Approach ..... **FLAPS 0° – 70–75 KIAS, wheel landing recommended, longer runway**

Deferred: Flaps inoperative – flaps-up landing at 70–75 KIAS, increased landing distance. ..... **NOTED**

No – stuck down / asymmetric:

Airspeed ..... **KEEP BELOW Vfe for the position (80 KIAS if 48°); aileron / rudder to hold wings level**

Approach ..... **POWER-ON, shallow, minimal bank**

Deferred: Flaps stuck extended – speed limited to Vfe, possible roll tendency; land as soon as practical. ..... **NOTED**

Door Open in Flight

Front door or rear cargo door unlatched

Airspeed ..... **REDUCE (approx 75–80 KIAS)**

Aircraft ..... **CONTROL – open door has little effect on handling**

▶ Which door?

Front door (left or right):

Window / vents ..... **OPEN (equalise pressure), then door CLOSE & LATCH**

Rear cargo door:

Door ..... **LEAVE – do not attempt to close in flight; passengers belted, away from door**

Loose articles ..... **SECURE**

Deferred: Rear cargo door open – reduced airspeed, land as soon as practical. ..... **NOTED**

Inadvertent Icing / Vacuum Failure

Airframe ice, or suction low / gyros unreliable

Pitot heat ..... **ON**

Exit icing conditions ..... **TURN BACK / CHANGE ALTITUDE**

Cabin heat / windshield defrost ..... **FULL ON**

Carb heat (O-540) ..... **ON / alternate air (IO-540) OPEN**

Power / propeller RPM ..... **INCREASE to minimise propeller ice**

Suction gauge ..... **CHECK – if low, disregard attitude / heading indicators, partial panel, exit IMC**

Airspeed on approach ..... **INCREASE (flaps 0°–24° max with residual ice; wheel landing)**

Deferred: Residual airframe ice / gyro loss – flaps 0°–24° landing, approach 10 KIAS faster, VMC only. ..... **NOTED**

Emergency procedures

Engine Failure During Takeoff Roll

On the runway

Throttle (memory) ..... **IDLE**

Directional control (memory) ..... **RUDDER, stick BACK**

Brakes (memory) ..... **APPLY (smoothly – avoid nose-over)**

Mixture ..... **IDLE CUTOFF**

Fuel selector ..... **OFF**

Ignition switch ..... **OFF**

Master switch ..... **OFF**

Engine Failure After Takeoff

Airborne, insufficient runway remaining

LAND IMMEDIATELY

Airspeed (memory) ..... **70 KIAS flaps 0° / 55–60 KIAS flaps 24°–40°**

Mixture (memory) ..... **IDLE CUTOFF**

Fuel selector (memory) ..... **OFF**

Ignition switch (memory) ..... **OFF**

Flaps (memory) ..... **AS REQUIRED (40°–48° once landing assured)**

Master switch (memory) ..... **OFF**

Doors ..... **UNLATCH**

Touchdown ..... **THREE-POINT, minimum speed, stick back**

Land straight ahead with only small heading changes. Do not attempt to turn back to the runway.

Engine Failure in Flight

Loss of power with altitude available

LAND AS SOON AS POSSIBLE

- Airspeed (memory) — **70 KIAS (best glide), flaps 0°**
- Propeller (memory) — **LOW RPM (full aft – reduces drag)**
- Fuel selector (memory) — **CHANGE MAIN (check quantity; transfer aux if mains low)**
- Fuel boost pump (memory) — **ON**
- Mixture (memory) — **RICH (if no restart: IDLE CUTOFF, then advance slowly)**
- Carb heat (O-540) / alternate air (IO-540) (memory) — **ON / OPEN**
- Ignition switch (memory) — **BOTH (START if propeller has stopped)**

▶ Engine restarted?

Yes:

- Propeller — **HIGH RPM, then as required**
- Power — **AS REQUIRED (minimum needed)**
- Fuel boost pump — **LEAVE ON if pressure fluctuates, else OFF**
- Engine instruments — **MONITOR**
- Deferred: Engine restarted after in-flight failure – land as soon as possible; suspect fuel starvation (tank selection / aux transfer), carb ice or ignition. — **NOT**

No – forced landing:

Forced landing without engine power:

- Field / wind — **SELECT & PLAN (into wind; the long wing and 48° flaps allow a very slow, steep arrival – avoid ditches and soft ground that could nose it over)**
- Mayday / 7700 — **TRANSMIT (time permitting)**
- Passengers — **BRIEF – brace, exits (both front doors, rear cargo door)**
- Seats, belts, shoulder harnesses — **SECURE**
- Airspeed — **70 KIAS flaps 0° / 55 KIAS flaps 40°–48°**
- Mixture — **IDLE CUTOFF**
- Fuel selector — **OFF**
- Aux fuel transfer switches — **OFF**
- Ignition switch — **OFF**
- Flaps — **40°–48° when landing assured**
- Master switch — **OFF**
- Doors — **UNLATCH prior to touchdown**
- Touchdown — **THREE-POINT, minimum speed, stick FULL BACK**
- Brakes — **AS REQUIRED (gently – nose-over risk on soft ground)**

Engine Fire During Start

- Cranking (memory) — **CONTINUE (draw flames into engine)**

▶ Engine started?

Yes:

- Power — **1,800 RPM for a few minutes**
- Engine — **SHUT DOWN & INSPECT for damage**

No:

- Throttle — **FULL OPEN**
- Mixture — **IDLE CUTOFF**
- Cranking — **CONTINUE**
- Fuel boost pump — **OFF**
- Fuel selector — **OFF**
- Ignition switch — **OFF**
- Master switch — **OFF**
- Fire extinguisher — **OBTAIN & USE**
- Aircraft — **EVACUATE, inspect for damage**

Engine Fire in Flight

LAND IMMEDIATELY

- Mixture (memory) — **IDLE CUTOFF**
- Fuel selector (memory) — **OFF**
- Fuel boost pump / aux transfer switches (memory) — **OFF**
- Master switch (memory) — **OFF**
- Cabin heat / air (memory) — **OFF (wing-root vents open)**
- Airspeed (memory) — **100 KIAS (increase if fire persists until extinguished)**

Do not attempt an engine restart.

- Forced landing — **EXECUTE (see Engine Failure in Flight)**

Electrical Fire in Flight

LAND AS SOON AS POSSIBLE

- Master switch (memory) ..... **OFF**
- Avionics master (memory) ..... **OFF**
- Vents / cabin air / heat (memory) ..... **CLOSED**
- Fire extinguisher ..... **ACTIVATE**
- All other electrical switches (except ignition) ..... **OFF**

After discharging the extinguisher, ventilate the cabin.

▶ Fire out and electrical power necessary?

Yes:

- Master switch ..... **ON**
- Circuit breakers ..... **CHECK – do not reset a faulted breaker**
- Avionics master ..... **ON, then radios one at a time with delay, check for smoke**
- Vents / cabin air ..... **OPEN when fire is completely out**
- Deferred: Electrical fire – faulted circuit isolated, affected equipment unavailable. ..... **NOTED**

No:

Continue with master off. Manual flaps still available; no radios, fuel gauges, boost pump or aux transfer pumps – fly on main-tank fuel only.

- Deferred: Electrical power off – no radio, no fuel gauges, no boost pump or aux transfer; main-tank fuel only. ..... **NOTED**

Cabin Fire

LAND AS SOON AS POSSIBLE

- Master switch (memory) ..... **OFF**
- Vents / cabin air / heat (memory) ..... **CLOSED**
- Fire extinguisher ..... **ACTIVATE**
- Cabin ..... **VENTILATE after fire is out**
- Land ..... **AS SOON AS POSSIBLE, inspect for damage**

Emergency Descent

- Throttle (memory) ..... **IDLE**
- Propeller (memory) ..... **HIGH RPM (full forward – maximum drag)**
- Mixture (memory) ..... **RICH**
- Flaps (memory) ..... **0°**
- Airspeed (memory) ..... **approx 135 KIAS smooth air (Vno) / approx 110 KIAS turbulence (Va)**
- Power ..... **CLEAR ENGINE periodically**

Alternative with structural damage suspected: flaps 40° and approx 85 KIAS maximum (48° / 80 KIAS gives the steepest path at low speed).

Loss of Directional Control / Ground Loop on Landing

Swing developing on landing roll or takeoff roll

- Rudder (memory) ..... **FULL OPPOSITE to swing, immediately**
- Stick (memory) ..... **BACK (three-point) – keep tailwheel loaded; aileron into wind**

▶ Swing controllable?

Yes:

- Brakes ..... **DIFFERENTIAL as required, smoothly**
- Roll-out ..... **CONTINUE, taxi clear, inspect oleo legs, tailwheel spring and steering chains**

No – airborne speed available:

- Throttle ..... **FULL POWER, go around, flaps as set (reduce 48° to 24°–40° when climbing)**
- Directional control ..... **RIGHT RUDDER for power swing**

No – too slow:

- Throttle ..... **IDLE**
- Mixture ..... **IDLE CUTOFF, ignition OFF if departure from the runway is certain**
- Stick ..... **FULL BACK, brakes as the swing dictates – accept the loop rather than nose over**

Prototype content. Verify against the operator's approved checklist and the POH/AFM before any use. AeroE Checklist 7f510494 · 2026-11-07