Cessna 208B Grand Caravan (C208B)

Pratt & Whitney PT6A-114A, 675 shp · 1 + 9 to 13 seats · Typical 208B (PT6A-114A) procedures; operator checklist may differ.

V-speeds & limits

Vr	**70–75 KIAS**
Vx	**72 KIAS**
Vy	**104 KIAS**
Best glide	**95 KIAS**
Vfe	**175 / 150 / 125 KIAS (10° / 20° / 30°)**
Va	**148 KIAS (8,750 lb)**
Vmo	**175 KIAS**
Vref	**75–85 KIAS**

Normal procedures

Before Start

Preflight inspection	**COMPLETE**
Seats, belts, harnesses	**ADJUST & LOCK**
Brakes	**TEST & SET**
Fuel selectors	**BOTH ON**
Fuel shutoff	**ON (push in)**
Emergency power lever	**NORMAL**
Power lever	**IDLE**
Propeller control	**MAX**
Fuel condition lever	**CUTOFF**
Avionics switches	**OFF**
Bleed air heat	**OFF**
Battery switch	**ON**
Annunciators	**CHECK (no abnormal lights)**
Fuel quantity	**CHECK**
Beacon	**ON**

Engine Start

Propeller area	**CLEAR**
Fuel boost	**ON**
Starter switch	**START**
Oil pressure	**CHECK rising**
Ng	**12% minimum (stable)**
Fuel condition lever	**LOW IDLE**
ITT	**MONITOR (1090°C max)**
Ng	**52% minimum**
Starter switch	**OFF**
Oil pressure	**CHECK in limits**
Starter annunciator	**OFF**
Generator	**CHECK charging**
Fuel boost	**NORM**
Avionics switches	**ON**
Engine instruments	**CHECK**

Before Taxi

Inertial separator	**BYPASS (as required)**
Flight instruments / avionics	**CHECK & SET**
Altimeters	**SET**
Trims	**SET for takeoff**
Autopilot	**CHECK**
Brakes	**CHECK during taxi**

Before Takeoff

Flight controls	**FREE & CORRECT**
Overspeed governor	**CHECK**
Propeller	**EXERCISE**
Standby power	**CHECK**
Engine instruments	**CHECK**
Fuel selectors	**BOTH ON**
Fuel condition lever	**HIGH IDLE**
Wing flaps	**SET (10°–20°)**
Trims	**SET**
Inertial separator	**NORMAL (unless contaminated)**
Pitot heat	**AS REQUIRED**
Lights	**AS REQUIRED**
Transponder	**ALT**
Doors	**LOCKED**
Takeoff briefing	**COMPLETE**

After Takeoff / Climb

Wing flaps	**UP (above 85 KIAS)**
Climb power	**SET (torque / ITT / Ng in limits)**
Propeller	**1600–1900 RPM**
Fuel boost	**NORM**
Engine instruments	**CHECK**

Cruise

Cruise power	**SET**
Fuel quantity / balance	**CHECK**
Engine instruments	**CHECK**
Pressure altitude / temperature	**NOTED**

Descent

Altimeters	**SET**
Fuel selectors	**BOTH ON**
Inertial separator	**AS REQUIRED**
Approach briefing	**COMPLETE**

Before Landing

Fuel selectors	**BOTH ON**
Fuel boost	**NORM**
Propeller	**MAX**
Wing flaps	**AS REQUIRED (full for landing)**
Airspeed	**SET (ref 75–85 KIAS)**
Landing lights	**ON**

After Landing

Wing flaps	**UP**
Trims	**SET**
Transponder	**STBY / as required**
Lights	**AS REQUIRED**
Inertial separator	**BYPASS**

Shutdown

Parking brake	**SET**
Avionics switches	**OFF**
Fuel boost	**OFF**
Propeller	**MAX**
Fuel condition lever	**CUTOFF**
ITT	**MONITOR during coast-down**
Propeller	**FEATHER (after Ng stops)**
Fuel shutoff	**OFF (pull out)**
Lights / battery	**OFF**
Control lock	**INSTALL**

Abnormal procedures

GENERATOR OFF annunciator

Generator switch ..... **RESET then ON**

▶ Generator restored?

Yes:

- Generator load ..... **MONITOR**

No:

- Generator switch ..... **TRIP**
- Non-essential electrical load ..... **REDUCE**
- Battery ..... **MONITOR (approx 30 min endurance)**
- Deferred: Generator failed – on battery power, limited electrical endurance. Land as soon as practical. ..... **NOTED**

Low Oil Pressure

OIL PRESS LOW annunciator or indication below limits

Oil pressure / temperature ..... **CHECK**

▶ Oil pressure confirmed low (below 85 psi)?

Yes:

- Power ..... **REDUCE to minimum required**
- Engine ..... **MONITOR for seizure indications**
- Deferred: Low oil pressure – land as soon as possible, expect possible engine failure. ..... **NOTED**

No – gauge fault:

- Flight ..... **CONTINUE, monitor oil temperature**

FUEL PRESS LOW annunciator

Fuel boost ..... **ON**

Fuel selectors ..... **BOTH ON**

Fuel quantity ..... **CHECK**

▶ Annunciator extinguished?

Yes:

- Fuel boost ..... **LEAVE ON**
- Deferred: Fuel boost pump on continuously – engine-driven pump suspect. ..... **NOTED**

No:

- Fuel contamination / exhaustion ..... **CONSIDER**
- Land ..... **AS SOON AS POSSIBLE**

FUEL SELECT OFF annunciator

Fuel selectors ..... **CHECK BOTH ON**

Fuel selector warning ..... **CHECK**

Inadvertent Icing

Pitot / static heat ..... **ON**

Inertial separator ..... **BYPASS**

Windshield / propeller anti-ice ..... **ON (if fitted)**

Exit icing conditions ..... **TURN / CLIMB / DESCEND**

Airspeed ..... **INCREASE (flaps-up landing)**

Wing flaps ..... **LIMIT to 10° for landing with residual ice**

Deferred: Residual airframe ice – flaps-up / 10° landing, increased approach speed. ..... **NOTED**

CHIP DETECTOR annunciator

Engine instruments ..... **MONITOR closely**

Power ..... **REDUCE to minimum practical**

Deferred: Chip detector – land as soon as practical, maintenance inspection required. ..... **NOTED**

VOLTAGE LOW annunciator

Generator ..... **CHECK ON / charging**

Electrical load ..... **REDUCE**

▶ Voltage recovered?

Yes:

Flight ..... **CONTINUE, monitor**

No:

Refer to GENERATOR OFF procedure.

Flap Failure

Flap circuit breaker ..... **CHECK / RESET once**

Standby flap motor ..... **ON (if fitted)**

▶ Flaps operable?

Yes:

Flap setting ..... **AS REQUIRED**

No:

Landing ..... **FLAPS UP – 95 KIAS approach, longer runway**

Deferred: Flaps inoperative – flaps-up landing, increased landing distance. ..... **NOTED**

Emergency procedures

Engine Failure after Takeoff

Airborne, insufficient runway remaining

LAND IMMEDIATELY

Airspeed (memory) ..... **85 KIAS (flaps up) / 75 KIAS (flaps down)**

Power lever (memory) ..... **IDLE**

Propeller (memory) ..... **FEATHER**

Fuel condition lever (memory) ..... **CUTOFF**

Wing flaps (memory) ..... **AS REQUIRED**

Fuel shutoff (memory) ..... **OFF**

Battery switch (memory) ..... **OFF**

Land straight ahead with only small changes of direction. Do not attempt a turn back.

Engine Failure in Flight

Loss of power with altitude available

LAND AS SOON AS POSSIBLE

Airspeed (memory)	**95 KIAS (best glide)**
Propeller (memory)	**FEATHER**
Emergency power lever (memory)	**NORMAL**

▶ Restart attempt practicable?

Yes – restart:

Fuel condition lever	**CUTOFF**
Ignition	**ON**
Fuel boost	**ON**
Starter	**START (Ng 12% min)**
Fuel condition lever	**LOW IDLE**
ITT	**MONITOR**
Propeller	**MAX (once running)**

▶ Engine restarted?

Yes:

Power	**AS REQUIRED**
Engine instruments	**MONITOR**
Deferred: Engine restarted after in-flight failure – land as soon as possible and report.	**NOTED**

No:

Continue with forced landing.

No – forced landing:

Forced landing without power:

Seats / belts / harnesses	**SECURE**
Wing flaps	**AS REQUIRED (full on final)**
Airspeed	**75–80 KIAS**
Fuel shutoff	**OFF**
Fuel condition lever	**CUTOFF**
Battery switch	**OFF (when no longer required)**
Doors	**UNLATCH before touchdown**

Engine Fire in Flight

LAND IMMEDIATELY

Fuel condition lever (memory)	**CUTOFF**
Fuel shutoff (memory)	**OFF**
Propeller (memory)	**FEATHER**
Cabin heat (memory)	**OFF**
Bleed air heat (memory)	**OFF**
Airspeed	**95 KIAS (or higher if fire persists)**
Forced landing	**EXECUTE (do not attempt restart)**

Engine Fire During Start

Starter (memory)	**CONTINUE cranking (purge)**
Fuel condition lever (memory)	**CUTOFF**
Fuel shutoff (memory)	**OFF**
Fuel boost	**OFF**
Starter	**OFF (after ITT decreases)**
Battery switch	**OFF**
Fire extinguisher	**OBTAIN**
Aircraft	**EVACUATE**

Cabin / Electrical Fire

LAND AS SOON AS POSSIBLE

Battery switch (memory)	**OFF**
Avionics switches (memory)	**OFF**
Cabin heat / vents	**CLOSE**
Fire extinguisher	**ACTIVATE**

After discharge, ventilate the cabin.

▶ Fire out and electrical power required?

Yes:

Circuit breakers	**CHECK – do not reset faulted**
Battery switch	**ON**
Avionics / electrical	**ON one at a time, check for smoke**
Deferred: Electrical fire – suspect circuits isolated, affected systems unavailable.	**NOTED**

No:

Continue with battery off. Standby instruments only.

Emergency Descent

Power lever (memory)	**IDLE**
Propeller (memory)	**MAX**
Wing flaps (memory)	**UP**
Airspeed (memory)	**175 KIAS (smooth air) / 148 KIAS (turbulence)**

Prototype content. Verify against the operator's approved checklist and the POH/AFM before any use. AeroE Checklist version 1.7 (build 849ad9ab) · 2026-11-07