# Cessna 208B Grand Caravan (C208B)

Pratt & Whitney PT6A-114A, 675 shp · 1 + 9 to 13 seats · Typical 208B (PT6A-114A) procedures; operator checklist may differ.

## V-speeds & limits

| | |
|---|---|
| Vr | **70–75 KIAS** |
| Vx | **72 KIAS** |
| Vy | **104 KIAS** |
| Best glide | **95 KIAS** |
| Vfe | **175 / 150 / 125 KIAS (10° / 20° / 30°)** |
| Va | **148 KIAS (8,750 lb)** |
| Vmo | **175 KIAS** |
| Vref | **75–85 KIAS** |

## Normal procedures

### Before Start

| | |
|---|---|
| Preflight inspection | **COMPLETE** |
| Seats, belts, harnesses | **ADJUST & LOCK** |
| Brakes | **TEST & SET** |
| Fuel selectors | **BOTH ON** |
| Fuel shutoff | **ON (push in)** |
| Emergency power lever | **NORMAL** |
| Power lever | **IDLE** |
| Propeller control | **MAX** |
| Fuel condition lever | **CUTOFF** |
| Avionics switches | **OFF** |
| Bleed air heat | **OFF** |
| Battery switch | **ON** |
| Annunciators | **CHECK (no abnormal lights)** |
| Fuel quantity | **CHECK** |
| Beacon | **ON** |

## Engine Start

| | |
|---|---|
| Propeller area | **CLEAR** |
| Fuel boost | **ON** |
| Starter switch | **START** |
| Oil pressure | **CHECK rising** |
| Ng | **12% minimum (stable)** |
| Fuel condition lever | **LOW IDLE** |
| ITT | **MONITOR (1090°C max)** |
| Ng | **52% minimum** |
| Starter switch | **OFF** |
| Oil pressure | **CHECK in limits** |
| Starter annunciator | **OFF** |
| Generator | **CHECK charging** |
| Fuel boost | **NORM** |
| Avionics switches | **ON** |
| Engine instruments | **CHECK** |

## Before Taxi

| | |
|---|---|
| Inertial separator | **BYPASS (as required)** |
| Flight instruments / avionics | **CHECK & SET** |
| Altimeters | **SET** |
| Trims | **SET for takeoff** |
| Autopilot | **CHECK** |
| Brakes | **CHECK during taxi** |

## Before Takeoff

| | |
|---|---|
| Flight controls | **FREE & CORRECT** |
| Overspeed governor | **CHECK** |
| Propeller | **EXERCISE** |
| Standby power | **CHECK** |
| Engine instruments | **CHECK** |
| Fuel selectors | **BOTH ON** |
| Fuel condition lever | **HIGH IDLE** |
| Wing flaps | **SET (10°–20°)** |
| Trims | **SET** |
| Inertial separator | **NORMAL (unless contaminated)** |
| Pitot heat | **AS REQUIRED** |
| Lights | **AS REQUIRED** |
| Transponder | **ALT** |
| Doors | **LOCKED** |
| Takeoff briefing | **COMPLETE** |

### After Takeoff / Climb

| | |
|---|---|
| Wing flaps | **UP (above 85 KIAS)** |
| Climb power | **SET (torque / ITT / Ng in limits)** |
| Propeller | **1600–1900 RPM** |
| Fuel boost | **NORM** |
| Engine instruments | **CHECK** |

### Cruise

| | |
|---|---|
| Cruise power | **SET** |
| Fuel quantity / balance | **CHECK** |
| Engine instruments | **CHECK** |
| Pressure altitude / temperature | **NOTED** |

### Descent

| | |
|---|---|
| Altimeters | **SET** |
| Fuel selectors | **BOTH ON** |
| Inertial separator | **AS REQUIRED** |
| Approach briefing | **COMPLETE** |

### Before Landing

| | |
|---|---|
| Fuel selectors | **BOTH ON** |
| Fuel boost | **NORM** |
| Propeller | **MAX** |
| Wing flaps | **AS REQUIRED (full for landing)** |
| Airspeed | **SET (ref 75–85 KIAS)** |
| Landing lights | **ON** |

### After Landing

| | |
|---|---|
| Wing flaps | **UP** |
| Trims | **SET** |
| Transponder | **STBY / as required** |
| Lights | **AS REQUIRED** |
| Inertial separator | **BYPASS** |

### Shutdown

| | |
|---|---|
| Parking brake | **SET** |
| Avionics switches | **OFF** |
| Fuel boost | **OFF** |
| Propeller | **MAX** |
| Fuel condition lever | **CUTOFF** |
| ITT | **MONITOR during coast-down** |
| Propeller | **FEATHER (after Ng stops)** |
| Fuel shutoff | **OFF (pull out)** |
| Lights / battery | **OFF** |
| Control lock | **INSTALL** |

# Abnormal procedures

## GENERATOR OFF annunciator

Generator switch ..... **RESET then ON**

**▶ Generator restored?**

**Yes:**

- Generator load ..... **MONITOR**

**No:**

- Generator switch ..... **TRIP**
- Non-essential electrical load ..... **REDUCE**
- Battery ..... **MONITOR (approx 30 min endurance)**
- Deferred: Generator failed – on battery power, limited electrical endurance. Land as soon as practical. ..... **NOTED**

## Low Oil Pressure

OIL PRESS LOW annunciator or indication below limits

Oil pressure / temperature ..... **CHECK**

**▶ Oil pressure confirmed low (below 85 psi)?**

**Yes:**

- Power ..... **REDUCE to minimum required**
- Engine ..... **MONITOR for seizure indications**
- Deferred: Low oil pressure – land as soon as possible, expect possible engine failure. ..... **NOTED**

**No – gauge fault:**

- Flight ..... **CONTINUE, monitor oil temperature**

## FUEL PRESS LOW annunciator

Fuel boost ..... **ON**

Fuel selectors ..... **BOTH ON**

Fuel quantity ..... **CHECK**

**▶ Annunciator extinguished?**

**Yes:**

- Fuel boost ..... **LEAVE ON**
- Deferred: Fuel boost pump on continuously – engine-driven pump suspect. ..... **NOTED**

**No:**

- Fuel contamination / exhaustion ..... **CONSIDER**
- Land ..... **AS SOON AS POSSIBLE**

## FUEL SELECT OFF annunciator

Fuel selectors ..... **CHECK BOTH ON**

Fuel selector warning ..... **CHECK**

## Inadvertent Icing

Pitot / static heat ..... **ON**

Inertial separator ..... **BYPASS**

Windshield / propeller anti-ice ..... **ON (if fitted)**

Exit icing conditions ..... **TURN / CLIMB / DESCEND**

Airspeed ..... **INCREASE (flaps-up landing)**

Wing flaps ..... **LIMIT to 10° for landing with residual ice**

Deferred: Residual airframe ice – flaps-up / 10° landing, increased approach speed. ..... **NOTED**

### CHIP DETECTOR annunciator

Engine instruments ..... **MONITOR closely**

Power ..... **REDUCE to minimum practical**

Deferred: Chip detector – land as soon as practical, maintenance inspection required. ..... **NOTED**

### VOLTAGE LOW annunciator

Generator ..... **CHECK ON / charging**

Electrical load ..... **REDUCE**

**▶ Voltage recovered?**

**Yes:**

Flight ..... **CONTINUE, monitor**

**No:**

Refer to GENERATOR OFF procedure.

### Flap Failure

Flap circuit breaker ..... **CHECK / RESET once**

Standby flap motor ..... **ON (if fitted)**

**▶ Flaps operable?**

**Yes:**

Flap setting ..... **AS REQUIRED**

**No:**

Landing ..... **FLAPS UP – 95 KIAS approach, longer runway**

Deferred: Flaps inoperative – flaps-up landing, increased landing distance. ..... **NOTED**

## Emergency procedures

### Engine Failure after Takeoff

Airborne, insufficient runway remaining

**LAND IMMEDIATELY**

Airspeed (memory) ..... **85 KIAS (flaps up) / 75 KIAS (flaps down)**

Power lever (memory) ..... **IDLE**

Propeller (memory) ..... **FEATHER**

Fuel condition lever (memory) ..... **CUTOFF**

Wing flaps (memory) ..... **AS REQUIRED**

Fuel shutoff (memory) ..... **OFF**

Battery switch (memory) ..... **OFF**

Land straight ahead with only small changes of direction. Do not attempt a turn back.

## Engine Failure in Flight

Loss of power with altitude available

**LAND AS SOON AS POSSIBLE**

| | |
|---|---|
| Airspeed (memory) | **95 KIAS (best glide)** |
| Propeller (memory) | **FEATHER** |
| Emergency power lever (memory) | **NORMAL** |

**▶ Restart attempt practicable?**

**Yes – restart:**

| | |
|---|---|
| Fuel condition lever | **CUTOFF** |
| Ignition | **ON** |
| Fuel boost | **ON** |
| Starter | **START (Ng 12% min)** |
| Fuel condition lever | **LOW IDLE** |
| ITT | **MONITOR** |
| Propeller | **MAX (once running)** |

**▶ Engine restarted?**

**Yes:**

| | |
|---|---|
| Power | **AS REQUIRED** |
| Engine instruments | **MONITOR** |
| Deferred: Engine restarted after in-flight failure – land as soon as possible and report. | **NOTED** |

**No:**

Continue with forced landing.

**No – forced landing:**

Forced landing without power:

| | |
|---|---|
| Seats / belts / harnesses | **SECURE** |
| Wing flaps | **AS REQUIRED (full on final)** |
| Airspeed | **75–80 KIAS** |
| Fuel shutoff | **OFF** |
| Fuel condition lever | **CUTOFF** |
| Battery switch | **OFF (when no longer required)** |
| Doors | **UNLATCH before touchdown** |

## Engine Fire in Flight

**LAND IMMEDIATELY**

| | |
|---|---|
| Fuel condition lever (memory) | **CUTOFF** |
| Fuel shutoff (memory) | **OFF** |
| Propeller (memory) | **FEATHER** |
| Cabin heat (memory) | **OFF** |
| Bleed air heat (memory) | **OFF** |
| Airspeed | **95 KIAS (or higher if fire persists)** |
| Forced landing | **EXECUTE (do not attempt restart)** |

## Engine Fire During Start

- Starter (memory) ..... **CONTINUE cranking (purge)**
- Fuel condition lever (memory) ..... **CUTOFF**
- Fuel shutoff (memory) ..... **OFF**
- Fuel boost ..... **OFF**
- Starter ..... **OFF (after ITT decreases)**
- Battery switch ..... **OFF**
- Fire extinguisher ..... **OBTAIN**
- Aircraft ..... **EVACUATE**

## Cabin / Electrical Fire

**LAND AS SOON AS POSSIBLE**

- Battery switch (memory) ..... **OFF**
- Avionics switches (memory) ..... **OFF**
- Cabin heat / vents ..... **CLOSE**
- Fire extinguisher ..... **ACTIVATE**

After discharge, ventilate the cabin.

### ▶ Fire out and electrical power required?

**Yes:**

- Circuit breakers ..... **CHECK – do not reset faulted**
- Battery switch ..... **ON**
- Avionics / electrical ..... **ON one at a time, check for smoke**
- Deferred: Electrical fire – suspect circuits isolated, affected systems unavailable. ..... **NOTED**

**No:**

Continue with battery off. Standby instruments only.

## Emergency Descent

- Power lever (memory) ..... **IDLE**
- Propeller (memory) ..... **MAX**
- Wing flaps (memory) ..... **UP**
- Airspeed (memory) ..... **175 KIAS (smooth air) / 148 KIAS (turbulence)**

---

Prototype content. Verify against the operator's approved checklist and the POH/AFM before any use. AeroE Checklist version 1.7 (build 0d080c7b) · 2026-11-07