X200 Router User Manual

Page 1 - Getting started
Connect the WAN port to your modem with the included cable.
Power on the router and wait for the status LED to turn solid white (about 2 minutes).
Open the admin console at http://192.168.1.1 and sign in with the password
printed on the label under the router.
Firmware 3.2 and later use http://router.local instead (see the release notes).

Solid white: connected to the internet.
Pulsing white: starting up or updating firmware. Do not unplug.
Solid amber: no internet connection. Check the modem and the WAN cable.
Blinking red: an error. Read the code in the admin console (see page 3).

E101 - Overheating. Move the router to a ventilated place; it restarts when cool.
E204 - WAN link down. The modem is not responding. Restart the modem, then the router.
E310 - Firmware verification failed. Download the firmware again and retry the update.
E415 - Too many devices. The X200 supports up to 128 connected devices.

Restart: hold the reset button for 3 seconds.
Factory reset: hold the reset button for 15 seconds until the LED blinks amber.
A factory reset erases all settings, including Wi-Fi names and passwords.
Firmware updates are installed from Settings > Firmware > Check for updates.

Wi-Fi 6E tri-band (2.4, 5 and 6 GHz), up to 5.4 Gbps combined.
Ports: one 2.5 Gbps WAN port, four 1 Gbps LAN ports, one USB-C port.
Coverage: up to 2,500 square feet.
Warranty: 2 years limited hardware warranty from the date of purchase.