

Arista Access Switch - ALARM_1118 - Critical Alarm SOP

Node: Arista-Access-Chennai-TN-96 | **Vendor:** Arista | **Severity:** Critical | **Alarm Code:** ALARM_1118

Description

This SOP outlines the procedures to troubleshoot and resolve a Critical Alarm (ALARM_1118) on Arista Access Switch - Arista-Access-Chennai-TN-96.

Potential Root Causes

Cause	Probability
Hardware Failure	High
Software Misconfiguration	Medium
Environmental Issues (Temperature, Power)	Low

Diagnostic Commands

```
show system resources
show hardware
show bootvars
show interface status
show environment
```

Resolution Steps

- Step 1: {'Step': '1. Check system resources and hardware status', 'Action': 'Verify that system resources are within normal limits and hardware is functioning properly. Run the command: "show system resources"', 'CLI_Commands': 'show system resources'}
- Step 2: {'Step': '2. Check boot variables', 'Action': 'Verify that boot variables are correctly configured. Run the command: "show bootvars"', 'CLI_Commands': 'show bootvars'}
- Step 3: {'Step': '3. Check interface status', 'Action': 'Verify that all interfaces are up and functioning properly. Run the command: "show interface status"', 'CLI_Commands': 'show interface status'}
- Step 4: {'Step': '4. Check environment', 'Action': 'Verify that temperature and power levels are within normal limits. Run the command: "show environment"', 'CLI_Commands': 'show environment'}
- Step 5: {'Step': '5. Reboot the switch', 'Action': 'Reboot the switch to clear any software issues. Run the command: "reload"', 'CLI_Commands': 'reload'}

Step 6: {'Step': '6. Verify the issue is resolved', 'Action': 'Run the diagnostic commands again to verify that the issue is resolved.', 'CLI_Commands': 'show system resources, show hardware, show bootvars, show interface status, show environment'}

Post-Check Verification

```
show system resources
show hardware
show bootvars
show interface status
show environment
```