

Arista Access Switch ALARM_9316 SOP

Node: Arista-Access-Kolkata-WB-108 | **Vendor:** Arista | **Severity:** Warning | **Alarm Code:** ALARM_9316

Description

This SOP outlines the procedure to diagnose and resolve the ALARM_9316 (Warning) on the Arista Access Switch Node ID: Arista-Access-Kolkata-WB-108.

Potential Root Causes

Cause	Probability
Hardware failure in one of the ports	High
Incorrect configuration or settings	Medium
Software issue or bug	Low

Diagnostic Commands

```
show inventory | grep "Port 26"
show version | grep "System Boot"
show interface status | grep "port 26"
show log | grep "ALARM_9316"
```

Resolution Steps

- Step 1: {'Step': 'Verify the port status and check for any hardware failure', 'Action': 'Run the command "show interface status | grep "port 26"" to check the port status.'}
- Step 2: {'Step': 'Check the configuration and settings', 'Action': 'Run the command "show run | grep "interface port 26"" to check the configuration.'}
- Step 3: {'Step': 'Reset the port or replace the hardware if faulty', 'Action': 'Run the command "clear interface port 26" to reset the port.'}
- Step 4: {'Step': 'Verify the issue is resolved', 'Action': 'Run the command "show log | grep "ALARM_9316"" to verify the alarm is cleared.'}

Post-Check Verification

```
show log | grep "ALARM_9316"
show interface status | grep "port 26"
show version | grep "System Boot"
```