

Arista Access Switch Alarm SOP - ALARM_4814

Node: Arista-Access-Kolkata-WB-116 | **Vendor:** Arista | **Severity:** Warning | **Alarm Code:** ALARM_4814

Description

This Standard Operating Procedure (SOP) outlines the steps to diagnose and resolve the ALARM_4814 issue on the Arista Access Switch (Node ID: Arista-Access-Kolkata-WB-116). The alarm indicates a warning condition.

Potential Root Causes

Cause	Probability
Incorrect configuration	High
Hardware failure	Medium
Software issue	Low

Diagnostic Commands

```
show system internal alarm-history
show system internal alarm-criteria
show interface detail
show hardware internal temperature
```

Resolution Steps

- Step 1: {'Step': 'Check system logs for any errors or warnings', 'Action': 'show system internal log-messages'}
- Step 2: {'Step': 'Verify configuration', 'Action': 'show running-config'}
- Step 3: {'Step': 'Reset interface', 'Action': 'interface Ethernet1/1, reset'}
- Step 4: {'Step': 'Replace hardware if faulty', 'Action': 'Replace the faulty hardware with a new one'}
- Step 5: {'Step': 'Upgrade software if necessary', 'Action': 'upgrade software to the latest version'}

Post-Check Verification

```
show system internal alarm-history
show interface detail
show hardware internal temperature
```