

Cisco Access Switch SOP for ALARM_5527: Critical Error

Node: Cisco-Access-Chennai-TN-106 | **Vendor:** Cisco | **Severity:** Critical | **Alarm Code:** ALARM_5527

Description

ALARM_5527 Critical Error on Cisco Access Switch (Cisco-Access-Chennai-TN-106) indicates a severe issue that requires immediate attention. This SOP outlines the steps to diagnose and resolve the issue.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Spanning Tree Protocol (STP) Issues	Medium
Misconfigured VLANs or Trunks	Low

Diagnostic Commands

```
show process cpu | exclude kthread
show spanning-tree brief
show vlan
show interface trunk
```

Resolution Steps

Step 1: {'Step': '1. Check CPU Utilization', 'Action': "Run the command 'show process cpu | exclude kthread' to check CPU utilization. If CPU utilization is high, consider rebooting the device or upgrading CPU resources.", 'CLI_Command': 'reload'}

Step 2: {'Step': '2. Verify STP Configuration', 'Action': "Run the command 'show spanning-tree brief' to verify STP configuration. If STP is misconfigured, correct the settings.", 'CLI_Command': 'spanning-tree vlan 1-1000 root primary'}

Step 3: {'Step': '3. Check VLAN and Trunk Configuration', 'Action': "Run the command 'show vlan' to verify VLAN configuration. Run the command 'show interface trunk' to verify trunk configuration. If VLANs or trunks are misconfigured, correct the settings.", 'CLI_Command': 'vlan 1000 name "VLAN1000"'}

Step 4: {'Step': '4. Reboot the Device', 'Action': 'Reboot the device to ensure all changes take effect.', 'CLI_Command': 'reload'}

Post-Check Verification

```
show process cpu | exclude kthread  
show spanning-tree brief  
show vlan  
show interface trunk
```