

Standard Operating Procedure: ALARM_6400 on Cisco-Access-Delhi-NCR-16

Node: Cisco-Access-Delhi-NCR-16 | **Vendor:** Cisco | **Severity:** Minor | **Alarm Code:** ALARM_6400

Description

ALARM_6400 is a minor alarm triggered on Cisco-Access-Delhi-NCR-16, indicating a potential issue with the access switch.

Potential Root Causes

Cause	Probability
Excessive Broadcast Traffic	Medium
Misconfigured VLANs	Low
Hardware Fault	High

Diagnostic Commands

```
show int status
show mac address-table
show vlan
show bgp summary
```

Resolution Steps

- Step 1: {'Step': 'Check for excessive broadcast traffic', 'Action': "Use 'show int status' command to verify if any interface is experiencing high broadcast traffic.", 'CLI_Command': 'show int status'}
- Step 2: {'Step': 'Verify VLAN configuration', 'Action': "Use 'show vlan' command to verify VLAN configuration and ensure it matches the design.", 'CLI_Command': 'show vlan'}
- Step 3: {'Step': 'Check for hardware faults', 'Action': "Use 'show int status' command to verify if any interface is experiencing a hardware fault.", 'CLI_Command': 'show int status'}
- Step 4: {'Step': 'Reset the switch', 'Action': 'Perform a hard reset of the switch to resolve the issue.', 'CLI_Command': 'reload'}

Post-Check Verification

```
show int status
show mac address-table
show vlan
```

```
show bgp summary
```