

Standard Operating Procedure for Resolving Alarm ALARM_3351 on Cisco Access Switch Cisco-Access-Delhi-NCR-20

Node: Cisco-Access-Delhi-NCR-20 | **Vendor:** Cisco | **Severity:** Major | **Alarm Code:** ALARM_3351

Description

This SOP outlines the steps to diagnose, resolve, and verify the fix for Alarm ALARM_3351 on Cisco Access Switch Cisco-Access-Delhi-NCR-20.

Potential Root Causes

Cause	Probability
Power supply failure	High
Overheating	Medium
Hardware failure	Low

Diagnostic Commands

```
show power inline
show env all
show diag
```

Resolution Steps

- Step 1: {'Step': 'Power cycle the switch', 'Action': 'Perform a cold reboot of the switch'}
- Step 2: {'Step': 'Check power supply', 'Action': "Verify power supply is functioning correctly using 'show power inline' command", 'CLI_Command': 'show power inline'}
- Step 3: {'Step': 'Check temperature', 'Action': "Verify temperature is within normal range using 'show env all' command", 'CLI_Command': 'show env all'}
- Step 4: {'Step': 'Inspect hardware', 'Action': 'Inspect the switch for any visible signs of hardware failure'}
- Step 5: {'Step': 'Replace faulty component', 'Action': 'Replace the faulty power supply or other hardware component as needed'}

Post-Check Verification

```
show power inline
show env all
```

```
show diag
```