

Cisco Access Switch - Alarm Resolution SOP for ALARM_4894

Node: Cisco-Access-Delhi-NCR-20 | **Vendor:** Cisco | **Severity:** Critical | **Alarm Code:** ALARM_4894

Description

This Standard Operating Procedure (SOP) outlines the steps to diagnose and resolve the Alarm Code ALARM_4894 on the Cisco Access Switch Node ID: Cisco-Access-Delhi-NCR-20.

Potential Root Causes

Cause	Probability
High CPU utilization due to software bugs or configuration issues	High
Stacking issues or misconfiguration	Medium
Hardware failure or malfunction	Low

Diagnostic Commands

```
show processes cpu
show system resources
show spanning-tree
show stack
show interface status
```

Resolution Steps

- Step 1: {'Step': '1', 'Action': "Check CPU utilization and system resources using 'show processes cpu' and 'show system resources' commands.", 'CLI_Commands': ['show processes cpu', 'show system resources']}
- Step 2: {'Step': '2', 'Action': "Verify spanning tree configuration and stack topology using 'show spanning-tree' and 'show stack' commands.", 'CLI_Commands': ['show spanning-tree', 'show stack']}
- Step 3: {'Step': '3', 'Action': "Inspect interface status using 'show interface status' command and verify for any misconfigured or faulty interfaces.", 'CLI_Commands': ['show interface status']}
- Step 4: {'Step': '4', 'Action': 'If high CPU utilization is observed, reboot the switch and verify the alarm status.', 'CLI_Commands': []}

Post-Check Verification

```
show processes cpu
```

```
show system resources
show spanning-tree
show stack
show interface status
```