

SOP for Cisco Access Switch Node:

Cisco-Access-Delhi-NCR-26 - Alarm ALARM_5332 (Warning)

Node: Cisco-Access-Delhi-NCR-26 | **Vendor:** Cisco | **Severity:** Warning | **Alarm Code:** ALARM_5332

Description

Alarm ALARM_5332 is triggered when there is a mismatch between the System MAC and the Spanning Tree MAC on the Cisco Access Switch.

Potential Root Causes

Cause	Probability
Spanning Tree MAC mismatch with System MAC	High
Incorrect configuration of System MAC	Medium
Hardware failure of the switch	Low

Diagnostic Commands

```
show spanning-tree | include System MAC
show spanning-tree | include Bridge ID
show system mac-address
show hardware internal temperature
```

Resolution Steps

- Step 1: {'Step': 'Verify the System MAC and Spanning Tree MAC', 'Description': "Compare the System MAC and Spanning Tree MAC using the commands 'show spanning-tree | include System MAC' and 'show spanning-tree | include Bridge ID'. If the MACs do not match, proceed to the next step.", 'Commands': ['show spanning-tree | include System MAC', 'show spanning-tree | include Bridge ID']}
- Step 2: {'Step': 'Correct the System MAC configuration', 'Description': "Use the command 'system mac-address ' to correct the System MAC. Note down the new MAC before making any changes.", 'Commands': ['system mac-address ']}
- Step 3: {'Step': 'Reboot the switch', 'Description': 'Reboot the switch to ensure the changes take effect.', 'Commands': ['reload']}

Post-Check Verification

```
show spanning-tree | include System MAC
```

```
show spanning-tree | include Bridge ID  
show system mac-address
```