

# Standard Operating Procedure: Cisco Access Switch Alarm ALARM\_9838

**Node:** Cisco-Access-Delhi-NCR-26 | **Vendor:** Cisco | **Severity:** Warning | **Alarm Code:** ALARM\_9838

## Description

This SOP outlines the steps to diagnose and resolve a warning alarm (ALARM\_9838) on Cisco Access Switch (Node ID: Cisco-Access-Delhi-NCR-26).

## Potential Root Causes

| Cause                                                           | Probability |
|-----------------------------------------------------------------|-------------|
| Incompatible firmware version on the Access Switch.             | High        |
| Network congestion leading to packet loss.                      | Medium      |
| Physical layer issues (e.g., cable problems, port malfunction). | Low         |

## Diagnostic Commands

```
show interface status | include Cisco-Access-Delhi-NCR-26
show tech-support
show logging | include ALARM_9838
show run | include alarm-settings
```

## Resolution Steps

- Step 1: {'Step': 'Verify firmware version and upgrade if necessary.', 'Action': ['show version', 'copy tftp:///firmware.bin flash:']}
- Step 2: {'Step': 'Check network congestion.', 'Action': ['show interface statistics', 'show queueing history']}
- Step 3: {'Step': 'Inspect physical connections and replace faulty cables if necessary.', 'Action': ['show interface status', 'show interface detail']}

## Post-Check Verification

```
show interface status | include Cisco-Access-Delhi-NCR-26
show logging | include ALARM_9838
show run | include alarm-settings
```