

Cisco Access Switch Alarm SOP: ALARM_5932 - Warning

Node: Cisco-Access-Delhi-NCR-32 | **Vendor:** Cisco | **Severity:** Warning | **Alarm Code:** ALARM_5932

Description

This SOP outlines the steps to diagnose and resolve the ALARM_5932 (Warning) on the Cisco Access Switch, Node ID: Cisco-Access-Delhi-NCR-32.

Potential Root Causes

Cause	Probability
Power Supply Failure	High
Temperature Threshold Exceeded	Medium
Fan Failure	Low

Diagnostic Commands

```
show environment
show power
show fan status
show temperature
```

Resolution Steps

Step 1: {'Step': '1. Check Power Supply Status', 'Action': "Issue the command 'show power' to verify the power supply status.", 'CLI_Command': 'show power'}

Step 2: {'Step': '2. Check Temperature Threshold', 'Action': "Issue the command 'show environment temperature' to verify the temperature threshold.", 'CLI_Command': 'show environment temperature'}

Step 3: {'Step': '3. Check Fan Status', 'Action': "Issue the command 'show fan status' to verify the fan status.", 'CLI_Command': 'show fan status'}

Step 4: {'Step': '4. Replace Failed Power Supply/ Fan', 'Action': 'Replace the failed power supply or fan as necessary.', 'CLI_Command': ''}

Post-Check Verification

```
show environment
show power
show fan status
```

show temperature