

Standard Operating Procedure:

Cisco-Access-Kolkata-WB-126 ALARM_1167 Minor Alarm

Node: Cisco-Access-Kolkata-WB-126 | **Vendor:** Cisco | **Severity:** Minor | **Alarm Code:** ALARM_1167

Description

This SOP outlines the steps to identify, diagnose, and resolve the ALARM_1167 minor alarm on Cisco-Access-Kolkata-WB-126, an access switch.

Potential Root Causes

Cause	Probability
Hardware failure or misconfiguration	Medium
Software bug or mismatch	Low
Environmental factors or power supply issues	Low

Diagnostic Commands

```
show logging | include ALARM_1167
show version
show inventory
show run | include ALARM_1167
```

Resolution Steps

- Step 1: {'Step': 'Verify the current configuration and log files for any indications of the alarm', 'Action': "Run the command 'show run | include ALARM_1167' to verify the configuration"}
- Step 2: {'Step': 'Check for hardware issues or misconfiguration', 'Action': "Run the command 'show inventory' to verify the hardware details and 'show run | include ALARM_1167' to verify the configuration"}
- Step 3: {'Step': 'Update the software or firmware if necessary', 'Action': "Run the command 'show version' to verify the current version and then use 'copy tftp' or 'copy scp' commands to update the software or firmware"}
- Step 4: {'Step': 'Check for environmental factors or power supply issues', 'Action': 'Verify the power supply and environmental conditions to ensure they are within the recommended specifications'}

Post-Check Verification

```
show logging | include ALARM_1167
show version
show inventory
show run | include ALARM_1167
ping to verify connectivity
```