

Standard Operating Procedure for ALARM_4697 on Cisco-Access-Mumbai-MH-40

Node: Cisco-Access-Mumbai-MH-40 | **Vendor:** Cisco | **Severity:** Minor | **Alarm Code:** ALARM_4697

Description

ALARM_4697 is a minor alarm indicating a potential issue with the Cisco-Access-Mumbai-MH-40 access switch. This SOP outlines the steps to diagnose and resolve the issue.

Potential Root Causes

Cause	Probability
Insufficient Power Supply	Medium
Faulty Interface Card	High
Misconfigured VLANs	Low

Diagnostic Commands

```
show power inline
show interface status
show interface transceiver detail
show vlan brief
```

Resolution Steps

- Step 1: {'Step': 'Check the power supply to the switch', 'Action': 'Verify the power supply is functioning correctly using the show power inline command'}
- Step 2: {'Step': 'Replace the faulty interface card', 'Action': 'Power off the switch, replace the faulty interface card, and then power on the switch'}
- Step 3: {'Step': 'Verify VLAN configurations', 'Action': 'Use the show vlan brief command to verify VLAN configurations and correct any misconfigurations'}

Post-Check Verification

```
show power inline
show interface status
show vlan brief
```