

Standard Operating Procedure for Ericsson Provider Edge Router Alarm ALARM_6029

Node: Ericsson-PE-Kolkata-WB-129 | **Vendor:** Ericsson | **Severity:** Warning | **Alarm Code:** ALARM_6029

Description

This SOP outlines the steps to troubleshoot and resolve the ALARM_6029 warning on the Ericsson Provider Edge Router (Node ID: Ericsson-PE-Kolkata-WB-129). The alarm is triggered due to a potential issue with the BFD (Bidirectional Forwarding Detection) protocol.

Potential Root Causes

Cause	Probability
BFD protocol configuration issue	High
BFD session timeout	Medium
Hardware or software issue on the Provider Edge Router	Low

Diagnostic Commands

```
show bfd session detail
show bfd session summary
show interface brief
```

Resolution Steps

Step 1: {'Step': 'Check BFD protocol configuration', 'Action': "Verify the BFD protocol configuration on the Provider Edge Router using the command 'show bfd session detail'. Make sure the BFD session is properly configured and the timers are set correctly.", 'CLI_Command': 'show bfd session detail'}

Step 2: {'Step': 'Check BFD session status', 'Action': "Verify the status of the BFD session using the command 'show bfd session summary'. Check if the BFD session is up or down.", 'CLI_Command': 'show bfd session summary'}

Step 3: {'Step': 'Clear BFD session', 'Action': "Clear the BFD session using the command 'clear bfd session'. Then verify the BFD session status again using the 'show bfd session summary' command.", 'CLI_Command': 'clear bfd session'}

Step 4: {'Step': 'Check interface status', 'Action': "Verify the status of the interface connected to the BFD session using the command 'show interface brief'. Check if the interface is up or down.", 'CLI_Command': 'show interface brief'}

Post-Check Verification

```
show bfd session detail
show bfd session summary
show interface brief
```