

Ericsson PE Router SOP for Alarm Code

ALARM_9184

Node: Ericsson-PE-Kolkata-WB-129 | **Vendor:** Ericsson | **Severity:** Warning | **Alarm Code:** ALARM_9184

Description

This SOP outlines the procedure to diagnose and resolve the Ericsson PE Router alarm ALARM_9184, which is triggered when a warning condition is detected.

Potential Root Causes

Cause	Probability
Interface Flapping	High
Hardware Failure	Medium
Software Bug	Low

Diagnostic Commands

```
show interface | include Flapping
show cpu | include Overload
show system resources | include Memory
```

Resolution Steps

- Step 1: {'Step': 'Check the interface for flapping', 'Description': "Verify if the interface is flapping by executing the command 'show interface | include Flapping'.", 'CLI_Command': 'show interface | include Flapping'}
- Step 2: {'Step': 'Check for hardware failure', 'Description': "Verify the hardware status by executing the command 'show system resources | include Error'.", 'CLI_Command': 'show system resources | include Error'}
- Step 3: {'Step': 'Check for software bug', 'Description': "Verify the software version and check for any known bugs by executing the command 'show version'.", 'CLI_Command': 'show version'}
- Step 4: {'Step': 'Restart the interface', 'Description': "Restart the interface by executing the command 'interface | shutdown' followed by 'interface | no shutdown'.", 'CLI_Command': 'interface | shutdown'}

Post-Check Verification

```
show interface | include Flapping
show cpu | include Overload
```

```
show system resources | include Memory
```