

Huawei Access Switch Alarm SOP: ALARM_8655 (Critical)

Node: Huawei-Access-Mumbai-MH-42 | **Vendor:** Huawei | **Severity:** Critical | **Alarm Code:** ALARM_8655

Description

This SOP outlines the procedure for diagnosing and resolving the ALARM_8655 alarm on Huawei Access Switch Node ID: Huawei-Access-Mumbai-MH-42. The alarm indicates a critical issue that requires immediate attention.

Potential Root Causes

Cause	Probability
High CPU Utilization	High
Memory Leak	Medium
Interface Misconfiguration	Low

Diagnostic Commands

```
display cpu utilization
display memory
display interface status
debug enable
debug interface
```

Resolution Steps

Step 1: {'Step': '1. Check CPU Utilization', 'Action': "Run the command 'display cpu utilization' to check the CPU utilization level. If it exceeds 80%, proceed to the next step.", 'CLI_Command': 'display cpu utilization'}

Step 2: {'Step': '2. Check Memory', 'Action': "Run the command 'display memory' to check the memory utilization level. If it exceeds 90%, proceed to the next step.", 'CLI_Command': 'display memory'}

Step 3: {'Step': '3. Check Interface Status', 'Action': "Run the command 'display interface status' to check the interface status. If an interface is down or misconfigured, proceed to the next step.", 'CLI_Command': 'display interface status'}

Step 4: {'Step': '4. Clear Debug History', 'Action': "Run the command 'debug clear all' to clear the debug history.", 'CLI_Command': 'debug clear all'}

Step 5: {'Step': '5. Reboot the Switch', 'Action': "Run the command 'reload' to reboot the switch.", 'CLI_Command': 'reload'}

Step 6: {'Step': '6. Verify the Issue is Resolved', 'Action': "Run the command 'display alarm' to verify the ALARM_8655 alarm is cleared.", 'CLI_Command': 'display alarm'}

Post-Check Verification

```
display alarm
display cpu utilization
display memory
display interface status
```