

Huawei Access Switch SOP for Minor Alarm

ALARM_3232

Node: Huawei-Access-Mumbai-MH-50 | **Vendor:** Huawei | **Severity:** Minor | **Alarm Code:** ALARM_3232

Description

This SOP outlines the steps to identify, diagnose, and resolve the minor alarm ALARM_3232 on Huawei Access Switch Node ID: Huawei-Access-Mumbai-MH-50.

Potential Root Causes

Cause	Probability
Optical Module Fault	High
Cable Fault	Medium
Switch Configuration Issue	Low

Diagnostic Commands

```
display current-configuration | include alarm 3232
display alarm-alarm 3232
display device optical-module
display device slot
ping
```

Resolution Steps

- Step 1: {'Step': 1, 'Description': 'Verify the alarm status', 'Command': 'display alarm-alarm 3232'}
- Step 2: {'Step': 2, 'Description': 'Replace the faulty optical module (if applicable)', 'Command': 'system-view\ninterface GigabitEthernet 0/0/0\nreplace optic-module'}
- Step 3: {'Step': 3, 'Description': 'Check the cable connections', 'Command': 'display device slot'}
- Step 4: {'Step': 4, 'Description': 'Configure the switch to disable the alarm', 'Command': 'system-view\nalarm enable false'}
- Step 5: {'Step': 5, 'Description': 'Verify the alarm status after configuration', 'Command': 'display alarm-alarm 3232'}

Post-Check Verification

```
display alarm-alarm 3232
```

```
display current-configuration | include alarm 3232  
ping
```